User Manual

ARS788BTHP

(Fold Inward) – – – – ▶

(Back Cover)

(Front Cover)

Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside
This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatiblechargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

Rating Label Definitions

⎓ Direct current symbol.

This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

BC This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.

Bluetooth® This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

RECYCLE RBRC Li-ion 1.800.822.8837

Warranty Information

60-Day Limited Warranty
Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER
This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service:
- Visit our customer support portal: www.customersupport123.com
- Select the brand and model of your device
- Select "Service Request" and fill out the form to begin your inquiry
- Exchanges require dated proof of purchase from an authorized retailer

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.

Designed in US
Printed in China
V1. 5-2026

ART+SOUND™

ACTIVE NOISE CANCELLATION

Instruction Manual
ARSANCHP

Bluetooth headset

Before You Begin...

Customer Support
For any questions or problems with your product, please visit our website at customersupport123.com.

⚠ Caution
To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.
- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- The headphones contain a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box
- Wireless Headphones (x1)
- USB Charging Cable (x1)
- Instruction Manual (x1)

Controls and Specifications

Power Button
- **Power On:** Press and hold the power button for 3-5 seconds. the indicator light will briefly emit a blue light, followed by a flashing pattern of red and blue.
- **Power Off:** Press and hold the power button for 3-5 seconds. The indicator light will briefly illuminate in red and then go out, accompanied by a "power off" voice prompt.
- **Play / Pause:** Short press the power button during music playback to pause or resume your audio.
- **Answer a Call:** Short press the power button when receiving an incoming call. The device will stream your phone's native ringtone.
- **End a Call:** Short press the power button during an active call to hang up.
- **Reject a Call:** Press and hold the power button to decline an incoming call.
- **Redial (Call Back):** Double-click the power button to automatically redial the last number in your call log.

Volume Up / Next Track Button
- Next Track: Briefly press the button to skip to the next track.
- Increase Volume: Press and hold the button to raise the volume level. A voice prompt will sound once you reach the maximum volume threshold.

Volume Down / Previous Track Button
- Previous Track: Press the button briefly to go back to the previous song.
- Decrease Volume: Press and hold the button to lower the volume level.

ANC Toggle Switch
1. Enable ANC: Flick the switch to turn on Active Noise Cancellation. A dedicated green indicator light will turn on and remain steady.
2. Disable ANC: Flick the switch to turn off Active Noise Cancellation. The green indicator light will turn off.

Product Specifications
Charging Input: Rated at 200mA.
Music Playback Current: 16 ~ 23 mA
Voice Call Current: 23 ~ 26 mA
Standby Current: 3 ~ 8 mA

Getting Started

Power & Charging
1. Low Battery Alert: When the battery runs low, the device will periodically broadcast a "low battery, please charge" voice prompt.
2. Charging Status: Connecting a charger forces the device to power downautomatically. While charging, the red light will turn on.
3. Fully Charged: Once the battery reaches 100% capacity, the indicator light will turn completely off.
4. Auto-Shutdown (Power Saving): To preserve battery life, the device will automatically shut down after 3 minutes if it remains idle or disconnected from Bluetooth.

Bluetooth Pairing & Connectivity
1. Pairing Mode: The device automatically enters pairing mode upon startup if no previous connection is found. The LED indicator will flash red and blue alternately.
2. Connecting to the Device: Open the Bluetooth settings on your smartphone, tablet, or computer and scan for available devices. Select the model number "ARSANCHP" from the pairing list to establish a connection.
3. Successful Connection: Once successfully paired to your device, the LED indicator will turn off once successfully paired.
4. Disconnected State: If the device loses its wireless connection or goes out of range (> 33 ft) , it will announce "disconnected".