

G101 TWS earphone User Manual

FCC ID: 2BHIM-ANC



Warning

Special Note: Before using the earphone for the first time, please put the earphone into the ordinary charging case once and then remove it. Only then can touch be effective.

Please read the warnings below carefully. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to

To reduce the risk of injury :

Keep batteries out of reach of children.

Do not heat, open, or dispose of battery pack in fire.

Do not allow metal objects to touch the battery on the device.

Do not expose battery pack to excessive heat.

Do not use a high current charger, or the charging line will burn out.

Please Charging with a DC 5V adapter (not included in the package).

Product Specification

- Product model: G101
- Bluetooth solutions: JL 7006F
- Bluetooth version: V6.0+BR+EDR+BLE
- Bluetooth decoding: SBC
- Bluetooth working frequency: 2.402GHz-2.480GHz
- Frequency response: 20Hz-20kHz
- Speaker size: 10mm
- Sensitivity(speaker unit): $102 \pm 3\text{dB}$ at 1kHz
- Speaker impedance (speaker unit): $16\Omega \pm 5\%$ at 1mW / 1000Hz
- Mic sensitivity: $-42 \pm 3\text{dB}$
- Effective distance: 10m (in an ideal environment without any large obstacles)
- Earphones battery capacity: 30mAh, 401012

- Charging case battery capacity:200mAh,502030
- Playing time:3-4hours (High quality music and volume may accelerate battery consumption)
- Earphone charging time: about 2 hours

Pairing

1: Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

2: Syncing your earphones..

When earphones do not sync together or enter disconnected state during use.

- 1): Turn off both earphones and turn back on.
- 2): If that does not work, placing both earphones back into case, closing the charging case and then open the charging case again.
- 3): While earphones is out of the charging case. Press and hold both earphones for 3 seconds. This will force the earphones to turn off and on again and sync with each other.

3: Open up Bluetooth setting on your smart device and scan for **G101**.

Operation

1: Power on/off .

- 1.) Take the earphones out of the charging case, automatically turn on;
Put the earphones back to the charging case, automatically turn off;
- 2.) Long press 3 seconds to turn on
Long press 5 seconds to turn off.

2: Play/Pause music.

When listening to music.

Tap left/right earphones once to play or pause the music.

3: Previous /Next Song

When listening to music.

Quick double tap left earphones to go to previous song.

Quick double tap right earphones to go to next song.

4: Volume +/-

Quick tap left earphones 3 times to increase the volume.

Quick tap right earphones 3 times to decrease the volume.

5: Answer/Hang up

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

6: Reject

When there is an incoming call.

Long press left or right earphones for 2 seconds to reject the call.

7: Voice assistant

Long press left or right earphones for 2 seconds

Charging Function

Fully charge the case and earphones before using for the first time.

1: Charging the charging case

When the charging case is charging, the red indicator flashes. When the charging case is fully charged, the red light stays on

2: Earphone charging

When battery is low, each 5s flash once for left and right-side red light at the same time, you will listen to a warning sign or tone. It will turn off when the earphones completely out of battery.

(a) Place the earphones into the charging case.

(b) red light on the earphones turns on when charging has begun. The light will turn off when charging is complete.

Package Contents:

- 2 x headset
- 1 x User manual
- 1 x Type-C cable

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.