

产品说明书 尺寸:60x90mm 材质:80g书写纸 双面印刷 风琴折

MINISO

PRODUCT MANUAL

Wireless Earbud MS108

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT IN A SAFE PLACE.

EN

What's in the box

Charging case

2 Earphones (A)

2 Earphones (B)

Quick Start Guide

Lanyard

USB-C cable

Components

Earphone LED

Touchpad

Charging case display

Charging contacts

USB Type-C port

How to put on the earphones

Basic operations

Power on/off

Music mode

Reset earphones

Phone mode

Reset earphones

How to reset the earphones

Key functions

Note: Mode switching is disabled when you're using a single earphone only.

Indicator LEDs

Power on

Power off

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.

Connect to Bluetooth device

Connect to Bluetooth device

FCC ID: 2BHJR-MS10801

FCC Warning:

The above guarantee does not apply to the following situations

Warranty Policy

Guidelines for safe and effective use

Important safety tips

Enjoy the company of MINISO

Creating sound to live with

Copyright©2025 MINISO Group affiliated companies and its licensors. All rights reserved