


产品说明书 尺寸:70x95mm 材质:80g书写纸 双面印刷 风琴折

Wireless Earbud N01



Quick Start Guide ZNP-N01

Specification of Product

Model of Product: ZNP-N01

Bluetooth

Range: 10 m
Version: 6.0

Speaker

Diameter: 16 mm
Impedance: 16 Ω


Earphone power

Input: 5V=70 mA
Battery capacity: 70 mAh
Battery life: >8 hrs
Charging time: <1.5 hrs

Charging case power

Input: 5V=400 mA
Output: 5V=140 mA
Battery capacity: 400mAh
Charging time: <1.5 hrs
Earphone recharges: 1 charges (when case is fully charged)

Power on and off



Power On
Auto power on: If the Earphone are taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du".
Manual power on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du".

Power Off
Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du".
Manual power off: Long press for 3 seconds, the Earphone will be powered off, with the prompt sound of "Du".


Note: After power on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down. Extended the effective connection distance and do not connect to the Bluetooth device. It will automatically power off after 3 minutes, with the prompt sound of "Du".

Connect to Bluetooth device




Open the Bluetooth settings option of the Bluetooth device. If it is not paired, select the option and find the Bluetooth pairing name of the headset "ZNP-N01". Click the pairing name to pair the Earphone.

What's in the box




- Charging case *1
- Headphones *2
- Instruction *1
- Charging cable *1

Components



Basic operations



Power on/off
L: Tap the earbud to power on/off.
R: Tap the earbud to power on/off.

Phone mode
L: Tap the earbud to enter phone mode.
R: Tap the earbud to enter phone mode.

Music mode
L: Tap the earbud to play/pause music.
R: Tap the earbud to play/pause music.

Reset earphones
L: Tap the earbud to reset.
R: Tap the earbud to reset.

Key functions

- Play/Pause: Tap either earphone once.
- Volume up: Tap the right earphone twice.
- Volume down: Tap the left earphone twice.
- Play previous track: Tap the left earphone three times.
- Play next track: Tap the right earphone three times.
- Answer/End call: Tap either earphone once.
- Repeat call: Press and hold either earphone for two seconds.
- Activate voice assistant: Press and hold the left earphone for two seconds.

Note: When using a single earphone only, press and hold the active earphone for two seconds.


- Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)

Note: Mode switching is disabled when you're using a single earphone only.

Indicator LEDs	Status
Blinking white and red	Both earphones: Powered on Single earphone: Unpaired
Solid red	Charging
Off	Paired or fully charged

Note: Mode switching is disabled when you're using a single earphone only.


Take out and pair the earphones



If you are using the earbuds for the first time, take both earbuds out of the charging case. The LED light on one of the earbuds will flash white and red alternately, indicating they are in pairing mode.

Note:
• If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful.
• If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.

How to put on the earphones




1. Insert the earbud into the ear.

2. Adjust the earbud to fit the ear.


3. The earbud is now correctly positioned.

Clear Bluetooth pairing history



When both ears cannot be paired, you need to clear all connected devices and click the left and right earphones 5 times at the same time.

Charging compartment operation




Lighting up the display screen
Method 1: When the screen is off, double-tap the display to turn it on.
Method 2: Press the multifunction button of the Charging Case once to light up the screen.

Turn off display screen.
Automatic shutdown: If there is no operation for an extended period after the screen is turned on, the display screen will automatically turn off.
Manual shutdown: Press the multifunction button on the charging case once to turn off the display screen.

You can also select the screen lock time on the charging case.

Wireless pairing mode
1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically enter pairing mode after they are turned on. After several pairing times, they will be paired.
2. When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "Beep".

Definition of multifunction button functions



Click once: On/Off screen.
Click once: Turn the screen on/off.
Long press for 5 seconds: In power-on mode, long press for 5 seconds, and the screen will display shutdown and restart icons. Swipe the icon to perform shutdown or restart.
Long press for 3 seconds: In shutdown mode, long press for 3 seconds to turn on the device.
Long press for 10 seconds: Restart the system (display the startup screen). This operation can be performed when the system crashes and cannot be operated.

Triple-tap: Click three times: Charging case paired with earbuds.

Icon Introduction


Display Screen Features

Lock screen interface




Double-tap or press the multifunction button to wake the screen.

AI Chat interface




Tap the screen to start chatting.

Music interface



Previous Song Play/Pause Next Song Volume up/down

Volume adjustment interface




Swipe left or right to adjust volume.
 Reduce volume, minimum music is 0 Increase volume, maximum volume is 100

TikTok Page flipping and like function




Go back to previous video Like the current video Go to the next video
 This feature only works with the TikTok app and may not be compatible with all phone models.

Translation interface




Turn on the in-app translation function, and the translated content will be displayed here in real time.

Equalizer interface



Tap the icon to switch between different EQ sound effects: Standard, Rock and roll, Pop, Classic, Jazz.


Find My Earphone interface



Click the L/R button, and the earphone speaker will start emitting sound. Click the same button again to stop the sound.

Remote photo capture

Needs to be connected to a Bluetooth device such as a cell phone.
 1. This function is only available for using phones with the Bluetooth camera of the phone. Other shooting software may not be able to work.
 2. This feature may have compatibility issues with some phones, and some phones may not be able to use it.
 3. If there are situations where it cannot be used, please ignore this feature.




Open the phone camera, click the button (📷), and the phone will start taking photos.

Game Interface



There are 2 game modes to choose from.


Brightness Adjustment and Sleep Interface



Swipe left or right to adjust the screen brightness.
 1. Swipe left to enter screen lock time adjustment.
 2. Swipe up or down to select the sleep duration.

Settings

Scroll up and tap an item to access its options.



Turn on **AI** to activate syncing with the phone's language.
 Turn on **AI** to enable speed-dialing for selecting different languages.

Language Settings



Turn on **AI** to activate syncing with the phone's language.
 Turn on **AI** to enable speed-dialing for selecting different languages.

Desktop Style




Swipe left or right and tap to set your favorite wallpaper.

Menu Style



Swipe up or down to choose from 3 menu styles.

Time Settings



Automatic update: When the charging case, headphones, and phone are connected, the time on the phone will be automatically updated to the charging case.
 Manual update: Click the button to enter manual settings.

Important Safety Instructions

Conformally read all safety instructions in this document before using the product.
 • Use the product with care and store it in a clean environment that is free from excessive temperature, moisture, and humidity. Make sure that the product is stored in a location where it cannot be lost or squashed.
 • Repair and replacement should only be performed by authorized after sales service staff. Do not attempt to disassemble or replace any part of the product prior to preventative or damage to the device. Any unauthorized modification to the product voids the warranty.
 • Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions
 • Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
 • Do not use the product when performing high-volume tasks that require your full attention.
 • For your hearing protection, do not listen at high volume for long periods.
 • Remove the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions
 The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.
 • Keep the product away from prolonged exposure to heat sources such as open fire or direct sunlight.
 • Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
 • Do not use or store the product in dampness, smoke, or highly humid environments.
 • Keep the product dry and away from liquids or moisture.
 • Only use an FCC or CE-Certified charger with an output voltage of 5V/1 A DC.
 • Do not use the product while charging.
 • Dispose of the product responsibly according to your local waste management guidelines.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction