

hTC
无线蓝牙耳机46

产品规格
型号:HTC NE46

蓝牙
范围:≈10m
版本:6.0

喇叭
直径:10mm
阻抗:32Ω

耳机功率
输入:5V=30mA
电池容量:320mAh
使用时间:≈4小时
充电时间:≈1.5小时

充电仓功率
输入:5V=320mA
输出:5V=60mA
电池容量:320mAh
充电时间:≈1.5小时
充电仓充满电时,可给耳机充电约2次

快速入门指南
使用前请阅读使用说明书
HTC NE46

物品清单

快速入门指南
USB-C 充电线

部件

心率检测传感器
耳机指示灯
多功能触摸键
充电触点
耳机喇叭
充电仓显示屏
Type-C 充电口
多功能按键

取出耳机并配对

如果您第一次使用耳机,请将两个耳机从充电仓中取出,其中一个耳机的LED灯将会闪烁白灯,表示它们处于配对模式。
配对成功,会有提示音。
-如果耳机未与任何设备配对,打开后会启动自动配对模式。
-如果耳机之前已配对,打开后会启动重新连接,连接时会听到提示音。

如何佩戴耳机

开机和关机

开机
自动开机:将耳机从充电仓中取出,耳机开机。
手动开机:长按3秒,耳机开机。
关机
自动关机:耳机放入充电仓中,耳机关机。
手动关机:长按2秒,耳机关机。

连接到蓝牙设备

基本操作

功能操作
-暂停/播放:轻触任一耳机一次
-音量加:轻触右耳机二次
-音量减:轻触左耳机二次
-上一曲:轻触左耳机三次
-下一曲:轻触右耳机三次
-接听/挂断电话:轻触任一耳机一次
-播放/暂停:轻触任一耳机两秒
-启动语音助手:按住左耳机两秒
注:单耳使用时,按住已开机的耳机2秒,均可激活语音助手
-游戏模式与音乐模式切换:按住右耳机3秒并快速
注:佩戴耳机时,无法切换游戏模式或音乐模式
注:出厂设置默认为音乐模式
注:通知声音较大的游戏模式

指示灯显示

耳机指示灯	状态
白灯闪烁	两个耳机:开机 单耳机:未配对
白灯常亮	耳机充电中
红灯	配对成功或充满电

如何清除蓝牙配对历史记录

双耳从充电仓取出后会自动开机配对,耳机未与蓝牙设备连接前耳机从蓝牙设备取消连接状态下,分别对左耳机和右耳机连续五击多功能键,提示音“嘟”四声后,耳机自动关机后将双耳机放回充电仓,再长按耳机取出,双耳机仓会自动配对,完成后即可连接蓝牙耳机使用。
适用于以下情况:
A:双耳无法配对时,单边边音,双配对长时。
B:使用单耳机时个别蓝牙不同蓝牙设备时。
C:清除连接的有蓝牙耳机时。
特别提示:
当单边耳机出现无音,或者无法配对时,请按以上恢复重置操作。

充电仓基本操作

多功能按键功能

单位:打开/关闭耳机
三击:充电仓与耳机配对。
长按4秒:进入系统菜单:“关机”和“重置”、“恢复出厂”。
长按3秒:关机状态下,开机。
长按2秒:耳机充电仓,充电仓设置。

图标介绍

图标	状态
红色	耳机在充电仓中,未连接到耳机
白色	充电仓已连接到耳机,但耳机未连接到手机
黄色	充电仓已连接到耳机,且耳机已连接到手机
绿色	耳机充电中
黄色	耳机使用中或充满电
绿色	耳机使用中或充满电
黄色	充电仓充电中
绿色	充电仓未充电

均衡器

寻找耳机

手电筒

语言切换

产品有害物质名称及含量

部件名称	有害物质
印刷电路板组件	铅(Pb) 0.01% 镉(Cd) 0.01% 六价铬 0.01% 多溴联苯(PB) 0.01% 多溴二苯醚(PBB) 0.01%
外壳等小结构件	0.01% 0.01% 0.01% 0.01%

重要安全说明

在使用本产品之前,请仔细阅读说明书中的所有安全说明。

常规安全说明

-小心使用本产品,并始终存放在没有极端温度、高温高压和潮湿的高温环境中,确保产品存放在安全不易被破坏的地方。
-避免将本产品长时间暴露在阳光下,以免损坏。
-请勿将本产品长时间存放在潮湿或温度过高等环境中,请勿使用。
-执行需要安全操作的任务时,请勿使用本产品。
-为了保护您的听力,请勿长时间高声听音乐。
-请勿将产品存放在潮湿、高温、高压或潮湿的环境中,请勿使用或存放本产品。
-保持产品干燥,远离液体或湿气。
-只能使用符合 FCC 认证、输出电压为 DC 5V/1A 的充电器。
-充电器不可用于本产品。
-产品充电时间不要超过2小时。
-按照当地的废物管理法规负责处理本产品。

电池安全说明

该产品内置可充电电池,请阅读以下说明,确保安全使用和处置。
-请勿将产品长时间存放在高温(如 35°C (95°F) 以上)的环境中。
-仅将产品存放在环境温度在 0°C 至 35°C (32°F 至 95°F) 的环境中。
-请勿将产品与易燃、易爆、高温、高压或潮湿的环境中存放或使用或存放本产品。
-保持产品干燥,远离液体或湿气。
-只能使用符合 FCC 认证、输出电压为 DC 5V/1A 的充电器。
-充电器不可用于本产品。
-产品充电时间不要超过2小时。
-按照当地的废物管理法规负责处理本产品。

法律声明
商标和版权:
HTC和HTC标志为HTC公司的商标。
使用或销售本产品上沃特利科技有限公司。
2025版权归深圳市上沃特利科技有限公司所有。
本文件仅供参考,不构成任何形式的保证,本公司保留所有权利。

HTC Wireless Earphones 46 Quick Start Guide HTC NE46 1	Product Specifications Model: HTC NE46 Bluetooth Range: >10 m Version: 6.0 Speaker Diameter: 10 mm Impedance: 32 Ω Earphone power Input: 5 V=30 mA Battery capacity: 30 mAh Battery life: > 4 hrs Charging time: > 1.5 hrs Charging case power Input: 5 V=320 mA Output: 5 V=50 mA Battery capacity: 320 mAh Charging time: > 1.5 hrs Earphone recharges: 2 charges (when case is fully charged) 2	What's in the box Charging case 2 Earphones Quick Start Guide USB-C cable 3	Components 4	Take out and pair the earphones If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white, indicating that they are in pairing mode. Note: - If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. - You'll hear two beeps when pairing is successful. - If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect. 5	How to put on the earphones 6 7																											
Power on and off Power on Taking the earphones out of the charging case will automatically turn them on. To manually turn on each earphone, press and hold the touchpad for three seconds. Power off Placing the earphones in the charging case will automatically turn them off. To manually turn off each earphone, press and hold the touchpad for five seconds. Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected. 8	Connect to Bluetooth device On your device, turn on Bluetooth and choose to connect to "HTC NE46". Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected. 9	Basic operations 10	Key functions • Play/Pause: Tap the right earphone twice. • Volume up: Tap the right earphone twice. • Volume down: Tap the left earphone twice. • Play previous track: Tap the left earphone three times. • Play next track: Tap the right earphone three times. • Answer/End call: Tap either earphone once. • Reject call: Press and hold either earphone for two seconds. • Activate voice assistant: Press and hold the left earphone for two seconds. Note: When using a single earphone only, press and hold the active earphone for two seconds. • Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.) Note: Mode switching is disabled when you're using a single earphone only. Indicator LEDs <table> <tr> <th>Earphone LED</th><th>Status</th></tr> <tr> <td>Blinking white</td><td>Both earphones: Powered on Single earphone: Unpaired</td></tr> <tr> <td>Solid white</td><td>Earphone charging</td></tr> <tr> <td>Off</td><td>Paired or fully charged</td></tr> </table> 11	Earphone LED	Status	Blinking white	Both earphones: Powered on Single earphone: Unpaired	Solid white	Earphone charging	Off	Paired or fully charged	How to reset the earphones If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history. 12	Case display: Basic operations Turn on display Tap the display twice or press the multifunction button once. Turn off display Press the multifunction button once to turn off the display. The display automatically turns off after 30 seconds of inactivity. Note: Initial activation required for first-time use. Do any of the following: • Charge the charging case via the USB Type-C port. • Press and hold the multifunction button for five seconds. 13	Multifunction button operations Press once: Turn the screen on/off. Press three times: Link earphones to charging case. Press and hold for four seconds: Open the system menu (Restart, Power off, and Factory reset) Press and hold for five seconds: Power on the screen (when off). Press and hold for eight seconds: Restore to factory settings. Status Icons Guide <table> <tr> <td></td> <td>Earphones in case, not connected to phone</td> </tr> <tr> <td></td> <td>Case connected to earphones, but earphones offline</td> </tr> <tr> <td></td> <td>Case connected to earphones, earphones paired to phone</td> </tr> <tr> <td></td> <td>Status</td> </tr> <tr> <td></td> <td>Earphones charging</td> </tr> <tr> <td></td> <td>Earphones in use/Earphones fully charged</td> </tr> <tr> <td></td> <td>Status</td> </tr> <tr> <td></td> <td>Charging case is being charged</td> </tr> <tr> <td></td> <td>Charging case is not being charged</td> </tr> </table> 14		Earphones in case, not connected to phone		Case connected to earphones, but earphones offline		Case connected to earphones, earphones paired to phone		Status		Earphones charging		Earphones in use/Earphones fully charged		Status		Charging case is being charged		Charging case is not being charged
Earphone LED	Status																															
Blinking white	Both earphones: Powered on Single earphone: Unpaired																															
Solid white	Earphone charging																															
Off	Paired or fully charged																															
	Earphones in case, not connected to phone																															
	Case connected to earphones, but earphones offline																															
	Case connected to earphones, earphones paired to phone																															
	Status																															
	Earphones charging																															
	Earphones in use/Earphones fully charged																															
	Status																															
	Charging case is being charged																															
	Charging case is not being charged																															
Case display: Feature overview Lock screen Swipe right to unlock the screen. With the screen unlocked, swipe left or right to go through these features. Music playback Previous Track Play/Pause Next Track 15	Volume Volume down Volume up Min. volume: 0 Max. volume: 16 TikTok Make sure your earphones are connected to your phone and the TikTok app is open. For iOS devices, AssistiveTouch must be turned on in Settings > Accessibility > Touch > AssistiveTouch. Go back to previous video Like the current video Go to the next video This feature only works with the TikTok app and may not be compatible with all phone models. 16	Camera Make sure your earphones are connected to your phone. Tap to open the phone's camera app and then press the multifunction button to take photos. This feature only works with the pre-installed camera app and may not be supported on all phone models. Settings Tap an item to access its options. 17	Heart rate monitoring (static) Wear headphones correctly (Incorrect use will make the following functions unavailable) 1. When testing, you must wear the left and right earphones. 2. The test must be conducted in a static environment (Attention: Cannot be used while exercising). Wear the left and right earphones correctly, click on , enter to start measuring, stay on the screen for about 15-30 seconds, and the measurement results will be displayed. (First measurement: waiting for about 30-50 seconds) After the measurement is completed, the measurement results of will be displayed, or you can click to display the measurement result. 18	Blood oxygen Wear headphones correctly (Incorrect use will make the following functions unavailable) 1. When testing, you must wear the left and right earphones. 2. The test must be conducted in a static environment (Attention: Cannot be used while exercising) Wear the left and right earphones correctly, click on , enter to start measuring, stay on the screen for about 45-60 seconds, and the measurement results will be displayed. After the measurement is completed, the measurement results of will be displayed, or you can click to display the measurement result. 19	Equalizer Tap to switch between the preset equalizer settings. Lock screen wallpaper Tap to choose a wallpaper for the case display. 20	Find my earphones Tap or depending on which earphone you want to find. Tap Start and a beeping sound will emit from the earphone you're trying to find. When you find																										