











 无线蓝牙耳机81  快速入门指南 使用前请阅读使用说明书 HTC NE81	产品规格 型号: HTC NE81 蓝牙 范围: ≈ 10m 版本: 6.0 喇叭 直径: 8mm 阻抗: 32Ω 耳机功率 输入: 5V=28mA 电池容量: 28mAh 使用时间: ≈ 4.5小时 充电时间: ≈ 1.5小时 充电仓功率 输入: 5V=300mA 输出: 5V=56mA 电池容量: 300mAh 充电时间: ≈ 1.5小时 充电仓充满电时, 能给耳机充电约3次	物品清单  快速入门指南 USB-C充电线 6耳帽	耳机部件  多功能触控键 耳机指示灯 耳机喇叭 充电触点 充电仓指示灯 Type-C 充电口	取出耳机并配对  蓝牙耳机: 如果您是第一次使用耳机, 请将两个耳机从充电仓中取出, 其中一个耳机的LED灯将会交替闪烁白灯和蓝灯, 表示它们处于配对模式。 注: - 如果耳机未与任何设备配对, 打开后会自动进入配对模式。配对成功后, 您会听到提示音。 - 如果耳机之前已配对, 打开后会自动重新连接。连接时您会听到提示音。 有线耳机: 如果您是第一次使用耳机, 将 Type-C 耳机插头插入设备底部的 Type-C 音频孔, 即可直接使用, 无需蓝牙连接。	如何切换蓝牙/有线耳机 蓝牙耳机:  有线耳机:  左右区分: 耳机本体和耳挂上均标注 L (左)/R (右), 请按标识对应佩戴, 确保声学体验。	如何佩戴耳机  1	有线耳机基本操作  注意事项: 1. 耳机触摸时默认进入声卡 (耳返) 模式 2. 可用另一台手机蓝牙连接 “HTC NE81 伴奏” 播放伴奏。 3. 本品标配 Type-C 接口声卡音频线, 仅支持带有 Type-C 接口的设备。 4. 线控状态只有声卡模式可以通话, 音乐模式不行。 5. 男变女、女变男 通话模式下, 需断开蓝牙 (苹果15以下不支持) <table> <tr> <th>使用方法</th><th>功能描述</th><th>按键操作</th></tr> <tr> <td rowspan="4">声卡功能</td><td>声卡模式/耳机模式</td><td>长按 2s 切换</td></tr> <tr> <td>变音糖、KTV、原声、男变女、女变男、音乐律动模式</td><td>单击 ② 切换</td></tr> <tr> <td>麦克风音量加</td><td>单击 ③ 切换</td></tr> <tr> <td>麦克风音量减</td><td>单击 ① 切换</td></tr> <tr> <td rowspan="4">声卡模式下</td><td>变音特效</td><td>长按 ③ 3s 切换</td></tr> <tr> <td>音乐暂停/播放</td><td>单击 ②</td></tr> <tr> <td>上一曲</td><td>三击 ②</td></tr> <tr> <td>下一曲</td><td>双击 ②</td></tr> <tr> <td rowspan="2">耳挂模式下</td><td>耳机音量加</td><td>单击 ③</td></tr> <tr> <td>耳机音量减</td><td>单击 ①</td></tr> </table>	使用方法	功能描述	按键操作	声卡功能	声卡模式/耳机模式	长按 2s 切换	变音糖、KTV、原声、男变女、女变男、音乐律动模式	单击 ② 切换	麦克风音量加	单击 ③ 切换	麦克风音量减	单击 ① 切换	声卡模式下	变音特效	长按 ③ 3s 切换	音乐暂停/播放	单击 ②	上一曲	三击 ②	下一曲	双击 ②	耳挂模式下	耳机音量加	单击 ③	耳机音量减	单击 ①																
使用方法	功能描述	按键操作																																															
声卡功能	声卡模式/耳机模式	长按 2s 切换																																															
	变音糖、KTV、原声、男变女、女变男、音乐律动模式	单击 ② 切换																																															
	麦克风音量加	单击 ③ 切换																																															
	麦克风音量减	单击 ① 切换																																															
声卡模式下	变音特效	长按 ③ 3s 切换																																															
	音乐暂停/播放	单击 ②																																															
	上一曲	三击 ②																																															
	下一曲	双击 ②																																															
耳挂模式下	耳机音量加	单击 ③																																															
	耳机音量减	单击 ①																																															
开机和关机  开机 自动开机: 将耳机从充电仓中取出, 耳机开机。 手动开机: 长按3秒, 耳机开机。 关机 自动关机: 耳机放入充电仓中, 耳机关机。 手动关机: 长按3秒, 耳机关机。 注: 当耳机开机后, 3秒种将与蓝牙耳机配对, 便会自动开机; 当配对的蓝牙耳机超出信号有效连接范围, 且未重新连接时, 3秒种后, 耳机自动关机。	连接到蓝牙耳机  在您的设备上, 打开蓝牙并选择连接到“HTC NE81”。	基本操作  开机/关机 3s/5s 音乐模式 ANC 麦克风 多功能键	功能操作 - 暂停/播放: 轻触任一耳机一次 - 音量加: 轻触右耳机二次 - 音量减: 轻触左耳机二次 - 上一曲: 轻触左耳机三次 - 下一曲: 轻触右耳机三次 - 接听/挂断电话: 轻触任一耳机一次 - 通话拒接: 长按任一耳机2秒 - 启动语音助手: 按住左耳机2秒 - 注: 单耳使用时, 按住已开机的耳机2秒, 均可激活语音助手 - 游戏模式与音乐模式切换: 按住右耳机2秒切换 - 注: 单耳使用时, 无法切换游戏模式和音乐模式 - 注: 出厂设置默认作为音乐模式 - 注: 通知声音较大的是游戏模式 - 切换ANC降噪模式: 轻触任一耳机四次, 可在模式间切换。(共有三种模式可供切换, 正常模式/ ANC降噪模式/透明模式) 指示灯显示 <table> <tr> <th>耳机指示灯</th><th>状态</th></tr> <tr> <td>白灯和蓝灯交替闪烁</td><td>两个耳机/开机</td></tr> <tr> <td>蓝色常亮</td><td>单耳机: 未配对</td></tr> <tr> <td>天灯</td><td>配对成功或充满电</td></tr> <tr> <th>充电仓指示灯</th><th>状态</th></tr> <tr> <td>蓝色常亮</td><td>耳机充电中</td></tr> <tr> <td>白灯闪烁</td><td>充电仓充满电</td></tr> <tr> <td>白灯常亮</td><td>充电仓充满电</td></tr> </table>	耳机指示灯	状态	白灯和蓝灯交替闪烁	两个耳机/开机	蓝色常亮	单耳机: 未配对	天灯	配对成功或充满电	充电仓指示灯	状态	蓝色常亮	耳机充电中	白灯闪烁	充电仓充满电	白灯常亮	充电仓充满电	如何清除蓝牙配对历史记录  双耳从充电仓取出后会自动开机配对, 耳机未与蓝牙设备连接或耳机从蓝牙设备取消连接状态下, 分别对左耳机和右耳机连续五击多功能键, 提示音“嘟”四声后, 耳机自动关机后将双耳机放回充电仓, 再将双耳机取出, 双耳机将自动配对, 完成后即可连接蓝牙设备使用。 适用以下情况: A: 双耳无法配对时, 单边音时, 双配对旁时; B: 使用单耳机分别连接不同蓝牙设备时。 C: 清除连接的所有蓝牙设备时。	产品中有有害物质名称及含量 <table> <tr> <th rowspan="2">部件名称</th><th colspan="6">有害物质</th></tr> <tr> <th>铅(Pb)</th><th>汞(Hg)</th><th>镉(Cd)</th><th>六价铬(Cr(VI))</th><th>多溴联苯(PBB)</th><th>多溴二苯醚(PBDE)</th></tr> <tr> <td>印刷电路组件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr> <td>外壳等小结构件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> </table> 本表格依据 SJ/T 11364 的规定限量要求。 ○ : 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 × : 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。 表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。 印刷电路组件: 包括印刷电路板及其零部件、电子元器件等, 根据产品类型不同, 您所购买的产品可能不会含有以上所有部件。	部件名称	有害物质						铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)	印刷电路组件	○	○	○	○	○	○	外壳等小结构件	○	○	○	○	○	○	重要安全说明 在使用本产品之前, 请仔细阅读本说明书中的所有安全说明。 常规安全说明 - 小心使用本产品, 并将其存放在没有极端温度、高温高压和潮湿的清洁环境中。确保产品存放在不易弯曲或挤压的地方。 - 维修和更换只能由授权的售后服务人员进行。 - 请勿自行拆卸或更换产品的任何部件, 以防受伤或损坏设备。 - 对产品的任何未经授权的修改都将使保修无效。 - 仅在允许蓝牙传输的环境中使用本产品。 个人安全说明 - 如果产品有明显烧蚀或出现膨胀或温度过高异常, 请勿使用。 - 执行重要安全警告的高风险任务时, 请勿使用本产品。 - 为了保护听力, 请勿长时间高音量收听。 - 请将产品及其包装放在儿童和宠物接触不到的地方, 以防发生吞咽和窒息等事故。
耳机指示灯	状态																																																
白灯和蓝灯交替闪烁	两个耳机/开机																																																
蓝色常亮	单耳机: 未配对																																																
天灯	配对成功或充满电																																																
充电仓指示灯	状态																																																
蓝色常亮	耳机充电中																																																
白灯闪烁	充电仓充满电																																																
白灯常亮	充电仓充满电																																																
部件名称	有害物质																																																
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)																																											
印刷电路组件	○	○	○	○	○	○																																											
外壳等小结构件	○	○	○	○	○	○																																											

HTC
Wireless Earphones NE81

Product Specifications

Model: HTC NE81

Bluetooth
Range: ≈10 m
Version: 6.0

Speaker
Diameter: 8 mm
Impedance: 32 Ω

Earphone power
Input: 5 V=28 mA
Battery capacity: 28 mAh
Battery life: ≈ 4.5 hrs
Charging time: ≈ 1.5 hrs
Earphone recharges: 3 charges (when case is fully charged)

Charging case power
Input: 5 V=300 mA
Output: 5 V=56 mA
Battery capacity: 300 mAh
Charging time: ≈ 1.5 hrs
Earphone recharges: 3 charges (when case is fully charged)

Quick Start Guide
HTC NE81

What's in the box

Components

Take out and pair the earphones

Bluetooth earphones
If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and blue alternately, indicating that they are in pairing mode.
Note:
• If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful.
• If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.

Wired earbuds
If you're using the earphones for the first time, insert the Type-C earphone plug into the Type-C audio port at the bottom of your device.
You can use them directly—no Bluetooth connection required.

Switch to Bluetooth / Wired mode

Bluetooth earphones:

Wired earbuds:

Left/Right Identification: Both the earphone body and ear hooks are marked L / R. Please wear them according to the markings to ensure the best acoustic experience.

How to put on the earphones

Wired Earphone Basic Operations

Category	Function	Key Operation
Sound Card	Sound Card / Headphone Mode	Long press ②: 3s
	Studio, KTV, Original, Male to Female, Female to Male, Hall Effects	Single tap ②
	Mic Volume Up	Single tap ③
	Mic Volume Down	Single tap ①
Headphone	Applause Effect	Long press ③: 3s
	Music Play/Pause	Single tap ③
	Previous Track	Triple tap ②
	Next Track	Double tap ②
Headphone Volume Up	Single tap ③	
	Headphone Volume Down	Single tap ①

Power on and off

Power on
Taking the earphones out of the charging case will automatically turn them on.
To manually turn on each earphone, press and hold the touchpad for three seconds.

Power off
Placing the earphones in the charging case will automatically turn them off.
To manually turn off each earphone, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.

Connect to Bluetooth device

On your device, turn on Bluetooth and choose to connect to "HTC NE81".

Basic operations

Key functions

- Play/Pause: Tap either earphone once.
- Volume up: Tap the right earphone twice.
- Volume down: Tap the left earphone twice.
- Play previous track: Tap the left earphone three times.
- Play next track: Tap the right earphone three times.
- Answer/End call: Tap either earphone once.
- Reject call: Press and hold either earphone for two seconds.
- Activate voice assistant: Press and hold the left earphone for two seconds.

Note: When using a single earphone only, press and hold the active earphone for two seconds.

- Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)

Note: Mode switching is disabled when you're using a single earphone only.

- Switch ANC noise reduction mode: Tap either earphone four times to switch between modes. (There are three modes to switch: normal mode / ANC noise reduction mode/transparency mode)

Indicator LEDs

Earphone LED	Status
Blinking white and blue	Both earphones: Powered on Single earphone: Unpaired
Solid blue	Charging
Off	Paired or fully charged

Charging case LED

Status	Status
Solid blue	Earphones charging
Blinking white	Case charging
Solid white	Case fully charged

How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously.
Note: Resetting the earphones will clear the Bluetooth pairing history.

Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

General safety instructions

- Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.
- Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
- Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions

- Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
- Do not use the product when performing high-risk tasks that require your full attention.
- For your hearing protection, do not listen at high volume for long periods.
- Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions

The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.

- Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
- Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
- Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
- Keep the product dry and away from liquids or moisture.
- Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
- Do not use the product while charging.
- Only use the product for charging for longer than eight hours.
- Dispose of the product responsibly according to your local waste management guidelines.

FCC ID: 2BHR-NE81

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Customer Service Email: service@yhemi.net

US REP

Company Name: LOBOS IOWA INC
FRN: 0036413961
Contact Name: Harley Li
Address: 4623 Bitter Creek Dr Colorado Springs CO 80922 US
Phone: +1 8188180538
Email: info@lobos-iowa.com

Legal notice

Trademarks and permissions:
HTC and the HTC logo are trademarks of HTC Corporation and used under license by Shenzhen Brands World Technology Co., Ltd. Copyright © 2026 Shenzhen Brands World Technology Co., Ltd. All rights reserved.
THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.