

E5201 User Manual

Safety Warning

Thank you for using our Multifunction Socket!

Before using this unit please, read the manual.

This Multifunction Socket was for indoor use only.

Do not place the apparatus in direct sunlight or heat.

This apparatus should be placed on a stable surface.

Do not attempt to repair this product as the warranty will be void, please contact with the store or customer service.

Trying to remove panels or repairing the unit by yourself could result in an electric shock.

This item should be connected to an AC 100V-240V Power outlet.

Do not use chemicals on this product.

Cautions

1. When you open a face shell, please do not exert strongly, and try to stress in vicinity of the oval logo.
2. During plugging in and out the socket, please take it carefully, and keep the direction of force perpendicular to the surface socket as far as possible.
3. Don't use too much force when closing it, sometimes there will be one corner of shell upturn slightly. Only you must press gently, it will be OK.
4. In the process of using, you can replace it to continue using it if due to overload or other accident to occur to overloading the fuse and powering down.
5. When the metal surface is smudgy, do not use alcohol or other corrective solutions to clean it, please clean it with the soft cloth.

Specification


Input	100V-240V~, 50/60Hz, 10A, Max:2400W
Output	100V-240V~, 50/60Hz, 10A
USB output	5V DC, 2.1A Max total
Wireless charging output	5V, 5W

Frequently asked questions


Problem	Possible cause and correction maintenance
The socket don't work	1. May be the fuse is burnt out, please replace the fuse 2. Take the product out of the sleeve; 3. Twist off the fuse holder from the product bottom.(Right "FUSE") 4. Replace the fusing fuse and close the fuse holder. 5. And put the product into the sleeve, then it will recover normally. 6. Caution: the specification and the size of appearance of the replaced fuse must be same as the before. 7. When the product appear some problems of electricity and it could not power, please don't take part it by yourself.

Mounting Manual

1. Drill a hole in the sofa ~size as follows~




Sponge is not allowed to be folded into the hole in this side, fixing the leather with nail on the side of the sofa.



Sponge and leather are not allowed to be folded into the hole in this side.

Sponge is not allowed to be folded into the hole in this side, fixing the leather with nail on the side of the sofa.

Sponge and leather are not allowed to be folded into the hole in this side.



Warning: the product is not allowed to disassemble once being equipped on the furniture

RF exposure considerations

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.