

Lenovo Handheld Game Console G02 User Manual


Directory

Packaging contents	2
Product Introduction	3
Security information	4
Function Introduction	5
Game Import	6
Common Settings	6
Indicator Light and Charging Function	6
Product Specifications	7
Note on Product Visible Light	7

Packaging contents



Host Quantity×1




Instructions×1




USB×1

Product Introduction



Product Introduction



Functional Operations	Function Description
A Key	Enter / Confirm
B Key	Back
X Key	Random jump
Y Key	Quick Search
SELECT Key	Quick Menu
START Key	Enter the Settings Menu
Left Joystick / D-Pad	Control Cursor Movement
Power Key	Long press to enter the shutdown or reset interface, short press to turn off or wake up the screen, and press and hold for a sustained period for a forced shutdown
Reset button	Forced restart
RGB Key	Light Switching
Volume Key	Control the volume level
L1/R1	Long press to scroll and turn pages
L2/R2	In emulator: Long press to scroll and turn pages
TF Card Slot	Insert the memory card
headphone jack	Connect a 3.5 mm audio device
DC jack	Device power supply or charging
OTG jack	Connect third-party devices

Security Information

Before using this product, please read the following safety instructions and follow all regular safety precautions. Any operation that does not comply with this manual may result in damage to this product.

WARN

1. Do not place the device near heat sources or exposed fire sources, or other places that may generate high temperatures.
2. If the battery is not replaced properly, there is a risk of explosion.
3. Do not attempt to replace the internal rechargeable lithium-ion battery.
4. If the product experiences severe swelling, do not continue to use it.
5. Do not squeeze or place the product in a place where it is easy to fall off.
6. Do not attempt to disassemble the battery. Otherwise, it may cause battery explosion or liquid leakage inside the battery. Batteries not specified by the manufacturer or batteries that have been disassembled and modified are not covered by the warranty.

Pay attention to

1. Electromagnetic waves of specific frequencies may affect the normal use of products;
2. Before you start working with the product, please read the instruction manual and operate it once to master its use proficiently;
3. When the machine malfunctions, do not disassemble or repair it arbitrarily. Only authorized maintenance personnel can carry out repairs on the machine;
4. If not used for a long time, please charge the device to about 50% every three months before storing it to effectively extend the battery life. Please fully charge it before use.

Function Introduction

1. When the handheld game console is turned on, the following corresponding operation settings can be performed

Functional Operations	Function Description
A Key	Enter /confirmation
B Key	Back
X Key	Short press for save file management, long press to add or remove favorites.
Y Key	Quick Search
SELECT Key	Quick Menu
START Key	Enter the settings menu
Left Joystick / D-Pad	Control cursor movement
Power Key	Long press to enter the shutdown or reset interface, short press to turn off or wake up the screen, and press and hold continuously for forced shutdown.
RBG Key	Light Switching
+	Increase Volume
-	Decrease Volume
L1/R1	Long press to scroll and turn pages

Function Introduction

1. The handheld game console is currently in game mode, and you can perform the following corresponding operational settings

Functional Operations	Function Description
SELECT+START Key	Exit and return to the main menu
ABXY	Game controls Key
SELECT	Select / Coin
START	Confirm / Start
Power Key	Long press to enter the shutdown or reset interface, short press to turn off or wake up the screen, and press and hold for a sustained period for a forced shutdown
Left Joystick / D-Pad	Control Movement
SELECT+A	Pause
SELECT+B	Show/Hide FPS
SELECT+X	Enter the backend settings
SELECT+L1	Load Game
SELECT+R1	Save Game
SELECT+L2	slow motion
SELECT+R2	Fast Forward
+	Increase the volume
-	Decrease Volume

Function Introduction

1. The handheld game console is currently in an emulator state, allowing for the following corresponding operational settings

Functional Operations	Function Description
A Key	Short press to enter/confirm; long press to access individual game settings
B Key	Short press to archive management, long press to add or cancel favorite
X Key	Back
Y Key	Short press to access quick search; long press for random menu jump
SELECT Key	Quick Menu
START Key	Enter the settings menu
up Key	Menu move up
Down Key	Menu Move down
Left Key	Switch to the previous simulator
right Key	Switch to the next simulator
Power Key	Long press to enter the shutdown or reset interface, short press to turn off the screen or wake up, and keep pressing to force a shutdown
RGB Key	Light Switching
+	Increase Volume
-	Decrease Volume
L2	Long press to scroll up
R2	Long press to scroll down
Left Stick Up	Menu Up
Left Stick Down	Menu moved down
Left Stick Left	Switch to last simulator
Left Stick Right	Switch to next simulator

Game Import

Please download the game format supported by the handheld gameconsole, place it in the corresponding game folder, insert the memory card into the game console card slot, and you can enjoy the game in the game menu.

Common Settings

After pressing the START button on the main interface, you can make some game settings, such as adjusting brightness, adjusting sound, changing UI theme, etc. Unless absolutely necessary, do not arbitrarily change button settings or any other settings you do not understand.

Indicator Light and Charging Function

1. When the handheld game console is low on power: the red indicator light stays on.

When the handheld game console is fully charged: all lights turn off after the console is fully charged.

When the handheld game console is charging: the red indicator light stays on, and all lights turn off after the console is fully charged.

2. The recommended charging voltage is 5V and the current is 1.5A. Please use the factory-equipped charging cable for charging. Do not use high-power charging cables to avoid excessively high voltage that may cause charging failure.

Product Specifications

Product Name	Lenovo Handheld Game Console
Product Model	Lenovo G02
Product Dimensions	L149*W99*H34mm
Rated Input	5V $\approx$ 1.5A
Rated Capacity	4000 mAh
Product Weight	258g($\pm$ 50g)
Executive Standard	GB 4943.1-2022

Note: Lenovo Group only provides game console equipment. The game content involved in the game console is downloaded by consumers themselves. Any legal disputes arising from the game content have nothing to do with Lenovo Group.

Note on Product Visible Light

Light Source	Incoherent Light
Light Source Name	Visible Light Source
Wavelength (nm)	RGB atmosphere light and charging light wavelength: 460-626nm
Grade	() Exempt Class (✓) Low Risk Class () Medium Risk Class () High Risk Class
Executive Standard	Compliance with GB 44703 Photoradiation Safety Requirements
Note: This includes the light source information for the product shown in this manual. The specific details are subject to the actual configuration of the product	

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.