

WiFi Camera

Manual


Please read the Manual carefully before using the product and keep it properly.

80.00 mm

64.00 mm

Connection Instructions

Connect the power interface and the power socket with the power cord.




01

Installation guide

1 Choose a location

Please install the camera in a location where the field of view is not blocked, and make sure that the location of the camera has a good wifi signal.



02

Voice broadcast instructions

Device status	Voice broadcast
Normal start	Network connection is successful, please open the APP to add a device
Normal reset	The reset is complete, the device is about to restart
Abnormal reset	Reset failed, please reset after connecting to the Internet or delete the device on the APP
QR code network configuration	Identify broadcast ding-
Alarm broadcast	Alarm sound

Camera reset

- When the camera is powered on, press and hold the reset button for 3-5 seconds until you hear a voice prompt and a prompt sound of "reset is complete, the device will be restarted soon", that is, the reset is successful.

03

Device connection

1 Download the APP

Scan the QR code below to download and install the APP.



2 Register and log in to the APP

1 Please register an APP account and log in.


2 If you have already registered, please log in directly.

04

Connection method--Bluetooth

1 Find the device Bluetooth, and click "Connect."


2-1. Find the device Bluetooth, and click "Connect."



05

3 Select WiFi, enter the correct password, and click "Next."

4. Waiting for connection.




06

Connection method--Scan the QR code

1 Click "+" to add device.

2. Scan the QR code on the camera label.



07

3 Upon hearing a sound or seeing the indicator light flashing, check and click "Next."

4. Select WiFi, enter the correct password, and click "Next."



08


5 Align the QR code with the camera.

6. Click on the input box, customize the device name, and click "Get started."



09


Device sharing



Open permission of Device sharing, the person being shared can set the function of the device. If the permission is turned off, you can only watch the video, and cannot set the function.

10

Rotation control



Can slide up, down, left and right


Rotation control

Live screen zoom


11

PTZ and functions

PTZ




Function




12

AI function

Humanoid tracking



Humanoid framing



13

FAQ

5. How far should the camera be from the router?

A: After testing, the Wi-Fi connection distance can normally reach 150 meters in an open area. But the actual situation depends on the strength of the Wi-Fi and its surroundings (thick walls, electromagnetic devices, large metal objects can all cause interference to the Wi-Fi signal). If the camera connection is weak or unstable, place the camera as close to the router as possible.

6. What should I do if the equipment fails?

A: Long press the power button to restart the camera. If there is no response, you can open the USB silicone cover at the bottom of the camera, long press the reset button to reset, and then long press the power button to restart the camera.

7. Can't add a camera for the first time?

A: When adding a camera for the first time, make sure the camera is powered on and the working status light is Blue flashes slowly. Or hear "Please use the App for WiFi configuration" from the camera.

1. Make sure the WiFi account and password are correct.

2. The camera only supports 2.4GHz WiFi and does not support 5G frequency band. Please do not use 5G WiFi to configure the network.

3. When adding a camera, ensure that the network is smooth, and it is recommended to operate close to the router.

4. If the QR code network configuration is unsuccessful, try to use the AP network configuration (the mobile phone can be

14

5. How far should the camera be from the router?

A: After testing, the Wi-Fi connection distance can normally reach 150 meters in an open area. But the actual situation depends on the strength of the Wi-Fi and its surroundings (thick walls, electromagnetic devices, large metal objects can all cause interference to the Wi-Fi signal). If the camera connection is weak or unstable, place the camera as close to the router as possible.

6. What should I do if the equipment fails?

A: Long press the power button to restart the camera. If there is no response, you can open the USB silicone cover at the bottom of the camera, long press the reset button to reset, and then long press the power button to restart the camera.

7. Can't add a camera for the first time?

A: When adding a camera for the first time, make sure the camera is powered on and the working status light is Blue flashes slowly. Or hear "Please use the App for WiFi configuration" from the camera.

1. Make sure the WiFi account and password are correct.

2. The camera only supports 2.4GHz WiFi and does not support 5G frequency band. Please do not use 5G WiFi to configure the network.

3. When adding a camera, ensure that the network is smooth, and it is recommended to operate close to the router.

4. If the QR code network configuration is unsuccessful, try to use the AP network configuration (the mobile phone can be

15

Warranty Card

User name: _____

Address: _____

Telephone: _____

Fax: _____

Post code: _____

E-mail: _____

Product model (Model): _____

Product Number (S/N): _____

Production Date: _____

Purchase Date: _____

If you have other requirements, please fill in below: _____

Dealer: _____ Telephone: _____

Distribution unit: (seal)

QUALIFIED CERTIFICATE

QC: PASS

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and, (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to, which, the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.