

正面

说明书

按键及部件

对讲机各部分名称及功能介绍

名称	功能
顶部 PTT	长按 PTT 键切换。
侧键/PTT 键	待机状态下，按该键进入对讲机功能。
	在对讲机功能下，按该键可进行 PTT 对讲功能操作。
侧键 2/菜单键	待机状态下，按该键进入主菜单操作功能。
	在对讲机功能中，功能通侧键。
	在对讲机功能下，进入好友列表或者群组成员列表试，可选中列表。
	组成临时群组进行对讲。
侧键 3/返回键 开关机键	菜单操作时，返回上级菜单。
	长按开关机。
旋钮	菜单操作时旋钮选择条。
	待机状态下，旋钮调节音量大小。

安装 UIM 卡

.关机后。 .讲 UIM 卡有芯片的一面，沿卡槽方向插到底即可。

3.基本操作

3.1.开机和关机

A.开机 长按“开机键”2 秒钟的时间，直到显示屏出现开机动画。

B.关机 待机状态时，长按“关机键”直至显示屏出现关机画面。

2.开始使用

电池充电

.使用原装的充电器充电。

.在第一次使用前，请先充电将电池充满。

.将充电器的插头插入对讲机的数据/充电端口。

.将充电器插在电源插座上，开始充电。

.充电结束后，从电源插座上拔下充电器，然后将插头从对讲机中拔出。

.屏幕提示充电完成，此时电池已经充满 95％左右，请继续保持充电半个小时以上，这样能保证电池出于完全充满状态。

注意：

- 手机低电告警时候，其 LED 闪烁提醒需要充电，同时 UI 部分电池状态栏盛框闪动，在未插入充电器前，会周期性出现“滴滴”低电报警提醒用户充电。

- 当插入充电器时，红色指示灯闪烁，提醒正在充电中；充电完成时，接收灯常亮。
- 按开机键开机动画+开机铃声完成后，搜索网络+启动对讲机应用完成后，待机界面显示本机名称+当前群组名称。

C.切换群组

a.按“菜单键”进入菜单列表，进入“选择群组”菜单。

b.按“菜单键”进入该群组并查看群组成员列表。

c.按“返回键”返回，按“PTT 键”发送语音。

备注：当在播报语音未结束时，按下 PTT 建是无反应的，需要等待其结束后，再按下 PTT 键，才能开始对讲。

D.选呼功能

a.本机有 2 种选呼方式，群组选呼和好友选呼。

b.群组成员；使用此方法时，每个成员不能加入超过 64 个群组，并且该用户加入所有群组的成员总和不能超过 200 个，否则对讲机有可能无法正常使用。

E.发送模式

当你按下 PTT 键时，发射灯亮时表示表示进入发送模式，对方将可以听到你所说的话，当正在发送时，有高一级的用户发起对讲，则会退出发送模式，进入接收模式，此时你只能被动接收对方的语音，你所讲的话对方无法听到，如果你一直按着 PTT 键对讲，则对方发送结束时，会直接进入发送模式，当处于发送模式时，LCD 屏幕会显示“本机在讲话...”。

所有用户都会分配讲话权限，分别为高、中、低。

高优先级的用户可以抢断低优先级用户的讲话。

F.接收模式

当接收灯亮时，表示为接听对方讲话

以下情况会退出接收对讲模式：

当本机优先级比对方优先级高时，按下 PTT 键会进入发送模式。

当处于接收模式时，LCD 屏幕上会显示对方用户名称。

a. 以群组列表为例使用方法如下（好友成员使用方式相同，仅后台设置不同）

b. 按“菜单键”进入菜单.

c. 按“菜单键”进入群组列表。

d. 选择想要单独对讲的用户所在群组，按“菜单键”进入群组以查看该群组的成员列表。

e. 选择该群组内想要单独对讲的用户（只有选择在线用户才能选呼，离线用户无法选呼），按“菜单键”。

f. 按“PTT 键”以建立临时群组。

g. 对讲完成后，按“返回键”将退出并返回当前群组。

注:只有已上线的用户（即对方已开机并且成功登陆）才能进行选呼。

反面

instructions

Keys and components

Name and function introduction of each part of walkie talkie

Name function

Press and hold PTT key at the top to switch.

In the standby mode of side key / PTT key, press this key to enter the walkie talkie function.

Under the interphone function, press this key to operate the PTT interphone function.

In the standby mode of side key 2 / menu key, press this key to enter the main menu operation function.

In the interphone function, the function is connected with the side key.

Under the walkie talkie function, enter the friend list or group member list, and you can select the list.

Form a temporary group for intercom.

When the side key 3 / return key is on / off, it returns to the upper menu.

Long press on / off.

Knob selection bar during knob menu operation.

In standby mode, the knob adjusts the volume.

Install UIM card

. after shutdown The UIM card has one side of the chip, which can be inserted to the bottom along the direction of the card slot.

3. Basic operation

3.1. Startup and shutdown

A. After startup, press and hold the "startup key" for 2 seconds until the startup animation appears on the display screen.

B. In shutdown standby mode, long press the "shutdown key" until the shutdown screen appears on the display.

2. Start using

Battery charging

. charge with the original charger.

Please charge the battery before using it for the first time.

. insert the plug of the charger into the data / charging port of the walkie talkie.

. plug the charger into the power socket and start charging.

. after charging, unplug the charger from the power socket, and then unplug the plug from the walkie talkie.

. the screen prompts that the charging is complete. At this time, the battery has been fully charged by about 95%. Please keep charging for more than half an hour, so as to ensure that the battery is fully charged.

be careful:

one When the mobile phone has a low power alarm, its LED flashes to remind the user that it needs to be charged. At the same time, the box in the battery status bar of the UI flashes. Before the charger is inserted, a "didi" low power alarm will appear periodically to remind the user to charge.

two When the charger is inserted, the red indicator flashes to remind that it is charging; When charging is completed, the receiving light is always on.

three Press the start button to start the animation + start the ring tone, search the network + start the walkie talkie application, and the standby interface will display the name of the machine + the name of the current group.

C. Switch groups

a. Press the "menu key" to enter the menu list and enter the "select group" menu.

b. Press "menu key" to enter the group and view the group member list.

c. Press "return" to return, and press "PTT" to send voice.

Note: when the broadcast voice is not finished, pressing PTT is unresponsive. You need to wait until it is finished, and then press PTT key to start intercom.

D. Selective call function

a. This machine has two selective calling modes, group selective calling and friend selective calling.

b. Group members; When using this method, each member cannot join more than 64 groups, and the total number of members of all groups joined by the user cannot exceed 200, otherwise the walkie talkie may not work normally.

E. Sending mode

When you press the PTT key, when the transmitting light is on, it means that you enter the sending mode, and the other party will be able to hear what you say. When you are sending, if a higher-level user initiates intercom, you will exit the sending mode and enter the receiving mode. At this time, you can only passively receive the other party's voice, and the other party can't hear what you say. If you keep pressing the PTT key for intercom, When the other party finishes sending, it will directly enter the sending mode. When it is in the sending mode, the LCD screen will display "this machine is talking...".

All users will be assigned speech permissions, which are high, medium and low.

High priority users can steal the speech of low priority users.

F. Receiving mode

When the receiving light is on, it means to answer the other party's speech

The following conditions will exit the receiving intercom mode:

When the local priority is higher than the other priority, press the PTT key to enter the sending mode.

When in receiving mode, the opposite user name will be displayed on the LCD screen.

a. Taking the group list as an example, the usage method is as follows (the use method of friend members is the same, but the background settings are different)

b. Press the "menu key" to enter the menu

c. Press "menu key" to enter the group list.

d. Select the group of users who want to talk to each other separately, and press "menu key" to enter the group to view the member list of the group.

e. Select the users who want to talk to each other independently in the group (only online users can choose to call, and offline users cannot choose to call), and press the "menu key"

f. Press the PTT key to create a temporary group.

g. After the intercom is completed, press the "return key" to exit and return to the current group.

Note: only online users (i.e. the other party has started up and successfully logged in) can make selective calls.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Specific Absorption Rate (SAR) information:

This product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device type: G6S (FCC ID: 2BK6D-G6S) was also tested against these values. The highest SAR value for accessories worn on the body, face is 1.13 W/kg and 0.58 W/kg. The device tested typical body wear operations with the back of the product 5mm from the body. To meet FCC RF exposure requirements, use accessories that maintain a separation distance of 5mm between the user's body and the back of the product. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.