


411704说明书
材质：80g书纸，双色双面印刷不过膜
尺寸：170mmX131mm
需要折叠好送货



折叠方式
虚线为折痕

15W WIRELESS CHARGING PAD

with USB-C Charging Cable

INSTRUCTION MANUAL

A

Wireless Charging Surface

B

LED Indicator Light

C

Charger Port (Type-C)

D

USB-A to USB-C Cord (35in/90cm)

NEED HELP?

Have any questions or comments about your product? Need help with trouble-shooting, service, or repair?

CONTACT US:

<https://www.gamestop.com/contact>
Phone: 1 (800) 883-8895

WHAT'S INCLUDED

- 15W Wireless Charging Pad
- USB-A to USB-C Cord (35in/90cm)
- User Manual

SETTING UP THE HEADSET

Connect the wireless base to a power outlet using a 15W or higher rated power adapter. This is essential for optimal charging performance.

Plug the equipped USB cable into the wireless charging port on the base. The indicator light will illuminate to confirm a successful connection.

Place your mobile device centrally on the wireless base. Charging will begin automatically.

Note: Using a power adapter with a lower wattage than 15W may result in slower or inefficient charging.

SPECIFICATIONS

• Input Requirement:

12V/2A, 9V/2A, 5V/2A

• Output:

15W / 10 W / 7.5W / 5W
(15W power adapter and above required for optimal charging)

CHARGING INDICATOR STATUS

Flashing Red

Charging mobile device

Solid Yellow

Charge complete or idle

starwars.com

© & ™ Lucasfilm Ltd.

Geeknet, Inc.

625 Westport Pkwy, Grapevine, TX 76051

Phone: 1(800)883-8895

正面

15W WIRELESS CHARGING PAD

with USB-C Charging Cable

IMPORTANT

IMPORTANT SAFETY INSTRUCTIONS

This 15W wireless charging base is designed to charge compatible mobile devices wirelessly. Any other use may result in fire, electric shock, or injury.

- Use only a certified 15W or higher rated power adapter. Using an incompatible or lower wattage adapter can lead to overheating, damage to the charger, or inefficient charging.
- Do not use the wireless charging base if the power adapter or cord is damaged.
- Always plug the power adapter directly into a wall outlet.
- Do not place any metal objects (e.g., coins, keys, jewelry) or magnetic stripe cards on the wireless charging base during use. These can interfere with charging and potentially cause overheating or damage.
- If your device or the charging base becomes excessively hot during use, immediately disconnect the power adapter and allow them to cool down before resuming charging.
- Do not charge your device while it is covered by any material that could trap heat (e.g., phone case).
- Do not attempt to disassemble or repair the wireless charging base yourself. If it malfunctions, contact the manufacturer or a qualified technician for assistance.
- Keep the wireless charging base away from water or other liquids. Do not use it in humid environments like bathrooms or near sinks.
- Keep the wireless charging base out of reach of children and pets.
- Do not place the wireless charging base near heat sources or in direct sunlight.

FC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

"FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons."

Model:15W WIRELESS CHARGING PAD

SKU: 411704

Made in China

Manufactured for Geeknet, Inc.

反面