



正面:

01 Product List


Please confirm the accessories before installation and use.
(Batteries and screwdrivers are not included and need to be purchased separately)




Food Tank




Food Bowl




User Manual




Main Unit



Food Bowl Holder



Desiccant Pack




Adapter




Cleaning Brush

Note: To provide better products, we will periodically make improvements.
The product images may slightly differ from the actual product. Please refer to the actual product.


02 Product Overview



Panel Buttons
Indication Lights
Food Tank
TF Card Slot
Microphone
Adjustable Camera
Laser Pet Feeding
Main Unit



Bottom View of Main Unit
Food Bowl
Food Bowl Holder
Type-C Port
Backup Battery Compartment




Desiccant Box

03 Product Installation

3.1 Assemble the Main Unit

- Take out the food bowl, food bowl holder, and adapter inside the food tank before installation.
- Place the food bowl holder on a flat table or floor and then place the food bowl inside it.
- Pick up the main unit, align it with the food bowl holder, and place it vertically down.
- Pick up the food tank, align it with the main unit, and place it vertically down.



3.2 Install the Desiccant

- Hold the machine and lift the top cover upwards to remove it.
- Open the desiccant box, take out the desiccant packet, spread it evenly inside, and then close the desiccant box.



3.3 Install the Backup Battery


- Remove the power cover, insert three size C batteries into the battery compartment.
- Pay attention to the polarity during installation and finally close the power cover.



Note: Replace the batteries promptly when the power is low. Check and replace the batteries during holidays.

3.4 Connect the Power

Take out the power adapter and insert one end into the Type-C port at the bottom of the main unit.



04 Product Use

4.1 Adding Pet Food

- Open the top cover and add the appropriate amount of pet food.
- Then close the top cover.



4.2 Indicator Lights and Buttons Instructions


Indicator Lights Description:

- When recording, the red light will turn on. When the power is turned on, the red light will flash briefly.
- The blue light will be on during playback and food dispensing. It will flash quickly if the grain is stuck.
- Connecting the power will turn on a green light. When the battery is low, the yellow light will flash. When connecting to the network, the green light will flash rapidly. Once the connection is successful, the green light will remain on.

Buttons Description:

- Long press to start recording, release to end recording. Supports 15 seconds of recording, double press to delete the recording.
- Short press for manual feeding, long press for initialization settings.
- Long press for 3 seconds to reset the device.

When turning on the power, the red light flashes, then the green light stays on. After 20 seconds, an alarm sounds. In 10 seconds, there will be a notification waiting for Wi-Fi connection, then a power indicator light starts flashing slowly.



05 Smart Control


5.1 Download and Install the App: Download "AJCLOUD" from the app store

Scan the QR code to download and install the AJCLOUD App to use more functions.





5.2 Adding Device


METHOD 1: Configure Wi-Fi via Bluetooth as Optimal Recommendation (Some Models Do Not Support)




METHOD 2: Configure Wi-Fi via QR Code








METHOD 3: Configure Wi-Fi via Wi-Fi Hotspot



1. Enter the homepage of this app and tap "Add device".



2. Select the "Automatic feeder" in the device type.



3. Select "Wi-Fi" connection by Soft AP.




4. Confirm that the feeder is connected to power.



5. Confirm the working indicator light is flashing or hear the prompt tone.



6. Select "Go to Settings" to connect to the Wi-Fi hotspot named "AJ_XXX".




7. Connect your phone to the Wi-Fi network named "AJ_XXX".




8. Select a Wi-Fi and input the password. Only 2.4GHz Wi-Fi is supported.




9. Hold for the connection. Once you hear "Feeding Successful", you can start using it.



10. After successful pairing, rename the device or continue using the current name.




11. Ensure the Wi-Fi signal strong and then tap "OK".



12. Tap the video image to enter the specific operation.

5.3 Operation Interface Description



Operation Interface Display

- You can set a feeding schedule through this App, and the device will dispense food according to the set schedule with fixed times and amounts each day.
- You can check the dispensing and eating status in time through this App.
- You can view the live camera, interact with your pets in real-time video, share and playback videos.
- The camera with laser and infrared light allows you to locate your pet remotely through this App, bringing you and your pet more fun.

06 Cleaning and Maintenance


- Before using, please read this manual carefully. Once installed and in use, it means you have read and accepted the following safety instructions.
- The company will not be held responsible for any damage caused by abnormal or improper use.
- The final interpretation belongs to our company.

Q: Will data be lost after network or power disconnection?

A: The built-in battery allows continuous recording without loss. When working with batteries, it will continue to work for a period of time (dual power supply is recommended).

Q: Why can not the main unit be reset?

A: Because the main unit is equipped with precise electronic components and circuit boards. For easy cleanup, just wipe the outside of the main unit with a wet rag after powering off.



Desiccant
Press here
By pressing on the side active area to install or remove the desiccant box.
Rotor
Inside the Food Tank
Before assembling, align the rotor inside the food tank with the triangular indicator.

Specifications

Product Name	Smart Pet Feeder (with Camera)	Product Material	Plastic
Product Size	190x190x132 mm	Product Weight	Based on actual product weight
Input	DV-2A	Food Storage Capacity	4L
Rated Power	10W	Applicable Range	Cats and small dogs
Connection Method	Wi-Fi via Bluetooth / QR Code / Hotspot	Video Resolution	1920*1080
Power Supply Parameters	BY external power + 3x size C batteries	Feeding Method	Laser
Suitable Food	Recommended to use 5-15mm dry non-sticky pet food	Camera Rotation	Up and Down

Notice to Users

- Before using, please read this manual carefully. Once installed and in use, it means you have read and accepted the following safety instructions.
- The company will not be held responsible for any damage caused by abnormal or improper use.
- The final interpretation belongs to our company.

Q&A Troubleshooting

Q: Will data be lost after network or power disconnection?

A: The built-in battery allows continuous recording without loss. When working with batteries, it will continue to work for a period of time (dual power supply is recommended).

Q: Why can not the main unit be reset?

A: Because the main unit is equipped with precise electronic components and circuit boards. For easy cleanup, just wipe the outside of the main unit with a wet rag after powering off.

Safety Instructions


***Failure to comply with the following terms may result in improper operation or other unexpected issues.**

- Please strictly follow the manual for installation and use of the device.
- Do not forcibly disassemble the device.
- Do not scratch or abrade the camera with sharp objects.
- Use indoors only. Do not place it where it can be exposed to direct sunlight, as it may affect the device's functions. Keep it away from fire sources.
- The device is powered by low voltage, but if a pet bites on the power cord it can still potentially cause electric shocks. Please use it correctly according to the user manual.
- Use the original power adapter to avoid device damage and safety hazards.
- Keep the device flat. Do not overturn it as it may malfunction.
- Do not feed anything other than pet food through the feeder, as it may cause the device to malfunction and even safety issues for your pet.
- Do not immerse the device in water or use in wet.
- To prevent pets from tipping over with the product, please place the feeder out of their reach.
- Do not place this device at a high location to prevent it falling as it may cause damage or pose a safety risk to pets.
- Dry and put the food tank back after cleaning to avoid water damage.
- Do not use the device if there is water on the power cord or plug.
- Unplug the power cord before installing and disassembling.
- Remove the battery and unplug the power cord, then store the device after washing and drying if stop using it.
- Ensure children using under adult guidance.
- Only qualified personnel should repair the device to avoid any accidents.
- Use the same rating when an extension cord is needed.
- If not used for three months, please check the battery capacity (this product uses alkaline batteries only).

Please carefully follow the manual and the operations listed above.

User Manual

Smart Pet Feeder (with Camera)



Please read this manual carefully before using the product and keep it for future reference.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.