

Please confirm the accessories before installation and use.
(Batteries and screwdrivers are not included and need to be purchased separately)




Diagram illustrating the components of the main unit and desiccant box:


- Top Cover
- Food Tank
- Microphone
- Main Unit
- Food Bowl
- Food Bowl Holder
- Panel Buttons
- Indication Lights

Diagram illustrating the desiccant box:


- Desiccant Box
- Type-C Port
- Backup Battery Compartment

3.1 Assemble the Main Unit

- ① Before installation, please take out the food bowl, food bowl holder and adapter first.
- ② Place the food bowl holder on a flat table or floor and then place the food bowl inside it.
- ③ Pick up the main unit, align it with the food bowl holder, and place it vertically down.
- ④ Pick up the food tank, align it with the main unit, and place it vertically down.



② Open the desiccant box, take out the desiccant pack, spread it evenly inside, and then close the desiccant box.



4.1 Adding Pet Food

① Open the top cover and add the appropriate amount of pet food.



Indicator Lights Description:

Connecting the power will turn on a green light.
When the power is on, the yellow light will flash. When connecting to the network, the green light will flash again. Once connection is successful, the green light will remain on.

The blue light will be on during playing and flame dispensing. It will flame quietly if the pump is stuck.

When recording, the red light will turn on. When the power is turned on, the green light will flash briefly.


Before Dispensing

Long press for 3-5 seconds, the device will reset.

When turning on the power: the red light flashes, then the green light stays on. After 20 seconds, an alarm sounds. In 10 seconds, there will be a notification without the WDI connection, then the green indicator light starts flashing.

5.1 Download and Install the App:

Download "Tuya Smart" from the app store



- Enter the app's main interface and select to add a device.
- Select smart appliances, then choose the P4i Feeder (Wi-Fi).
- Enter Wi-Fi information.
- Choose a wireless network and enter the password.
(Supports 2.4GHz wireless networks)
- As required, verify that the indoor light is blinking, and then click to proceed to the next step.

Return to the main interface

10:58 44% 10:58

Smart Feeder

Next Feeding: 2020-10-20 10:00 (Feeding)

Feed Plan

Feed Record

1 2 3 4 E

Feed Number

Feed

Change name

Battery Status

Set

Feeder status

Set up a feeding plan


View feeding records

Manual feeding

Operation Interface Display

- You can set a feeding schedule through this App, and the device will dispense food according to the set schedule with fixed times and amounts each day.
- You can check the dispensing and eating status in time through this App.
- Real time grain shortage detection, and when the surplus grain is insufficient, push the grain shortage information through the App

- ① Open the top cover and take out the desiccant pack, then remove the food bowl and food bowl holder.
- ② Remove the food tank, separating it from the main unit.
- ③ Add the appropriate amount of detergent to clean the food tank, main unit, top cover, food bowl, and food bowl holder and rinse.
- ④ Dry and reassemble them.



Product Name	Smart Pet Feeder
Product Size	195x118x325 mm
Input	5V=2A
Rated Power	10W
Connection Method	Wi-Fi via Bluetooth/Hotspot
Power Supply Parameters	5V external power + 3x size C batteries
Suitable Food	Recommended to use 5-10mm dry non-sticky pet food
Product Material	ABS + Stainless steel
Product Weight	Based on actual product weight
Food Storage Capacity	6L
Applicable Range	Cats and small dogs

Before using, please read this manual carefully. Once installed and in use it means you have read and accepted the following safety instructions.

The company will not be held responsible for any damage caused by abnormal or improper use.

The final interpretation belongs to our company.

The company will not be held responsible for any damage caused by abnormal or improper use.

The final interpretation belongs to our company.

A: The built-in battery allows continuous recording without loss. When working with batteries, it will continue to work for a period of time (dual power supply is recommended).

Q: Why can not the main unit be rinsed?

A: Because the main unit is equipped with precise electronic components and circuit boards. For easy cleanup, just wipe the outside of the main unit with a wet rag after powering off.

***Failure to comply with the following terms may result in improper operation or other unexpected issues.**

- Please strictly follow the manual for installation and use of the device.
- Do not forcibly disassemble the device.
- Do not scratch or abrade the camera with sharp objects.
- Use indoors only. Do not place it where it can be exposed to direct sunlight, as it may affect the device's function. Keep it away from fire sources.
- The device is powered by low-voltage, but a bit of pets on the power cord it can still potentially cause electric leaks. Please use it correctly according to the user manual.
- Use the original power adapter to avoid device damage and safety hazards.
- Keep the device flat. Do not overheat it as it may malfunction.
- Do not feed anything other than pet food through the feeder, as it may cause the device to malfunction and even safety issues for your pet.
- Do not immerse the device in water or use in wet.
- To prevent pets from spilling over with the product, please place the feeder out of their reach.
- Do not place this device at a high location to prevent it falling as it may cause damage or pose a safety risk to pets.
- Dry and put the foot back after cleaning to use it again.
- Do not use the device if not in power on the power cord or plug.
- Unplug the power cord before installing and disassembling.
- Remove the battery and unplug the device, then store the device after washing and drying if stop using it.
- Ensure children under adult guidance.
- Only qualified personnel should repair the device to avoid any accidents.
- Use the same rating when an extension cord is needed.
- If not used for three months, please check the battery capacity (this product uses alkaline batteries only).
- Please carefully follow the manual and the operations listed above.

A line drawing of a baby potty. It has a rectangular body with a flat top lid. The lid has a small rectangular opening in the center with a handle. On the front of the body, there is a horizontal band with four small square buttons. Below this band is a circular opening where a bowl is attached. The bowl is shown detached and lying flat in front of the potty.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.