



qi2

5000mAh



MagCell **Qi2**

Qi2 Magnetic PowerBank

5000mAh

Model No. MC511Q2

取扱説明書
User Manual

ご使用の前に必ずこの説明書をお読みください
保管用に大切に保管してください




警告

本取扱説明書の安全上の指示に従って操作してください。
そうしないと、火災、感電、その他の傷害につながるおそれがあります。

1.製品仕様書

- 製品名: Qi2ワイヤレス充電モバイルバッテリー
- モデル名: MC511Q2
- バッテリー種類: リチウムポリマー電池
- 電池容量: 5000mAh 3.87V (19.35 Wh)
- 定格容量: 3300mAh 5V (16.5Wh)
- USB-C 入力: 5V = 3A, 9V = 2A
- USB-C PD 出力: 5V = 2.4A, 9V = 2.22A,
12V = 1.67A (20W Max.)
- ワイヤレス充電: 5W/7.5W/10W/15W (iOS/Android)
- サイズ: 8 x 69 x 106 mm
- 重量: 129g
- 保管温度: -10~40°C
- 動作環境温度: 5~35°C

2.製品構成



3.充電ケーブルを 使用してスマートフォン/ヘッドセットを充電



基本操作説明

- **電源オン / バッテリー残量表示:**
電源ボタンを押すと、デバイスが起動し、バッテリー残量が表示されます。
- **スリープモード:**
システムに負荷がなく、操作が行われない場合、ステータスインジケータが消灯し、デバイスはスリープモードに入ります。
- **電源オフ:**
電源ボタンを長押しすると、デバイスの電源がオフになります。


○ = 常にオン  = フラッシュ ● = オフ

電量	放電状態	充電状態
10%未満	 ● ● ●	 ● ● ●
10%~25%	○ ● ● ●	○  ● ●
25%~50%	○ ○ ● ●	○ ○  ●
50%~75%	○ ○ ○ ●	○ ○ ○ 
100%	○ ○ ○ ○	○ ○ ○ ○


4.スマートフォン/ヘッドセットのワイヤレス充電

■ スマートフォンをバッテリーの上に置くと(下図参照)

スマートフォンの
ワイヤレス充電:



※MagSafe機能搭載のiPhoneや、磁石吸着ケースを装着したAndroidスマートフォンは、磁石によって固定されます。




ヘッドセットのワイヤレス充電:

※MagSafe充電ケース付きAirPods
またはQi充電対応ワイヤレスイヤホン

低電流モード

※ USB-Cポートを使用してAirPodsまたはApple Watchを充電する場合は、低電流モードをオンにしてください。



電源とステータス
インジケータ



電源ボタン

■ 操作方法 :

低電流モードON : 電源ボタンを2回押す。


低電流モードOFF : 電源ボタンを押す。※2時間後に自動OFF。

■ 指示灯状態 :

低電流モードON時、4つの指示灯  が順番に点滅。
(ランニングライト効果)

5. 充電と放電の同時実行


機器へのワイヤレス充電と同時に、
モバイルバッテリー自体も充電できます。



※充電・放電時の発熱で温度が上がり、
高温になると充電効率や出力が低下するため、5℃～35℃の環境でご
使用ください。

6. モバイルバッテリーの充電

USB充電器と充電ケーブルを使用して、
本製品を充電してください



7. ⚠️ 注意事項

- 磁気ワイヤレス充電は、Magsafe非対応のスマホケースと互換性がありません。
- モバイルバッテリーの充電には5V=1A(5W)未満の電源を使用しないでください。
- 高温時は充電速度が低下し、出力も制限されます。これはすべての
- ワイヤレス充電器に共通の問題です。5～35℃の環境下での充電をおすすめします。
- 磁吸無線充電について
本製品はスマート自動ウェイクアップ磁気ワイヤレス充電に対応。非標準の磁気スマホケースを使うと、自動ウェイクアップ充電が認識されない場合があります。その際は、手動ボタン（1回押し）で充電を開始してください。最適な体験を得るために、公式標準の磁気スマホケースの使用を推奨します。
- 安全上のご注意
本製品はスマート安全制御システムを内蔵しています。非標準の保護ケースや磁気リングを使用した場合、システムは異常充電と判断し、安全のため充電を停止する場合があります。正常な使用のために、公
- 電子製品の廃棄について
 1. 電子製品を家庭ごみとして廃棄しないでください。
 2. 地域の法令に従って電子製品を廃棄してください。

8. ⚠ 重要な安全上の説明

誤った使い方をすると、バッテリーの故障、発熱、発火や爆発の原因となる可能性があります。

本製品の使用時は、基本的な安全上の注意を必ず守ってください。

- 涼しく乾燥した場所に保管する。
- 高温多湿な環境に置かないでください。
- メーカー推奨・販売していない電源や充電器を使用すると、傷害の危険性があります。
- 動作温度は 5~35℃の間である必要があります。
- 分解しないでください。修理が必要な場合は、適切な修理業者に相談してください。誤った組み立ては火災や傷害の原因となります。
- 長期間使用しない場合は、3ヶ月ごとに充放電してください。
- このモバイルバッテリーはおもちゃではありません。子供の手の届かない場所に保管してください。事故防止のため、子供に使わせたり遊ばせたりしないでください。
- 充電時に発熱するのは正常ですので、ご安心ください。
- 通常、バッテリー性能は数年で徐々に低下します。
- 高温環境や火の中に置かないでください。
- 有害な化学薬品や洗剤で清掃しないでください。
- 分解、刺し穿ち、衝撃を与えたり、誤用、落下、過度の力を加えると、短絡や破損の原因となります。
- 使用済み電池を処分する際は、異なる電気化学系統を分け、放電による発火や発煙を防ぐために端子をテープで絶縁してください。

FC (FCC) 警告声明

本機器の変更や改造を、コンプライアンス責任者の明確な承認なしに行うと、本機器の操作に対するユーザーの権限が無効となる可能性があります。本機器はFCC規則パート15に基づくクラスBデジタル機器の制限に適合していることが試験により確認されています。これらの制限は、住宅環境において有害な干渉から適切に保護することを目的としています。本機器は、無線周波数エネルギーを発生・使用・放射する可能性があり、取扱説明書に従って設置および使用されない場合、無線通信に有害な干渉を引き起こす恐れがあります。ただし、特定の設置において干渉が発生しないことは保証されません。もし本機器が無線またはテレビの受信に有害な干渉を引き起こした場合（電源のオン・オフによって確認できます）、次のいずれかまたは複数の対策を行うことを推奨します：

- 受信アンテナの向きを変えるか、設置場所を変える
- 機器と受信機との距離を広げる
- 受信機とは別の回路に接続されたコンセントに本機器を接続する
- 販売店または経験豊富な無線・テレビ技術者に相談する

本機器はFCC規則パート15に準拠しています。使用は以下の2つの条件に従う必要があります：

(1) 本機器が有害な干渉を引き起こさないこと (2) 本機器が受ける可能性のある干渉（望ましくない動作を引き起こす場合も含む）を受け入れること。

本装置は一般的なRF（無線周波）曝露要件に適合していると評価されており、制限なく携帯状態での使用が可能です。

9. 修理規定

⚠ 注意事項

- 製品の修理サービスは、Savewo公式サイトまたは認定販売店で購入した製品に対してのみ適用されます。
- 修理の際、Savewo Distribution Limitedまたは認定販売店が発行した正式な領収書を技術者に提示する必要があります。有効な書類が提示できない場合、修理費用を支払う必要があります。（詳細は利用規約を参照してください。）
- 紛争が発生した場合、Savewo Distribution Limitedの最終的な判断が優先されます。

利用規約

Savewo Distribution Limited（以下、"本社"と称す）は、発注書の日付から12ヶ月間の限定保証サービスを提供します。この期間を超えた場合、製品の保証サービスには修理費用がかかります。

1. 本社は製品の不適切な使用により生じた故障、損傷、停止、または他者や財産に直接または間接的に生じた損失や損害について、一切の責任を負いません。
2. 保証サービスを利用する際、お客様は製品を自身で顧客サービスセンターまたは指定場所に持ち込み、同じ場所で受け取る必要があります。
3. 通常の使用条件下で、本社は保証期間内に故障した製品に対して無償の保修サービスを提供します。（表面、筐体、消耗品、アクセサリ、消耗品を除く）
4. 保証範囲に含まれない以下の項目については、お客様が別途必要なサービス料金を支払う必要があります。
 - (a) 非承認の個人によって改造、変更、または修理が行われた製品。
 - (b) 不適切な使用、保守不足、異常な電力供給または電圧、事故、自然災害、昆虫や異物、液体の侵入、腐食、通常の使用による摩耗または外部要因により生じた損傷があった製品。
 - (c) 製品の使用説明書に記載されている方法に従わないことにより生じた製品の損傷。
5. 通常の使用条件下で、本社は保証期間内に故障した製品に対して無償の保修サービスを提供します。（表面、筐体、消耗品、アクセサリ、消耗品を除く）



本製品を正しく安全にお使いいただくために、この説明書を必ずお読みください。

説明書は大切に保管し、必要に応じてご確認ください。

※製品の改良により、実際の製品と説明書の内容が異なる場合がございます。実物を優先してください。

カスタマーサポート

Customers Service and After-Sales Support Hotline
+81 03-6202-7180

Betsutenjin Japan株式会社

〒103-0023

東京都中央区日本橋本町336ワカ末ビル7階

www.savewo.com

 Savewo

 savewohk

      **RoHS UN38.3**





qi2

5000mAh



MagCell Qi2

Qi2 Magnetic PowerBank

5000mAh

主型號：MC511Q2

使用說明書
User Manual

使用前請仔細閱讀本說明
請妥善保存，以備參考




警告

請按照說明書上的安全提示進行操作，
否則有可能導致起火、漏電或者其他傷害

1.產品規格

- 產品名稱: Qi2磁吸行動電源
- 型號: MC511Q2
- 電池種類: 鋰聚合物電池
- 電池容量: 5000mAh 3.87V (19.35 Wh)
- 額定容量: 3300mAh 5V (16.5Wh)
- USB-C 輸入: 5V = 3A, 9V = 2A
- USB-C 輸出: 5V = 2.4A, 9V = 2.22A, 12V = 1.67A (20W Max.)
- 無線輸出: 5W/7.5W/10W/15W (iOS/Android)
- 尺寸: 8 x 69 x 106 mm
- 重量: 129g
- 儲存溫度: -10~40°C
- 工作環境溫度: 5~35°C

2.產品結構



3.使用充電線為手機/耳機充電



基本操作說明

■ 開機/電量顯示：

點擊電源鍵開機，裝置將顯示目前電量狀態。

■ 休眠狀態：

當系統無負載且無操作時，電量指示燈熄滅，設備進入休眠狀態。

■ 關機長按電源鍵可關閉設備。


○ = 常亮 -○- = 閃爍 ● = 熄滅

電量	放電狀態	充電狀態
低於10%	-○- ● ● ●	-○- ● ● ●
10%~25%	○ ● ● ●	○ -○- ● ●
25%~50%	○ ○ ● ●	○ ○ -○- ●
50%~75%	○ ○ ○ ●	○ ○ ○ -○-
100%	○ ○ ○ ○	○ ○ ○ ○


4. 為手機/耳機無線充電

- 將您的設備放在行動電源上 (如下圖所示)

手機無線充電



※ 備有MagSafe功能的iPhone、配備磁吸式手機殼的Android手機會被磁吸裝置固定到位




耳機無線充電


※ 配備MagSafe充電盒的AirPods 或支援Qi充電技術的無線耳機

低電流模式

※ 使用USB-C插口為 AirPods 或 Apple Watch充電時，請開啟低電流模式



電量及狀態指示燈



電源鍵

■ 操作方法


開啟：雙擊電源鍵，進入低電流模式。 關閉：單擊電源鍵，關閉低電流模式。 ※低電流模式會在2小時後自動關閉。

■ 指示燈狀態

開啟低電流模式後，四個指示燈  循環閃爍。 ※走馬燈效果

5. 充電和放電同步


為設備無線充電的同時為行動電源充電



※ 充放電過程產生的熱量可能加速溫升，
建議於5°C至35°C環境中使用，以避免高溫限制充電效率與功率輸出。

6. 為行動電源充電

透過USB充電器連接充電線為本產品充電。



7. ⚠️ 注意事項

- 磁吸式無線充電不兼容非 Magsafe 手機殼。
- 請勿使用低於 5V = 1A (5W) 的輸入功率為行動電源充電。
- 高溫會降低充電速度，而且會限制功率，這是所有充電器及行動電源都會出現的問題。建議在溫度介乎 5~35°C 的環境中為設備充電。
- 手機保護殼和設備在無線充電器上的位置都會影響充電速度。離無線充電器中心越遠，充電速度越慢。
- 關於磁吸無線充電
本產品支援智慧型自動喚醒磁吸無線充電功能。若使用非標準磁吸手機保護殼，可能導致裝置無法辨識並自動喚醒充電功能。此時，需手動按鍵（按一次）開啟充電。建議購買或使用官方標準的磁吸手機保護殼，以獲得最佳體驗。
- 安全使用提示
本產品內建智慧安全控制系統。當偵測到使用非標準保護套或引磁環進行磁吸充電時，系統可能判定為異常充電狀態，並自動關閉充電功能以確保安全。建議您使用官方標準配件，避免影響正常使用。
- 廢棄電子產品處理
 1. 請勿將電子產品當成家庭廢棄物丟棄；
 2. 請依當地的法例規定處理廢棄的電子產品；

8. ⚠️重要安全說明

使用不當可能會導致電池故障、過熱，甚至起火或爆炸。

使用本產品時，務必要採取基本的預防措施

- 將產品存放在陰涼乾燥處。
- 請勿將產品存放及置於高溫、火源附近或潮濕的環境中。
- 工作溫度應介乎 5~35°C 之間。
- 請勿拆解、刺穿、撞擊本產品。使用不當、摔落或過度用力可能會導致產品短路或損壞。不正確的重新組裝可能會導致火災或人身傷害。
- 需要維修時，請聯絡售後支援。
- 如果產品長期不用，應每三個月充放電一次。
- 此行動電源不是玩具。請將其遠離兒童。不要讓兒童使用或玩耍，以免發生意外。
- 充電時，本產品可能會發熱。這是正常現象，無需擔心。
- 在正常情況下，電池性能會在幾年內逐漸下降。
- 請勿使用有害化學品或清潔劑清潔本產品。
- 若本產品發生鼓脹、變形、漏液或容量明顯下降，請立即停止使用並妥善處置。
- 使用非本產品製造商推薦或出售的電源或充電器可能會導致人身傷害的風險。
- 請根據當地的法規處置廢舊電池。請分開不同電化學體系的電池，並以膠貼絕緣正負極，以防放電引發火災或冒煙。

FC (FCC) 警告聲明

未經負責遵循規範方明確批准擅自更改或改裝設備，可能導致使用者喪失操作本設備的權限。本設備經測試符合 FCC 規則第 15 部分中針對 B 類數位設備所制定的限制。這些限制旨在為住宅安裝提供合理的有害干擾保護。本設備會產生、使用並可能輻射射頻能量，若未依說明安裝與使用，可能對無線電通訊造成有害干擾。儘管如此，在特定安裝環境中仍無法保證不會產生干擾。若本設備對無線電或電視接收造成有害干擾（可藉由開關設備來判斷），建議用戶採取以下一種或多種措施來排除干擾：

- 重新調整或移動接收天線。
- 增加產品與接收器之間的距離。
- 將產品連接至與接收器不同電路的插座。
- 諮詢經銷商或有經驗的無線電/電視技術人員以獲取幫助。

本裝置符合 FCC 第 15 部分的規定。操作需符合以下兩個條件：

- (1) 本裝置不得造成有害干擾，且(2) 本裝置必須能接受接收到的任何干擾，即使該干擾可能導致不希望的操作。

本設備已評估符合一般的射頻暴露需求，並可在可攜式使用條件下不受限制地使用。

9. 保修條款

注意事項

- 產品保修服務只適用於救世官網或官方授權經銷商出售之產品。
- 維修產品時客戶需出示由 Savewo Distribution Limited 或官方經銷商所發出之正式發票予技術員查閱，如客戶未能出示有效文件，則須繳付所需之維修費用。（詳情請參閱條款及細則。）
- 如有任何爭議，Savewo Distribution Limited 會保留最終決定權。

條款及細則

Savewo Distribution Limited(下稱“本公司”)將提供十二個月有限保修服務(由發票上的日期起計)。超過此期間者，產品保修服務將收取維修費用。

- 1.對於任何因產品不適當地使用而導致產品之故障、損壞、停頓，或引致任何人士和財產的直接或間接損失及破壞，本公司概不負責。
- 2.使用保修服務時，客戶須自行將產品送往客戶服務中心或指定地點，並於同一地點取回。
- 3.在正常使用情況下，本公司將在保養期內為故障之產品提供免費保修服務。（產品表面、機殼、損耗性零件、配件及消耗品除外。）
- 4.下列項目並不包括於保修範圍內，客戶須另付所需的服務費用。
 - (a) 曾被非授權人士進行改裝、更改或修理的產品。
 - (b) 曾經被不適當或疏忽使用、用後疏於保養、不正常供電或電壓不正常意外、天災或因昆蟲、外物、液體入侵、腐蝕、正常使用損耗或外來因素而造成損壞的產品。
 - (c) 未遵守使用說明書列明的方法使用，造成產品損傷。
- 5.所有資料如有任何更改，恕不另行通知。如有任何爭議，本公司保留最終決定權。



為保證您能充分了解並正確使用本產品，
請您仔細閱讀說明書。建議妥善保存，以便需要時查閱。

*產品更新有機會造成說明書內容有差異，請以實物為準。

台灣客戶服務及售後支援專線

台灣進口總代理：信星科技有限公司 電話：02-8992-5190

地址：新北市新莊區建國一路312號5樓

www.xincing.com

救世客戶服務中心

地址：香港荃灣德士古道266-270號 金泰線廠1樓

1/F, 266-270 Texaco Road, Tsuen Wan, N.T., Hong Kong

電話： +852 5503 2370

www.savewo.com



 Savewo



 savewohk



RoHS



外箱
化粧紙



トレイ
窓
フック





SAVEWO

www.savewo.com



Savewo



savewohk

qi2

5000mAh



MagCell Qi2

Qi2 Magnetic PowerBank

5000mAh

Model No. MC511Q2

User Manual

Please read this instruction completely and keep it properly



WARNING

Please follow the safety instructions contained in this user manual; otherwise, it may result in fire, leakage, or other damages.


FCC ID: 2BKF4-MC511Q2

Latest Update: 20250722


1. Product Specification

■ Product Name :	Magcell Qi2-Magnetic Wireless PowerBank
■ Model :	MC511Q2
■ Battery Type :	Lithium Polymer Battery
■ Battery Capacity :	5000mAh 3.87V (19.35 Wh)
■ Rated Capacity :	3300mAh 5V (16.5Wh)
■ USB-C Input :	5V = 3A , 9V = 2A
■ USB-C PD Output :	5V = 2.4A, 9V = 2.22A, 12V = 1.67A (20W Max.)
■ Wireless Charging :	5W/7.5W/10W/15W (iOS/Android)
■ Dimensions :	8 x 69 x 106 mm
■ Weight :	129g
■ Storage Temperature :	-10~40°C
■ Operating Temperature :	5~35°C

2. Product Structure



3. Use the Charging Cable to Charge Phone/Earbuds



Basic Operation Instructions

- **Power On / Battery Level Display:**
Press the power button to turn on the device; the current battery level will be displayed.
- **Sleep Mode:**
When the system is idle with no load or operation, the battery indicator light will turn off, and the device will enter sleep mode.
- **Long-press the power button** to shut down the device.


○ = Stays on -⦿- = Flash ● = Light Off

Battery Level	放電狀態	充電狀態
Below 10%	-⦿- ● ● ●	-⦿- ● ● ●
10%~25%	○ ● ● ●	○ -⦿- ● ●
25%~50%	○ ○ ● ●	○ ○ -⦿- ●
50%~75%	○ ○ ○ ●	○ ○ ○ -⦿-
100%	○ ○ ○ ○	○ ○ ○ ○


4 . Use the Charging Cable to Charge Phone/Earbuds

- Place your device on the power bank (as shown in the image).

Wireless Charging for Phone :



※ iPhone with MagSafe or Android smartphone with magnetic phone cases will be securely held in place magnetically.




Wireless Charging for Earbuds :

※ AirPods with MagSafe charging case or Wireless Earbuds with Qi Charging case

Low Current Mode

※ When charging AirPods or Apple Watch via the USB-C port, please enable low current mode.



Power and status indicator



PowerButton

■ Operation Method

Enable: Double-click the power button to enter low current mode.

Disable: Single-click the power button to exit low current mode.


※ Low current mode will automatically turn off after 2 hours.

■ Indicator Light Status

After enabling low current mode, all four indicator lights will flash in sequence. ※ Marquee effect

5 . Charge & Discharge Simultaneously


Wirelessly charge devices while being charged



※ Heat from charging/discharging may raise the temperature.
Use between 5°C–35°C to avoid high temperatures limiting charging efficiency and power output.

6 . Charging the Power Bank:

Connect the product to a USB charger using a charging cable to charge it.



7 . ⚠️ Product Notes

- Magnetic wireless charging is incompatible with non–MagSafe phone cases.
- Do not use input power below 5V = 1A (5W) to charge the power bank.
- High temperatures reduce charging speed and limit power, a common issue for all chargers and power banks. Charge devices in a 5~35°C environment.
- Phone cases and device placement on the wireless charger affect charging speed. The farther from the center, the slower the charge.
- About Magnetic Wireless Charging
This product supports smart auto–wake magnetic wireless charging. Non–standard magnetic phone cases may prevent auto–wake charging, requiring manual activation (press once). For the best experience, use official magnetic phone cases.
- Safety Tips
The built–in smart safety system may detect non–standard cases or magnetic rings as abnormal charging and disable charging for safety. Use official accessories to ensure proper function.
- Electronic Waste Disposal
Do not dispose of electronic products as household waste.
Follow local regulations for proper disposal.

8. ⚠ Important Safety Instructions

Improper use may result in battery malfunction, overheating, or even incidents such as fire or explosion.

Please follow the precautionary instructions provided below:

- The product should be stored in a cool, dry place.
- Do not expose the product to high temperatures or humid environments
- The use of a power source or charger not recommended or sold by the manufacturer of this product may result in a risk of personal injury.
- The operating temperature should be between 5~35°C .
- Do not disassemble the product. When repair is needed, please hand it over to qualified technicians. Improper reassemble may result in fire or personal injury.
- If not used long-term, charge and discharge the device once every three months.
- This product is not a toy. Please keep it out of reach of children and refrain from allowing them to play with or use it to prevent accidents.
- Some heat may be generated during the charging process, which is a normal occurrence.
- Under normal conditions, the performance of the battery will gradually degrade over the course of several years.
- Do not place this product in a high temperature environment or in a fire.
- Do not use harmful chemicals or detergents to clean this product.
- Do not disassemble, puncture, or crash this product. Improper use, bumps or excessive force may cause a short circuit or damage to the product.
- When disposing of used batteries, separate different electrochemical systems and insulate the terminals with tape to prevent discharge, fire, or smoke.

FC (FCC) Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

9 . Warranty Terms & Conditions


Important notes:

- The Warranty Service is only applicable to products purchased on the official website of Savewo or through authorised dealers.
- Customers are required to present the official purchase invoice issued by Savewo Distribution Limited or authorised dealers to the technician for verification when service is required. Otherwise, the service will be subject to charges.
(Please refer to Terms and Conditions for details).
- In case of any dispute, the decision of Savewo Distribution Limited shall be final.

Terms and Conditions

Savewo Distribution Limited (“The Company”) provides a warranty period of 12 months from the date of purchase. Repair and maintenance services beyond the warranty period will be subject to charges.

1. “The Company” shall not be liable for any direct or indirect loss or damage to any person or property, howsoever caused arising from improper use, or any stoppage, breakdown or failure of the product.
2. Customers are responsible to deliver the product to our service centres or designated stores, and to pick up the repaired product from the same location.
3. For any defect which in our judgment is caused under normal use, “The Company” will repair or replace the defective parts, free of charge within the warranty period (excluding any surface, cabinet, consumptive parts, accessories and consumable).
4. Warranty service does not cover the following items. Additional charges shall be levied if services are required.
 - (a) The product has been modified, tempered with, altered or repaired in any way by unauthorised persons.
 - (b) The product has been damaged through misuse, negligence, neglect of care after use, power interruption or abnormal voltage input, accident, natural calamities, or due to ingress of insects, foreign matters or liquid, corrosion, normal wear and tear or external factors.
 - (c) The product has been damaged due to use contrary to the instructions in this manual.
5. All terms stated are subject to change without notice. In case of any dispute, the decision of Savewo Distribution Limited shall be final.



In order to ensure that you can fully understand and use this product correctly, please read this manual carefully, and it is recommended to keep this manual properly for reference when needed.

*Differences may arise due to product updates. Please refer to the actual product for accurate information.

Customer Service and After-Sales Support Hotline
+852 5503 2370

SAVEWO LIMITED Customer Service Center
1/F, 266-270 Texaco Road, Tsuen Wan, N.T., Hong Kong

www.savewo.com

 Savewo

 savewohk

      **RoHS UN38.3**

