

User Manual

FCC COMPLIANCE STATEMENT/Information to User

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Please Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: To comply with the limits for an FCC Class B computing device, always use the signal cord and power cord supplied with this unit.

The Federal communications Commission warns that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.
- This radio should NOT be installed and operating simultaneously with other radio

Product Diagram



- | | | |
|----------------|----------------|--------------------|
| 1.OK Button | 2. M Button | 3. Power Button |
| 4. Lens | 5. LCD Screen | 6. Reset Button |
| 7. TYPE-C Port | 8. Card Slot | 9. Indicator Light |
| 10. Speaker | 11. Microphone | |

Operation Guide

Video/Photo Mode Switching Turn on the camera to enter the video interface, press the Power Button lightly to switch to photo mode, and press the OK Button lightly to take a photo.

Playback Mode Press the Power Button lightly in preview mode to switch to playback mode Select and open an image file or video file, press the Power Button or M Button to view, and press the OK Button to confirm.

App Download and Use

Before using the WiFi function, please install the “**Hiicam**” APP on your mobile phone first.

Android users: Search for “**Hiicam**” on Google Play; iOS users: Search for “**Hiicam**” on Apple Store to download and install. You can also scan the QR code below to download:



WIFI Connection Steps:

After turning on the camera, long press the OK Button to turn on WiFi.

Open your mobile phone, enter the Settings-WLAN menu, search for the camera's corresponding WIFI name, enter the password, and connect to use.