




正面



- | | | |
|---|-------------------------------|--|
|  | <p>Press 2s
Power on</p> |  <p>Blue LED blinks</p> |
|  | <p>KOVE
Kasita</p> |  <p>Blue LED on</p> |
|  | <p>Press 1x</p> | <p>Pause Play Mute</p> |
|  | <p>Press 2s
Power off</p> |  <p>LED off</p> |

-
1. If master speaker is connected with phone, after TWS disconnection, master speaker is still playing music, slave speaker is waiting for pairing.
2. If no speaker is connected with phone, after TWS disconnection, both are waiting for pairing.
3. After TWS disconnection, you need to press power buttons of both twice quickly again to active TWS. If you do not disconnect them, they will be paired automatically for next time.

The diagram is divided into two horizontal sections. The top section shows a Master speaker on the left, which has a power button and a Bluetooth symbol. An arrow labeled "Quick press 3x" points from the Master speaker to a smartphone on the right. The smartphone screen displays a Bluetooth connection icon and the text "KOVE Kasita". To the right of the smartphone, text reads: "Setting Master speaker: Connect speaker with your phone, quick press 3 times on power button." The bottom section shows two Slave speakers on the left, each with a power button and a Bluetooth symbol. An arrow labeled "Quick press 3x on rest of speakers" points from the Slave speakers to a smartphone on the right. The smartphone screen displays a Bluetooth connection icon and the text "KOVE Kasita". To the right of the smartphone, text reads: "Setting Slave speaker: They are not connected with phone, quick press 3 times on their power buttons."

1. Master speaker controls all speakers

2. Slave speaker can not control any speaker

3. Only one master speaker

-
- The diagram illustrates the sequence of button presses to enter recovery mode:
- Press and hold the power button.
 - Quick press 3x on the power button.
 - Press and hold the power button again.

- | | | | |
|--|--|----------|--|
| | | Press 1x | |
| | | Press 2s | |
| | | Press 1x | |
| | | Press 2s | |

 Short Press 2 buttons together	Prompt sound: Balanced Sound, Bass Sound, Pure Sound
 Long Press 2s on 2 buttons together	 Blue LED blinks For Bluetooth disconnection
 Long Press 5s on 2 buttons together	 Reset

Model	KOVE Kasita
Bluetooth Version	5.4
Battery	7.4V/4000mAhx2
Playing time	6-9H (50% Volume)
Charging time	4H
Charging input	DC5~8V≡2~3A Max 18W
Speaker unit	4Ω 25Wx2, 8Ω 10Wx2
Dimension	372 x 137 x 137mm
Weight	3575G±50

16

海國