

USERS MANUAL



A3 Pro

Before using the product, please read this manual.
Read carefully and keep for future reference.

Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction


Installation steps	01
English	02-03
Français	04-05
Deutsch	06-07
Italiano	08-09
Español	10-11
日本語	12-13
한국어	14-15
Русский	16-17
Indonesia	18-19
Polski	20-21
Nederlands	22-23
Dansk	24-25
Magyar	26-27
Português	28-29
Ελληνικά	30-31
ภาษาไทย	32-33

Installation steps

■ Fix by clips

1		Pull the steel clip a little wider and insert it directly into the left edge of the helmet
2		Lift the felt lining corresponding to the hook of the inner cavity speaker at the ear position of the helmet, and attach hook and loop fasteners
3		Attach the hook side of the loudspeaker to the corresponding loop side properly (Attach the short - wire loudspeaker to the left side)
4		Stick the butterfly - shaped sticky board in the appropriate position on the left side of the helmet, and place the microphone corresponding to the position of the mouth (arrange the wires and the inner lining properly)
5		Insert the plug into the headphone jack
6		Installation completed

English



2-person intercom with the same brand:
After turning on both headsets, long press button [4] to enter intercom mode. The green indicator light will flash quickly and there will be a voice prompt. After successful pairing, the prompt tone will be "Intercom connected", and the two can talk to each other.

2-person intercom with different brands:
After turning on the A3 Pro headset, long press button [4] to enter intercom mode. The green indicator light will flash quickly and there will be a voice prompt. At the same time, turn on another headset of another brand and enter the waiting state for pairing. The A3 Pro will automatically connect to the headset of the other brand. After the two headsets are successfully paired, the prompt tone will be "Intercom connected", and the two can talk to each other across brands.

Multi-person half-duplex intercom:
After turning on multiple A3 Pros and double-clicking button [4], there will be a "beep" prompt. At this time, all headsets enter "multi-person intercom mode". If one of them wants to talk to each other, double-click button [3] to start a multi-person intercom. Double-click button [3] again to exit the multi-person intercom. (Note: When one earbud is in an intercom call, the other earbuds can only listen. Wait until the first earbud exits the intercom call before the other earbuds can enter the intercom call.)
(Note: Before enabling "Multi-person Intercom Mode," please disconnect the earbuds from your phone's Bluetooth connection.)

Music Sharing:
After connecting earbuds A and B to your phone's Bluetooth connection, double-click the volume + button on each earbud to enable music sharing. Music will now play on earbud A and earbud B. Double-click the volume + button again to disable music sharing.

The charger's output power must be between the minimum power required by the wireless device [2.5W] and the maximum power [5W] to achieve maximum charging speed.



1		Previous song: Single tap
		Volume down: Long press
		Voice Assistant: Double tap to wake up the phone's built-in voice assistant
2		Next song: Single tap
		Volume up: Long press
		Auto answer: Double tap (when not connected)
		Turn music sharing on/off: Double tap (both earbuds simultaneously)
3		Power on/off: Long press for 2 seconds
		Play/Pause: Single tap
		Call back (last call contact): Double tap
		Change language: Double tap (when not connected to Bluetooth)
		FM on/off: Triple tap
4		Toggle lighting: Single tap
Intercom on/off: Long press		
5		Enter half-duplex multi-person intercom mode: Double tap
6		
		Type-C charging port
1 + 2		Press and hold the volume [-] and volume [+] buttons simultaneously for 5 seconds to reset to factory settings and shut down
		Toggle cycling sound effects: Short press the volume [-] and volume [+] buttons simultaneously