

# USERS MANUAL



X13 Pro

Before using the product, please read this manual. Read carefully and keep for future reference.


## Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

## 中文



|                |
|----------------|
| 产品型号:X13 Pro   |
| 工作时间:25-30小时   |
| 充电时间:1-2小时     |
| 待机时间:300小时     |
| 充电接口:Type-C接口  |
| 充电电压:USB 5V 1A |

### 同品牌2人对讲:

两台耳机开机后, 长按【4】号按键, 进入对讲模式, 绿色指示灯快闪, 并伴有语音提示。配对成功后, 提示音“对讲已连接”, 可以2人对讲通话。

### 跨品牌2人对讲:

X13 Pro耳机开机, 长按【4】号按键, 进入对讲模式。绿色指示灯快闪, 并伴有语音提示。同时另一台其他品牌耳机开机, 进入等待配对状态, X13 Pro会自动连接其他品牌耳机。两台耳机配对成功后, 提示音“对讲已连接”, 此时可以2人跨品牌对讲通话。

### 多人半双工对讲:

多台X13 Pro开机, 并双击【4】号按键, 伴有提示音, 此时所有耳机进入“多人对讲模式”。若其中一人想要对讲通话, 双击【3】号按键, 则可进行多人对讲通话。再次双击【3】号按键, 则退出多人对讲通话。(注:一台耳机对讲通话时, 其他耳机只能收听声音。等待此耳机退出对讲通话后, 其他耳机方可进入“对讲通话”)

(注意:启用“多人对讲模式”前, 请将耳机断开连接手机蓝牙)

### 音乐分享:

AB耳机分别连接AB手机蓝牙后, 两台耳机双击音量【+】按键, 开启音乐分享, 此时A耳机播放音乐, B耳机就能共享音乐;再次双击音量【+】按键, 关闭音乐分享

### FM模式:


开启耳机后, 请三击【3】以启动FM收音机模式;双击可进行自动搜台(等待1分钟)。单击【1】/【2】可切换频道;再次连续按三击【3】以关闭FM收音机模式。

充电器所输出的功率必须在无线设备所需的最低功率(2.5W)和最大功率(5W)之间, 以实现最大充电速度。



|       |  |                                                                                                             |
|-------|--|-------------------------------------------------------------------------------------------------------------|
| 1     |  | 上一曲: 单击<br>音量减: 长按<br>语音助手: 双击唤醒手机自带语音助手                                                                    |
| 2     |  | 下一曲: 单击<br>音量加: 长按<br>自动应答: (未连接状态下) 双击切换<br>开启/关闭音乐分享: (两台耳机同时) 双击                                         |
| 3     |  | 开机/关机: 长按2秒<br>播放/暂停: 单击<br>回拨 (上一通电话联系人): 双击<br>切换语言: (未连接蓝牙状态下) 双击<br>开启/关闭FM: 三击<br>切换接收/发射多人半双工对讲模式: 双击 |
| 4     |  | 切换灯光: 单击<br>开启/关闭对讲: 长按<br>进入半双工多人对讲模式: 双击                                                                  |
| 5     |  | Type-C耳机接口/Type-C充电接口                                                                                       |
| 1 + 2 |  | 同时长按音量【+】和音量【-】5秒恢复出厂设置, 并关机                                                                                |

## English



|                             |
|-----------------------------|
| Product Model: X13 Pro      |
| Working Time: 25-30 hours   |
| Charging Time: 1-2 hours    |
| Standby Time: 300 hours     |
| Charging Port: Type-C       |
| Charging Voltage: USB 5V 1A |

### Two-person walkie-talkie from the same brand:

After powering on both headsets, press and hold button [4] to enter intercom mode. The green indicator light will flash rapidly, accompanied by a voice prompt. Once pairing is successful, a message will sound saying "Intercom connected", allowing two people to talk to each other.

### Cross-brand 2-person intercom:

Power on the X13 Pro headset and press and hold button [4] to enter intercom mode. A green indicator light will flash rapidly, accompanied by a voice prompt. Simultaneously, power on another headset from a different brand and enter pairing mode. The X13 Pro will automatically connect to the other headset. Once both headsets are successfully paired, a "Intercom connected" message will sound, allowing two people to make cross-brand intercom calls.

### Multi-person half-duplex intercom:

Power on multiple X13 Pro headsets and double-click button [4]. A prompt tone will play, and all headsets will enter "Multi-person Intercom Mode." If one person wants to make a call, double-click button [3] to initiate a multi-person intercom call. Double-clicking button [3] again will exit the multi-person intercom call. (Note: When one headset is engaged in an intercom call, other headsets can only receive audio. Other headsets can only enter "Intercom Call Mode" after the first headset exits the intercom call.)

(Note: Before activating "Multi-person Intercom Mode", please disconnect the headsets from the phone's Bluetooth connection.)

### Music sharing:

After connecting earbuds A and B to phones A and B via Bluetooth respectively, double-click the volume up button on both earbuds to enable music sharing. At this point, earbud A can play music, and earbud B can share the music. Double-click the volume up button again to disable music sharing.

### FM mode:

After turning on the headphones, triple-click [3] to start the FM radio mode; double-click to perform automatic station search (wait 1 minute). Single-click [1]/[2] to switch channels; triple-click [3] again to turn off the FM radio mode.

The charger output power must be between the minimum power (2.5W) and the maximum power (5W) required by the wireless device to achieve the maximum charging speed.



|       |  |                                                                                                                                                                                                                                                                                                             |
|-------|--|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1     |  | Previous track: Click<br>Volume down: Long press<br>Voice assistant: Double-tap to wake up the phone's built-in voice assistant.                                                                                                                                                                            |
| 2     |  | Next song: Click<br>Volume up: Long press<br>Auto-answer: (Double-click to switch when not connected)<br>To turn music sharing on/off: (Double-click on both headphones simultaneously)                                                                                                                     |
| 3     |  | Power on/off: Press and hold for 2 seconds<br>Play/Pause: Click<br>Call back (previous call contact): Double-click<br>Switch language: (When Bluetooth is not connected) Double-click<br>Turn FM on/off: Triple hit<br>Switch between receive/transmit multi-person half-duplex intercom mode: Double-click |
| 4     |  | To switch lights: Click<br>Turn the intercom on/off: Long press<br>Enter half-duplex multi-person intercom mode: Double-click                                                                                                                                                                               |
| 5     |  | Type-C headphone jack/Type-C charging port                                                                                                                                                                                                                                                                  |
| 1 + 2 |  | Simultaneously press and hold the volume down button and the volume up button for 5 seconds to restore factory settings and power off.                                                                                                                                                                      |