

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver:
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator8 your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Caydo



P1 ART PROJECTOR USER MANUAL

Thank you for purchasing the **Caydo P1 Art Projector**. Please read this manual carefully before use and keep it for future reference.

Do not make any changes or settings that are not described in this manual. If physical injury, data loss, or damage occurs due to failure to follow the instructions, the warranty will not apply.

If you have any questions while using it, feel free to contact us at **support@caydo.com**.

We sincerely hope this projector brings more color to your life.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

The device supports 5GHz U-NII 1 frequency band, which is 5.150 to 5.250 GHz. It will be restricted for use in the indoor environment only.

EMMC	8GB
Light Source	LED
Throw Ratio	1.45:1
Unit Net Weight	800g
Installation Options	Front/Rear/Ceiling
Wi-Fi frequency bands	2.4GHz/5.0GHz
Photo Format	JPG/PNG/BMP/GIF/JPEG
Video Format	MKV/MP4/FLV/MOV/M2TS/AVI/ TS/MPG/3GP
Power Supply	Input:100~240V~50/60Hz 1.5A Max Max Output:19.0V= 2.5A
Ports	HDMI In x1/USB Port x1/Audio Out x1
Mounting Screw	1/4"

Table of Contents

1	Warnings and Safety Precautions	02
2	What's Included	05
3	Six Views of the Projector Structure	06
4	Remote Control Structure	07
5	Getting Started	08
6	Settings	14
7	Projector Connection and Input Source	18
8	Bluetooth Connection	21
9	Wi-Fi Connection	21
10	Screen Mirroring	22
11	Art Drawing	25
12	Local Send	32
13	Specifications	39

1 Warnings and Safety Precautions

1.1 Warnings

Do not use the product in any way other than as described herein to avoid personal injury or property damage.

To reduce the risk of fire and/or electric shock, **do not** expose the product to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this product.

Do not place this product on soft surfaces, such as tablecloths or carpets, as this could pose a fire hazard.

Avoid placing this product in areas prone to excessive dust and dirt or near appliances that generate strong magnetic fields.

To prevent overheating, **do not** block or obstruct the ventilation openings.

Never place this product in a confined space; always leave enough space around it for ventilation.

Do not use the product in environments where the temperature is too high or too low. **Never** expose the product to direct sunlight or wet conditions.

When this product runs for an extended period, the surface may become hot. If this occurs, shut it down immediately and unplug the adapter. Resume operation **only** after the product has cooled down.

Always handle this product with care and avoid touching the lens.

Do not look directly into the projector lens while it is operating, as it may burn your eyes.

Do not stare at the operating beam.

Do not allow children to handle the product without supervision.


Do not place heavy or sharp objects on this product.

13 Specifications

RAM	1GB
Display Technology	LCD
Resolution Native	1280x720P
Unit Dimension	6.61*5.08*3.46inches 168*129*88mm
Android Version	13
Bluetooth Version	5.0
USB Format	FAT, FAT32
Audio Format Supported	OGG/AAC/MO3/FLAC/WAV/ PCM
Focus	Auto/Electric Focus
Keystone Correction	Auto/Manual
Remote Control Batteries	AAA X2

3. Receiving Records on projector

Select the record list on the receive page, and press OK to view the file transfer record table. Select a single image file to perform related operations.



To avoid electric shock, **do not** disassemble the product.

Avoid extreme vibrations, as they may damage the internal components.

Please ensure you use **only** the adapter provided by the manufacturer.

Using an unauthorized adapter may be dangerous and violate the Terms of Use and product warranty.

Users should comply with the laws and regulations of the corresponding countries and regions where the equipment is used, abide by professional ethics, pay attention to safety obligations, and strictly prohibit the use of our products or equipment for any illegal purposes. Our company will not be responsible for any legal liability of violators under any circumstances.

Replacing an adapter with an incorrect type may defeat safeguards and create danger.

Disposing of the adapter/device in a fire, hot oven, or other significant heat sources, or mechanically crushing or cutting the adapter/device, may result in an explosion.

Leaving the adapter/device in an extremely hot environment may result in an explosion or leakage of flammable liquids or gases.

The adapter/device subjected to extremely low air pressure may also result in an explosion or leakage of flammable liquids or gases.

Within a 30cm range of the projector's air inlet and outlet, there should be no objects obstructing.

1.2 Hearing Safety

To prevent hearing damage, **do not** listen at high volume for extended periods. Set the volume to a safe level.

1.3 Adapter

Keep the adapter out of the reach of children.

The adapter is for indoor use only.

The adapter should be installed near the product and must be easily accessible.

Always use the adapter provided by the manufacturer to power the product.

It is recommended to operate the device in an environment with a temperature that ranges from 41°F-77°F / 5°C-25°C.

1.4 Remote Control

Keep the remote control out of the reach of children.

Remove the batteries when the remote control has not been used for an extended period.

Batteries contain chemical substances and should be disposed of properly.

1.5 Cleaning

Use a soft, lint-free cloth. Never use liquid, gaseous, or easily flammable cleansers for cleaning.

Do not use any liquid cleaning agents on the lens to avoid damaging the film coating.

Wipe surfaces gently, and be careful not to scratch them.

Use lens cleaning paper to clean the lens.

1.6 Repairs



Do not attempt to make any repairs to this product yourself.

Improper maintenance can result in injury or damage to the product.

Refer all servicing to qualified service personnel.

2. Projector receive the Pictures

During the image file receiving process, a transfer progress bar will be displayed, and after the transfer is completed, a prompt will be displayed indicating that it has been completed.




12.3. Projection end receive pictures


1. Pictures acceptance prompt

The projector receive the image file receiving request and clicks "Accept".

Note: After turning on the quick hold setting, the device will automatically accept it and there will be no related acceptance prompt.



2 What's Included



1

P1 Art Projector




2

Remote Control
(Batteries Not Included)



3


Adapter




4

User Manual


3 Six Views of the Projector Structure




Top




Right




Front



Left




Bottom



Back


4. Send Pictures

After adding the pictures, select the device to be transferred to start the file transfer.




5. Sending completed


After the file transfer is complete, a list of image files will be displayed.




2. Switch to the Send page
Switch the page from the Receive to the Send .



3. Add pictures and select device to send
Click **Media**, select a photo from your phone album or take a photo with the camera, confirm and add.
Note: You can add multiple image files in once.



4 Remote Control Structure




Note: Two additional AAA batteries are required.

5 Getting Started

5.1 Prepare the Remote


Slide to open the battery compartment, and insert new batteries matching the polarity (+/-) and close the battery compartment.



12.2. Sending image from mobile device

1. Launch the app

Click **LocalSend** to run and open the app.




12 Local Send

12.1. Function Entry

Select **LocalSend** on the homepage, and press the **OK** button on the remote control to open the LocalSend application software.

Note: LocalSend is a LAN file transfer tool that supports file transfer between two system devices (including Android, iOS, Windows, and Linux). When transferring files, the devices must be connected to the same WLAN network.



5.2 Install the Projector

Place the projector on a stable, flat surface in front of the projection surface. For the best results, the projection surface should be white and flat.

The distance between the projector and the projection surface determines the projection image size. For the best result, position the projector 0.96~3.21m away from the projection surface to get a screen size of 30-100inches.

Screen Size	Distance Between Projector Lens and Screen
30 inches	0.96m/3.16ft
40 inches	1.28m/4.21ft
50 inches	1.61m/5.26ft
60 inches	1.93m/6.32ft
70 inches	2.25m/7.37ft
80 inches	2.57m/8.42ft
90 inches	2.89m/9.48ft
100 inches	3.21m/10.53ft


5.3 Connecting to Power Source

Plug the adapter into the socket and connect the adapter power cord to the projector.



5.4 Power On/Off


After connecting the power cable to an outlet, press the **Power** button on the projector for 1-3 seconds or the remote once to turn on/off the projector.



11.8. Full Screen


Move the focus to the upper right corner of **Full screen** and confirm **OK** to enter full screen mode.

In full screen mode, move the focus to the upper right corner **Back** and confirm **OK** to exit full screen mode.



11.7. Invert

Enable the invert color function and the picture will display the opposite color effect.



5.5 Images Adjustment


1. Focus

[Auto Focus]

When the projector is powered on or slightly moved, it will automatically adjust the image quality.

[Electric Focus]


If you find the image is not sufficiently clear, you can also press and hold the **Focus** buttons on the remote to sharpen the image focus until the blurry image becomes clear.



2. Keystone Correction

[Auto Keystone Correction]


When the projector is powered on, you can navigate to **SETTINGS > Display > Focus Settings > Auto keystone Correction** to enable it, and then slightly move the projector, it will automatically correct the keystone distortion. You can also refer to the projector interface and use the left and right buttons on the remote control to fine-tune the aspect ratio of the image.



11.6. Processing Mode

Art Drawing provides 5 image display modes (**original**, **meshing**, **sketch**, **comic**, **black and white**). You can switch and confirm the final display effect according to the actual image.

Note: The following image effects are for reference only.



(Original)



(Meshing)



(Sketch)



(Comic)



(Black-and-white)