

Operating Instructions


To use massager independently:

1. This item comes with a travel lock feature. To turn product on, press and hold the power button on the base of massager for 3 seconds; flashing LED lights will indicate the product is on.
2. On the top of the product, press front button to turn on vibrations for the front motor. Press the front button repeatedly until the desired function is reached.
3. To turn off vibrations for the front motor at any time, press and hold the front button for 3 seconds. To resume vibrations on the last function used, single press the front button again.
4. To turn on gyrations in the shaft, press the middle button. Press the middle button repeatedly until the desired function is reached.
5. To turn off gyrations in the shaft at any time, press and hold the middle button for 3 seconds. To resume gyrations on the last function used, single press the middle button again.
6. Press the back button to turn on vibrations for the back motor. Press the back button repeatedly until the desired function is reached.
7. To turn off vibrations for the back motor at any time, press and hold the back button for 3 seconds. To resume vibrations on the last function used, single press the back button again.
8. To turn product off, repeat step 1. LEDs will turn off.

To use with a remote:

1. This item comes with a travel lock feature. To turn on and activate product, press and hold the power button on the base of massager for 3 seconds; flashing LED lights will indicate the product is activated.
2. To turn on gyration in the shaft, press the X button on the remote. Press the X button repeatedly until the desired function is reached.
3. To turn off gyration in the shaft at any time, press and hold the X button for 3 seconds. To resume gyration on the last function, single press the X button again.
4. Press the O button on the remote to turn on both rumbling motors in the base. Press the O button repeatedly until the desired function is reached.
5. To turn off vibrations for the rumbling motors at any time, press and hold the O button for 3 seconds. To resume vibrations on the last function, single press the O button again.
6. To turn off and deactivate product, repeat step 1. LEDs will turn off.

The massager must be activated to pair with the remote. Flashing LED lights will indicate the massager is activated. Ensure the massager is deactivated after each use to preserve battery life. Massager will automatically deactivate after 30 minutes of inactivity. Product has a memory chip feature and will resume on the last function used.



Remote control information:

Product name: Triple Rider Remote Control Gyrating Rumbler

Product model: SE-4300-75-3

Frequency:433.92MHz **Product temperature range:** 0°C-45°C

Battery warning:

Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;

Referring to Article 10.2 of the Directive, this equipment is so constructed that it can be operated in all Member States, without infringing applicable requirements on the use of radio spectrum.

IC Statement:

The device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1.L'appareil ne doit pas produire de brouillage;
- 2.L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an

uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.

- RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.