

Table of Contents	
• What's in the box	01
• Product Specifications	02
• Product Overview	03
• Wear and Adjust	04
• Power On/Off	05
• Pairing	06
• Volume and Power Button Controls	07
• Mode Switch Button Controls	08
• Charging	09
• Reset	10
• Wired playback	11
• Warranty	12
• Safety	13

User Manual for Airwave Max 6 0

- Headphone weight: 303g
- Speaker driver size: 40 x 12 mm
- Supported profiles: A2DP/AVRCP/HFP/HSP/BLE/SPP
- Bluetooth version: 6.0
- Charging time: 120 minutes
- Working voltage: 5V
- Standby time: Up to 300 hours
- Playtime without ANC: Up to 120 hours at 50% volume
- Playtime with ANC: Up to 90 hours at 50% volume
- Bluetooth range: 10m

User Manual for Airwave Max 6 02

A line drawing of a pair of over-ear headphones. Numbered callouts point to the following parts: 1. Headband, 2. Ear cup, 3. Ear pad, 4. Headband adjustment lever, 5. Headband adjustment lever, 6. Headband adjustment lever.

User Manual for Airwave Max 6 0


User Manual for Airwave Max 6 0

A pair of over-ear headphones with a black headband and large, dark ear cups. The right ear cup features a control panel with several buttons and a small display screen. A line points from the text 'Control panel' to this panel.

Power Off: Press and hold the Power button for 5 seconds till the white LED turns off.

User Manual for Airwave Max 6 05

Note: Your Noise Airwave Max 6 will automatically connect to the last paired device as soon as it is powered on.



	Press Once Press and hold 2 sec Press and hold for 5 sec	Play/Pause/Answer/End call Power On/Reject call Power Off
	Press Once Press & hold for 2 sec	Volume up Next Track
	Press Once Press & hold for 2 sec	Volume down Previous Track

FCC RF Exposure Warning Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

User Manual for Airwave Max 6 0


Double Press: Switch between Spatial Audio/Music Mode.

Press & Hold for 2 sec: Switch between Gaming Mode/Normal mode


Manual for Airwave Max 6

User Manual for Airwave Max 6 0

LED Indication:



Once the device is powered on, press and hold the + and- button simultaneously for 5 seconds. A voice prompt will indicate that the headphones have been reset, and they will automatically come into pairing mode.



A pair of over-ear headphones with a black cable. The headphones have a black headband and large, circular ear cups. The cable is black and has a 3.5mm audio jack at one end and a USB-C connector at the other.

Note : Some phones are limited by the system version, and you may not be able to use the headphones button and the microphone functions in wired mode.

User Manual for Airwave Max 6 1

The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.

Things that are not covered in the warrant are listed below:

Unauthorised tampering, modifications or repairs of the product.

Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not by the product manual or documentation or any other instruction provided along with the Noise product.



For any assistance,
please reach out to us at
support.gonoise.in

User Manual for Airwave Max 6 12

Follow these tips to get the best out of your new Noise Airwave Max 6

Follow these tips to get the best out of your new Noise Airwave Max 6

- Do not expose the headphones to liquids, moisture, or humidity as they have electronics and batteries inside.
 - Do not use any abrasive cleaning solvents to clean your new headphones. Wipe them down with a slightly damp cloth if and when necessary.
 - Do not throw the headphones in a fire to dispose them. The internal battery may explode.
 - Do not try to disassemble your headphones. There are no user-serviceable parts inside it.
 - Avoid dropping the headphones, and keep them away from sharp objects such as keys or in pockets.
 - Only charge your headphones for 3-4 hours, particularly such as phones and laptops or PC chargers.
 - Avoid listening to music at a high volume or you may permanent damage your hearing.
 - Pay attention to your surroundings and never wear any headphones while riding, driving, or walking in the street.

User Manual for Airwave Max 6 13

成品尺寸：125x125mm
展开尺寸：500x250mm
材质：128g双铜纸
正反四色印刷 过哑膜
风琴折再对折 RoHS

尺 寸 公 差			要求		品名	耳机 B427 Noise 折页说明书 YN		比例	1:1	日 期 DATE	2025.12.08
位 数	尺 寸	角 度									
X / X . X	±2mm	±0.5°			料号	40611000018127	设 计 DESIGNED	邹小露	审 核 CHECKED		
X . XX	±1mm	±0.5°									
					版 本 FORMAT	A	制 图 DRAWN		批 准 APPROVED		
					深圳奥尼电子股份有限公司 SHENZHEN AONI ELECTRONIC CO., LTD						
记 事			变更NO.	年/月/日							