252 MM

84 MM

84 MM

252 MM

84 MM

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device is in compliance with Specific Absorption Rate(SAR) for general population.
uncontrolled exposure limits 1.6W/kg specified in FCC 47 CFR part2(2.1093).
Device types have also been tested against this SAR limit. The evaluation distance for product specific head and body is 0mm. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

FCC ID:2BKRSMASTER

We are grateful.

We believe that there's noise within each and every one of us. A burning flame that's constantly pushing us to do everything possible to follow our passions.

Our goal has always been to give you wonderful products equipped with the latest technology that bring out the best in you. We hope we can be an able companion in your journey towards making all your dreams come to life.

Thank you for choosing our product, and a very warm welcome to the Noise family.

Register your warranty.

Your Noise product is covered under a warranty against manufacturing defects for one year after purchase.

Scan the QR code with your smartphone camera or pay us a quick visit at **bit.ly/noisewarranty** to register your product.

NOISE

POWER ON & OFF

The earbuds will automatically turn on, on opening the charging case.
The earbuds will automatically turn off once placed inside the charging case with the lid closed.

PAIRING

Open the charging case, Long press the charging case button for 3 seconds
Select 'Add Device' and select Noise Air Buds Pro 6 from the list of devices.
Your Noise Air Buds Pro 6 are now paired with your device and ready to use.

Note: Your Noise Air Buds Pro 6 will automatically connect to the last paired device as soon as you take them out of the charging case.

RESET

Make sure your earbuds are fully charged.
On your paired devices, delete/remove Noise Air Buds Pro 6 from the list of paired devices in the Bluetooth menu
Insert both earbuds into the charging case and long press the charging case button for 15 seconds
The White LED on the charging case will start blinking, to indicate that the earbuds have been reset.

CONTENTS

1 PAIR OF NOISE AIR BUDS PRO 6

1 CHARGING CASE

LARGE, MEDIUM AND SMALL EAR TIPS

1 CHARGING CABLE
1 USER MANUAL
1 WARRANTY CARD

CONTROLS

Single tap right	Volume up
Single tap left	Volume down
Double tap left	Play/Pause/Answer/End call
Double tap right	Play/Pause/Answer/End call
Triple tap right	Next song
Triple tap left	Previous song
Touch and hold either earbud	Reject Call
Tap 4 times left	Voice Assistant
Tap 4 times right	SpatialAudio
Touch and hold left	Mode switching (Transparency/Normal/ANC)

NOISE USER MANUAL

For the detailed user manual, scan the QR code and search for " Masterbuds user manual"

USER MANUAL

NOISE

Noise Masterbuds

Please refer to this User Manual before using the product.