


USER MANUAL

K8 Karaoke Machine


Portable Wireless Microphone&Speaker



·Product Function Introduction



1	Type-C Charging Port
2	Power ON/OFF
3	TF Card Port
4	USB Port
5	Audio Port



6	Short Press: Turn Down the Volume	Long Press:Previous Song
7	Short Press: Turn Up the Volume	Long Press: Next Song
8	Short Press:Switch Light Mode	Long Press:Light ON/OFF
9	Short Press:Switch BT/ TF Card Mode	
10	Short Press: Play/Pause	

·Accessories List

Speaker Wireless Microphone Type-C charging cable User Manual

·Precautions for using karaoke speaker

·Switch Speaker

Pull the ON/OFF button to the right in the off state, the product will start automatically. When no TF card is inserted, it will enter the Bluetooth mode by default, and the voice prompt will be "Bluetooth mode". Pull the ON/OFF button to the left to shut down.

·Bluetooth Connection

Open the Bluetooth settings of the mobile phone and search for the device name "K8", click it and connect. When connect successfully, there will be a prompt sound and the blue status light will be on.

·Mobile Phone Play

When connect successfully, turn on the mobile music player, download and play your favorite songs or accompaniments. You can also adjust the volume on your phone to a suitable volume.

·Tf Card Play

Insert the TF card into the device, the machine will automatically play the music in the TF card.

·Sound Adjustment

The volume can be adjusted through the buttons on the control panel of the device.

·Charging

Connect the charger with the standard Type-C charging cable to charge, the red light is always on when charging, and off when fully charged.

·Bluetooth Connection Method

1. Pull the ON/OFF button to the right, the voice prompt "Bluetooth mode" and indicator light will flash blue quickly. The blue light is always on when connect successfully.
2. Turn on the bluetooth of the mobile phone and scan, search for the device name "K8" and click it to connect. After connecting, you will hear a beep from the device for a successful connection.

Note: ① After the device is connected to the mobile phone once, the Bluetooth has a memory function, and it will automatically connect after turning on the device. If you need to disconnect, you can disconnect the Bluetooth through the mobile phone settings.
② If you only listen to music, you can turn the volume of the microphone to the minimum.

·Speaker Technical Parameters

- Bluetooth version: version 5.0
- Speaker diameter: 57mm
- Speaker power: 6W
- Working voltage: 3.7V
- Frequency range: 20Hz-20kHz
- Reverb: echo sound effect reverb
- Charging time: 2.5 hours
- Battery specification: 2000mAh built-in battery
- Power adapter: DC5V≤1A (common with mobile phone charger)
- Product name: Karaoke Machine
- Model: K8
- FCC ID: 2BKSF-K8
- Manufacturer: Dongguan MeiYin keji Co.,LTD.
- Address: Room 1004, No.3, Lane 6, Minchang Road, Nanzha, Humen Town, Dongguan City, Guangdong Province

·Easy Troubleshooting

Symptoms	Cause of Issue	Method of Exclusion
The power light is off or the machine shuts down automatically	①The battery power is too low; ②The charging cable is not plugged in correctly	①Charging the device. ②Check connector or charging cable
Music playback via Bluetooth is distorted	①The volume is too high; ②The battery power is too low	①Turn down the phone media volume; ②Charge the battery
There is noise in singing or recording	①Environmental noise; ②Mobile phone signal interference; ③Karaoke software setting problems	①Use it in a quiet place ②Increase the distance between the mobile phone; ③Turn the vocal volume to the minimum.
Bluetooth cannot connect	①Bluetooth distance too far; ②There are obstades; ③Bluetooth already connected to another mobile phone	①Move closer to the mobile phone to avoid obstacles; ②Disconnect the another connected mobile phone
Accompaniment staccato during Bluetooth playback	①The Bluetooth distance is too far; ②There is an obstacle between the mobile phone and the microphone	①Move closer to the phone; ②Avoid obstacles
Bluetooth accompaniment is small or silent	①The volume of the mobile phone is low; ②The sound of the original music file is low	①Turn on the mobile phone media, download a loud music accompaniment; ②Adjust the volume to a suitable position

FCC Statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.