

USER MANUAL

Karaoke Machine



The image shows a black, rectangular portable karaoke machine with a red carrying handle on top. The front of the machine features a large circular speaker grille with a colorful, rainbow-like LED light ring around it. To the right of the machine are two black wireless microphones with silver mesh heads and red power buttons. The entire setup is presented against a white background with decorative musical notes and a treble clef in the bottom corners.

Karaoke Machine
with 2 Wireless Microphones

· Welcome

Thank you very much for purchasing our products, your support and suggestions are the driving force for our improvement. Please feel free to contact us if you have any questions. We are committed to providing you with good service.

· Products Feature

K8-M Multi-functional karaoke machine with medium-sized has a fashionable locking. Including two handheld wireless mics and a 6.5-inch HD speaker, which can amplify distance reaches 49ft/15m. The powerful TWS function allows you to pair two K8-M systems for stereo effect. There are independent control buttons for microphone volume, reverb, colorful RGB lights on / off, etc. Ideal for family friends party, outdoor activities, musical performance, teaching, etc.

· Packing List

Karaoke Speaker	Wireless Mics
Type-C charging cable	Shoulder Strap

• Button Functions

The diagram shows the iRig MP3 interface with the following numbered callouts:

- 1: Power/Music Mode button
- 2: LED indicator
- 3: M1 Mode button
- 4: Bluetooth Mode button
- 5: Previous Song button
- 6: Play/Pause Button
- 7: Next Song button
- 8: Mic Volume Knob
- 9: Echo Knob
- 10: Accompaniment/Audio Port
- 11: TF Card Slot
- 12: USB Port
- 13: Mic Instrument Port
- 14: DC 5V Charging Port

1. Power/Music Mode: Short press the button to turn on/off microphone pre-amp. Long press the button to turn on/off music only.

2. LED: Short press the LED button to switch to a light mode. The LED lights of karaoke machine will flash with the rhythm.

3. M1 Mode: Short press to choose Bluetooth-M1 mode.

4. Bluetooth Mode: Search the Bluetooth named "iRig MP3" on your phone, click to be paired and **T** to automatically pair next time.

5. Previous Song: Long press the button to play previous song. Long hold the button for fast reverse.

6. Play/Pause Button: Short: Press the button to play/pause music. In Bluetooth mode, long hold the button to disconnect. Two connection. Please use this button on the standard Karaoke Machine. Short double-click to turn on the TF2 function. Long press to turn off the TF2 function.

7. Next Song: Press the button to play the next song. Long hold for fast forward.

8. Mic Volume Knob: Rotate the knob to control mic volume.

9. Echo Knob: Rotate the knob to adjust echo effect.

10. Accompaniment/Audio Port: Input accompaniment music and AUX.

11. TF Card Slot: Insert TF card to play MP3 files in it.

12. USB Port: Use USB flash drive to play MP3 files in it.

13. Mic Instrument Port: Support wired microphone and instrument audio input.

14. DC 5V Charging Port: Use the included USB charging cable and 5V charger (not include) to charge the karaoke machine.

Power/Volume Knob: Turn the knob clockwise to turn on device, keep turning to increase volume. Turn the knob anticlockwise to decrease volume, keep turning to turn off device.

· LED Lighting

LED Short Press RED WHITE RED YELLOW BLUE GREEN WHITE

· Microphone (not include/batteries)

1 2 AA VY

· Cautions

1. Please note each wireless microphone needs 2AA (not included).
2. When receiving the product, please use the included USB charging cable and a V-charger (not included) to charge the karaoke machine.
3. Since the machine is built-in high capacity, please keep the product away from high temperature environments and avoid exposure to sunlight for a long time.
4. To avoid strident sound, please do not put the microphone too close to the speaker during use.
5. If you have any questions about our product, do not worry; you can go to your order and click 'Contact Seller'; we'll do our best to help you!

Microphone and speaker factory configuration has been set up, the user will automatically connect when using

A black portable karaoke machine with a large circular speaker featuring a rainbow-colored LED light ring. It has a carrying handle on top and a control panel with various buttons and a small display. Two black wireless microphones with silver grilles and red power buttons are shown next to the machine. The background is white with decorative musical notes and a treble clef in the bottom corners.

Willkommen

Vielen Dank für den Kauf unserer Produkte. Ihre Unterstützung und Ihre Vorschläge sind die treibende Kraft für unseren Fortschritt. Bei Fragen stehen wir Ihnen gerne zur Verfügung. Wir sind bestrebt, Ihnen einen guten Service zu bieten.

Merkmale

Die multifunktionale Karaoke-Maschine K9-M ist mittelgroß und verfügt über ein stilvolles Schloss. Enthält zwei drahtlose Handmikrofone und einen 5,2-Zoll-LCD-Display mit einer verstärkten Reichweite von bis zu 15 m. Mit der leistungsstarken TWS-Funktion können Sie zwei K9-M-Systeme für Stereoklang koppeln. Es gibt unabhängige Steuerstationen für die Mikrofonlautstärke, den Hall und das Ein-/Ausstellen der bunten RGB-Lichter. Ideal für Familien- und Freundschaften, Outdoor-Aktivitäten, Musikaufführungen, Unterricht und mehr.

Packliste

 Karaoke-Lautsprecher  Typ-C-Ladekabel	 Drahtlose Mikrofone  Schalterriemen
--	--

[illegible]

- **LED-Beleuchtung**

LED	Short Press	RGB	WHITE	RED	YELLOW	BLUE	GREEN
-----	-------------	-----	-------	-----	--------	------	-------

- **Mikrofon**

- Bitte beachten Sie, dass jedes kabellose Mikrofon 2AA benötigt (nicht im Lieferumfang enthalten).
- Wenn Sie das Produkt erhalten, verwenden Sie bitte das mitgelieferte USB-A-Ladekabel und das 5V-Ladegerät (nicht im Lieferumfang enthalten), um die Juicebox aufzuladen.
- Da die Karaoke-Maschine über ein integriertes mit großer Kapazität verfügt, halten Sie sie bitte von Umgebungen mit hohen Temperaturen fern und vermeiden Sie längere Sonneneinstrahlung.
- Haltieren Sie das Mikrofon bei der Verwendung nicht zu nahe am Lautsprecher, um keinen harten Klang zu erzeugen.
- Wenn Sie Fragen zu unseren Produkten haben, machen Sie sich bitte keine Sorgen. Sie können Ihre Bestellung eingeben und auf „Klerküfer kontaktieren“ klicken. Wir werden unser Bestes tun, um Ihnen zu helfen!

SEDC RSS warning
 This device complies with Innovation, Science and Economic Development Canada Compliance
 Notice: The SEDC RSS standard (s) Operation is subject to the following two conditions:
 (1) This device may not cause interference, and
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.
 Le présent appareil est conforme aux CNR d'innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
 L'exploitation est autorisée aux deux conditions suivantes:
 (1) L'appareil ne doit pas produire d'interférence,
 (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
 This equipment complies with SEDC RF radiation exposure limits set forth for an uncontrolled environment.
 This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.
 This equipment should be installed and operated with minimum distance 20cm between the antenna and your body (or for KG-M),
 IC exposure to radiation:
 Cet équipement est conforme aux limites d'exposition à la radiofréquence SEDC
 s'appliquant pour un environnement non contrôlé.
 Cet équipement ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou émetteur.
 Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre la radio et votre corps (uniquement pour le KG-M).