

正面

TWS无线耳机 使用说明书		耳机配置 产品型号：E311版本：5.4 耳机容量：30mAh/3.7V充电时间：约1小时 包装清单 1. 充电盒*1 2. 左右耳机*1 3. 产品手册*1 4. 充电线*1 耳机充电：耳机放入充电盒自动充电 充电盒低电：数码管个位数闪烁 充电盒充电：数码管个位数闪烁，充满100停止	充电仓配置参数 电池容量：350mAh/3.7v 充也时间：约1小时 输入电压：5v/500mAh 佩戴方式 打开充电仓盖，取出右耳耳机，将耳机喇叭端轻轻放入右耳耳道，再轻轻揉动耳机不晃动为宜。用同样方法佩戴左耳耳机。 操作方式 1.开机 (1) 打开充比仓盖子，取出耳机白动开机，耳机红蓝灯闪烁 (2) 将本机在关机状态下，长按耳机按键板3秒开机 2.关机 (1) 将耳机放回充电仓，耳机自动关机充电 (2) 将本机在开机状态下，长按耳机按键板5秒关机	双耳配对连接 1. 打开充电仓盖子，取出耳机自动开机，红蓝灯闪烁，进入自动组队状态，其中一个耳机闪烁，另一个耳机常亮 3.点击连接 "TWS"即可连接。 如朵连接失败，将耳机放回充电仓盖上盖子，然后重复上面操作步骤即可。 4. 双耳同时离开与设备正常连接距离后，耳机进入回连蓝牙耳机状态，5分钟内未完成回连成功，双耳将自动关机。 5、耳机开机之后，未连接手机之前，双击双耳任意一边自动切换中英文语言（单中文或单英文的产品无此功能） 首次连接设备后，下一次耳机重启开机，会自动连接上一次配对设备	双耳触控操作 播放/暂停音乐 普尔状态下 轻按L/R耳机1下 播放上一曲 普尔状态下，轻按L/R耳机2下 播放下一曲 普尔状态下轻按L/R耳机2下 音乐状态下，轻按3次L/R音量加+ 普尔状态下，轻按3次L/R音量减- 接听电话 来电时，轻按L/R耳机1下 拒接电话 来电时，轻按L/R耳机2下(或长按) 语音助手 进入语音助手状态	F&Q 1、问：怎么只有一个耳机有声音？ 答：将两个耳机同时放回充电仓，关盖充电，然后在取出看是否恢复双耳模式，如未恢复，恢复出厂设置即可解决 2、问：手机无法连接耳机？ 答：怎么听歌/通话没有声音？ 答：安卓手机在手机连接记录的右边有一个设置图标，点击进入，将两个音频选项取消勾选再勾选选择，苹果手机在设置通用辅助功能进入盲键通讯方式，选择自动，如果本来就是自动，就更为其他选项，然后在更改为自动，如未恢复，删除配对记录重新连接尝试 4、问：怎么有卡顿/断续？ 答：如果使用耳机时，周边有大量的Wi-Fi设备，4G信号，大功率电器等等产生干扰，可能会造成卡顿，断线情况，更换环境或者重新配对连接可以恢复正常。 注意事项 1、请使用正规渠道有安全认证的充电器进行充电 2、使用耳机时适当的调节音量大小以免损伤听觉 3、正确使用产品避免高空掉落或重度折压 4、儿童请在成人陪同下使用避免误食 5、远离高温或潮湿等极坏环境 6、请勿拆卸本产品
---	--	---	---	--	--	---

反面

TWS wireless headphones Operating instruction		Headset con guration product Model: E311 version: 5.4 Running time: about 4 hours Talk time: about 3 hours Headphone capacity: 30mAh/ 3.7V charging time: about 1 hour E ective distance : ≥ 10 m Horn: copper ring 8mm packing list 1. charging box *1 2. Left and right earphones *1 3.product Manual *1 4. charging cable *1 Earphone charging: The earphone is automatically charged in the charging case The charging indicator light is red and the red light goes out when it is full charging case low power: digital tube single digit ashing charging case charging: digital tube single digit ashing' full 100 stop ICC Warning This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Note: 1. The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Note: 2. Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.	charging bin con guration parameters . Battery capacity: 350mAh/ 3.7v charging time: about 1 hours Input voltage: 5v/ 500mAh wearing a way Open the cover of the charging bin' take out the earphone of the right ear' and put the earphone horn end.Gently put into the ear canal of the right ear' and then gently swing the earphone not to shake.Wear the left earpiece in the same way. Mode of operation 1. The boot (1) Open the cover of the charging bin' take out the earphone and turn it on Blue lights ashing (2) When the dryer is o' press the button for 3 seconds to start the machine 2.To turn it o (1) put the earphone back to the charging bin' and the earphone will automatically shutdowns and charge (2) When the headset is on' press the button for 5 seconds to power o the headset	pairs of ears connected 1. Open the charging compartment cover' remove the earphones and turn them on automatically'The red and blue lights are iashing'ntering automatic teaming mode' one of whichThe earphone light is of or the red and blue lights on both earphones iash slowly' indicating a successful team formation. 2. Open the bluetooth list of the device and search for "TWS". 3. click "TWS" to connect. If the connection fails' put the earphones back on the cover of the charging bin. put the lid on and repeat the top The operation procedure is ok. 4. Ears left connected to the equipment normal distance at the same time' Headset The headset is connected back to the Bluetooth headset' and the connection is not completed with in 5 minutes If the connection is successful' both ears will shut down automatically. 5. Double-click after the headset is turned on and before the phone is disconnected Automatically switch between chinese and English on either side of ears (Only chinese or only English products do not have this function) After the device is connected for the rst time' the next time the headset is restarted.It will automatically connect the last pair device	Two-ear touch operation play/pause the musicLight music condition according to the L/R headset under 1 play a songunder the light press L/R headset 2 music condition play the next songunder the light press L/R headphones 2 music condition Light music' according to the 3 L/R volume plus +' light music condition according to the 3 Rthe volume - reduction Answer the phonecalls' light according to the L/R headset under 1 Refuse to answer the phonecalls' under the light according to the L/R headphones 2 (or long) voice assistantNote 1.5 seconds long press any headphones let go nuclear state into speech aides	F&Q 1. Q: How come only one earphone has sound? A: put the two earphones back into the charging bin at the same time' close the cover to charge' and then take them out to see whether the dual-ear mode is restored If the fault is not recti' ed' restore the fault to factory Settings 2. Q: The phone can' t connect to the headset? A: Delete the paired TWS on the mobile phone' and then make the paired connection. 3. Q: How can I listen to music/talk without sound? A: Android phones have a setting icon on the right side of the phone onnection record, click enter to select two audioDevicelect and then re-select. Enter audio call mode in Setting General Accessibility' and select Automatic' if it is automatic' then other options' and then change to automatic' if not restored' Delete the pairing record retry attempt. 4. Q: Why is there a stutter/ stutter? A: If you use headphones' there are a lot of Wi-Fi devices' 4G signals' high power appliances and so onInterference' stuttering and di continuous conditions may occur' and the connection can be restored by changing the environment or re-pairing. . Matters needing attention 1. please use a charger with safety certi cation from a formal source for charging 2. Adjust the volume of headphones to avoid damage to hearing 3' the correct use of the product to avoid falling from high or heavy extrusion 4. children should be accompanied by adults to avoid accidental ingestion 5. Stay away from extreme environments such as high temperature or humidity 6. Do not disassemble the product
---	--	--	--	--	--	--