


User Manual



CUSTOMER SERVICE



WORRY-FREE SHOPPING

We always promise all our products are covered 30-Days Hassle-free Refund & a 1-YEAR Replacement Guarantee.



PROFESSIONAL CUSTOMER SERVICE TEAM

Our customer support doesn't end after your purchase;
Please contact us if there's anything we can do for you.
You can click "Contact Seller" on your order, and our customer service team will help you asap.

How to Use:

Device Part:

Long press to turn on the product, then the item is on standby and the LED light turns on.

Short press to activate the vibrating function and switch among 9 vibrating modes.

Long press to turn off the product, then the LED light is off.

Remote Control Part:

When the device is on standby:

Short press on the remote control to activate the vibrating function.

Short press to switch among 9 vibrating modes.

Long press on the remote control to turn off the vibrating function, then the item returns to standby mode.

APP Part:

Download and install the APP:

Scan the QR code below to download the APP or search

“Love Spouse” to download the APP on Apple Store or Google Play(It is recommended to scan the QR code below).



Make sure your Bluetooth is on before opening this APP

Register Your Account:

Open the APP, click “New User” to create your account, then you can login the device.

Add Device:

Click the icon "+" to scan the binding QR code below to connect the device(make sure your Bluetooth is on), then start to control it(It needs to scan the binding QR code when connecting the device for the first time).



1.Classic Mode: Touch the screen to switch among 9 vibrating modes.

2.Video Mode: Select a local video, then you can watch the video & touch the screen to switch among 9 vibrating modes.

3.Musical Mode: Select the music and play, then the device can vibrate based on the music rhythm.

4.Draw Something: Click the icon “+” to set and save different vibrating modes, then you can click the play button and enjoy the custom vibrating pleasure.

5.Shake Mode: Shake your cell phone to customize the vibrating, and the vibrating intensity varies according to your force.

6.Interactive Mode:

- Click the icon “+”, and search Email/ID to add your partner's account(Your friend can download and register this APP account even if he/she doesn't have this toy and he/she can apply to control your toy).

- You can find your partner' s ID from his/her account after login (Mine-Personal Information-ID).

- After making the verification, your friends appear in the friend list.

- When you both are online, click your friend's name to send a request to interact. After your friend confirms the request, you both can via invite video to control your device(including text, image sending, voice & video calls). Your partner could control your toy by Classic Mode, or with DIY vibration by Draw Something or Shake Mode.

Tips: If you don' t know how to control your device via APP, you can get help from “Mine - Operation Guide or Feedback & FAQ” . Or you can ask for help from “Message - News - Official Customer Service” . We promise to respond to you within 24 hours.

How to Clean & Store:

1.Please turn off the product before cleaning.

2. Please clean the toy with warm water and aseptic soap.

3. After washing, dry the item with a towel or paper tissue.

4. Keep the item in a cool and dry place.

5. Please avoid sun exposure, being heated, high pressure and wet environment.

How to Charge:

The indicator light flashes while charging, and is always on after fully charged.

Package List:

1 Vibrator, 1 Remote Control, 1 USB Cable, 1 User Manual

Product Details:

Product Size	9.50*3.65*2.26 Inches
Material	Silicone + ABS
Working Noise	≤50DB
Product Modes	9 Vibrating Modes
Charging Time	70 Minutes(Fully Charged)
Working Time	About 60 Minutes(Fully Charged)
Waterproof Rating	IPX7

Notes:

- Please kindly read the manual before using this product.
- Fully charged before first use.
- Please charge it with a matching adapter.
- Please use the charging cable inside this package.
- Please don' t use the product while charging.

⚠ WARNING


- INGESTION HAZARD:** This product contains a button cell or coin battery.
- DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical**
- KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep them away from children. Please do NOT dispose of batteries in household trash or incinerate them.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Battery type: CR2032
- Nominal battery voltage: 3.7V
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating), or incinerate. Doing so may result in injury due to venting,

- leakage, or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and-).
 - Do not mix old and new batteries, different brands, or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
 - Remove and immediately recycle or dispose of batteries from equipment not used for an extended period according to local regulations.
 - Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Benutzerhandbuch



CUSTOMER SERVICE



WORRY-FREE SHOPPING

We always promise all our products are covered 30-Days Hassle-free Refund & a 1-YEAR Replacement Guarantee.



PROFESSIONAL CUSTOMER SERVICE TEAM

Our customer support doesn't end after your purchase;
Please contact us if there's anything we can do for you.
You can click "Contact Seller" on your order, and our customer service team will help you asap.

Verwendungsweise:

Für Gerät:

Drücken Sie lange , um das Produkt einzuschalten, dann ist das Gerät im Standby-Modus und das LED-Licht leuchtet.

Drücken Sie kurz , um die Vibrationsfunktion zu aktivieren und unter 9 Vibrationsmodi zu wechseln.

Drücken Sie lange , um das Gerät auszuschalten, dann erlischt das LED-Licht.

Für Fernbedienung:

Wenn sich das Gerät im Standby-Modus befindet:

Drücken Sie kurz  auf der Fernbedienung, um die Vibrationsfunktion zu aktivieren.

Drücken Sie kurz  um unter 9 Vibrationsmodi zu wechseln.

Drücken Sie lange  auf der Fernbedienung, um die Vibrationsfunktion auszuschalten, dann kehrt das Gerät in den Standby-Modus zurück.

Für APP:

Herunterladen und Installieren der APP:
Scannen Sie den folgenden QR-Code, um die App herunterzuladen, oder suchen Sie im Apple Store oder bei Google Play nach „Love Spouse“, um die APP herunterzuladen (Es wird empfohlen, den folgenden QR-Code zu scannen).



Stellen Sie sicher, dass Ihr Bluetooth aktiviert ist, bevor Sie diese APP öffnen.

Ihr Konto registrieren:

Öffnen Sie die APP, klicken Sie auf "Neuer Benutzer", um Ihr Konto zu erstellen. Anschließend können Sie sich am Gerät anmelden.

Gerät hinzufügen:

Klicken Sie auf das Icon "+" und scannen Sie den verbindlichen Code unten, um das Gerät zu verbinden (Stellen Sie sicher, dass Ihr Bluetooth aktiviert ist). Starten Sie dann die Steuerung (Sie müssen diesen verbindlichen QR-Code scannen, wenn Sie das Gerät zum ersten Mal verbinden).

1. Klassischer Modus: Berühren Sie den Bildschirm, um unter 9 Vibrationsmodi zu wechseln.

2. Video-Modus: Wählen Sie ein lokales Video aus, dann können Sie das Video ansehen und durch Berühren des Bildschirms unter 9 Vibrationsmodi wechseln.

3. Musik-Modus: Wählen Sie die Musik aus und spielen Sie sie ab, dann kann das Gerät im Rhythmus der Musik vibrieren.

4. Etwas Zeichnen: Klicken Sie auf das Icon "+", um



verschiedene Vibrationsmodi einzurichten und zu speichern, dann können Sie auf den Abspielknopf klicken und das individuelle Vibrationsvergnügen genießen.

5. Schüttelmodus: Schütteln Sie Ihr Handy, um das Vibrieren einzurichten, und die Vibrationsintensität variiert je nach Ihrer Kraft.

6. Interaktiver Modus:

- Klicken Sie auf das Icon "+" und suchen Sie nach E-Mail / ID, um das Konto Ihres Partners hinzuzufügen. Ihr(e) Freund(in) kann diese APP herunterladen und dieses APP-Konto registrieren, auch wenn er/sie dieses Spielzeug nicht hat, und er/sie kann sich anmelden, um Ihr Spielzeug zu steuern.

- Die ID Ihres Partners können Sie nach dem Einloggen in seinem/ihrer Konto finden (Meine-Persönliche Informationen-ID).

- Nach der Verifizierung erscheinen Ihre Freunde in der Freundesliste.

- Wenn Sie beide online sind, klicken Sie auf den Namen Ihres Freundes, um eine Anfrage zur Interaktion zu senden. Nachdem Ihr Freund die Anfrage bestätigt hat, können Sie beide Ihr Gerät per Videoeinladung steuern (einschließlich Text, Bildversand, Sprach- und Videoanrufe). Ihr Partner kann Ihr Spielzeug über den klassischen Modus oder über die DIY-Vibration ("Etwas Zeichnen" oder "Schüttelmodus") steuern.

Tipps: Wenn Sie nicht wissen, wie Sie Ihr Gerät über die APP steuern, können Sie die Hilfe von "Mine - Bedienungsanleitung oder Feedback & FAQ" finden. Oder Sie können unter "Nachricht - News - Offizieller Kundendienst" um Hilfe bitten. Wir versprechen, Ihnen innerhalb von 24 Stunden zu antworten.

Reinigung & Aufbewahrung:

1. Bitte schalten Sie das Gerät vor der Reinigung aus.

2. Bitte reinigen Sie das Spielzeug mit warmem Wasser und aseptischer Seife.

3. Trocknen Sie den Artikel nach dem Waschen mit einem Handtuch oder Papiertuch.

4. Bewahren Sie den Artikel an einem kühlen und trockenen Ort auf.

5. Sonneneinstrahlung, Heizung, hoher Druck und feuchte Umgebungen sollen vermieden werden.

Lademethode:

Das LED-Licht blinkt während des Ladevorgangs und leuchtet nach vollständiger Aufladung immer.

Packliste:

1 Vibrator, 1 Fernbedienung, 1 USB-Kabel, 1 Benutzerhandbuch

Produktdetails:

Produktmaße	24,13*9,28*5,75 cm
Material	Silikon + ABS
Arbeitsgeräusch	≤50DB
Produktmodi	9 Vibrationsmodi
Ladezeit	70 Minuten(vollständig aufgeladen)
Arbeitszeit	Etwa 60 Minuten(vollständig aufgeladen)
Wasserdichtheit	IPX7

Hinweise:

1. Bitte lesen Sie das Handbuch, bevor Sie dieses Produkt verwenden.
2. Vollständig aufgeladen vor der ersten Verwendung.
3. Bitte laden Sie es mit einem passenden Adapter auf.
4. Bitte verwenden Sie das Ladekabel in diesem Paket.
5. Bitte verwenden Sie das Produkt nicht während des Ladevorgangs.

⚠️ WARNUNG

- **VERSCHLUCKUNGSGEFAHR:** Dieses Produkt enthält eine Knopfzelle
- Eine verschluckte Knopfzelle oder Münzbatterie kann innerhalb von nur **2 Stunden interne chemische Verbrennungen** verursachen.
- **TOD** oder schwere Verletzungen können auftreten, wenn sie verschluckt wird.
- **Halten** Sie neue und gebrauchte Batterien **UNERREICHBAR FÜR KINDER.N**
- **Suchen Sie sofort ärztliche Hilfe auf**, wenn der Verdacht besteht, dass eine Batterie verschluckt oder in irgendeinen Teil des Körpers eingeführt wurde.



- a) Nehmen Sie verbrauchte Batterien heraus, recyceln Sie sie oder entsorgen Sie sie gemäß den örtlichen Vorschriften und halten Sie sie von Kindern fern. Bitte entsorgen Sie Batterien NICHT im Hausmüll und verbrennen Sie sie auch nicht.
- b) Selbst verbrauchte Batterien können zu schweren oder tödlichen Verletzungen führen.
- c) Rufen Sie eine örtliche Giftnotrufzentrale an, um Informationen zur Behandlung zu erhalten.
- d) Batterietyp: CR2032
- e) Nennspannung der Batterie: 3,7 V
- f) Nicht wiederaufladbare Batterien dürfen nicht wieder aufgeladen werden.

g) Das Gerät nicht gewaltsam entladen, nicht aufladen, nicht auseinanderbauen, nicht über die vom Hersteller angegebene Temperatur hinaus erhitzen oder verbrennen. Andernfalls kann es zu Verletzungen aufgrund von Entlüftung, Leckagen oder einer Explosion mit daraus resultierenden chemischen Verbrennungen kommen.

h) Stellen Sie sicher, dass die Batterien entsprechend der Polarität (+ und -) eingelegt sind.

i) Mischen Sie keine alten und neuen Batterien, unterschiedliche Marken oder Batterietypen, wie z. B. Alkali-, Kohlenstoff-Zink- oder wiederaufladbare Batterien.

j) Nehmen Sie die Batterien aus dem Gerät heraus und recyceln oder entsorgen Sie sie sofort gemäß den örtlichen Vorschriften über einen längeren Zeitraum verwendet werden.

k) Sichern Sie das Batteriefach immer vollständig. Wenn das Batteriefach nicht sicher schließt, verwenden Sie das Produkt nicht mehr, entfernen Sie die Batterien und halten Sie sie von Kindern fern.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.