

User Manual

How to Use:

Device Part:

Long press to turn on the product, then the item is on standby and the LED light turns on.

Short press to activate the vibrating function and switch among 9 vibrating modes.

Long press to turn off the product, then the LED light is off.

Remote Control Part:

When the device is on standby:

Short press button on the remote control to activate and switch among 9 taint vibrating modes.

Long press button on the remote control to turn off the taint vibration.


Short press button on the remote control to activate and switch among 9 Tail vibrating modes.

Long press button on the remote control to turn off the tail vibration.

App Controlled Part:


Download and install the APP:

Download and install the APP by scanning the QR code below to get the LuvvJoy App, or search "LuvvJoy" on the Apple Store.(Scanning the QR code is recommended)



LuvvJoy Account Register:

Open the App, go to "Sign in" to register by entering your email, creating a password, and repeating it for confirmation, then you can log in to the App. Then, follow the on-screen instructions to enter your basic information.



“Home” Page Device Binding:

Turn on your phone’s Bluetooth, then bind the device in 1 of 3 ways(this step is only needed the first time you connect):

- 1)Scan the product QR code
- 2)Enter digital code "608003"
- 3)Enter product name "AnalVibe"



Note: Before binding the product, please allow Bluetooth access.

Device Controlling:

Select the device to enter the operation page.


- 1)**Classic Mode:** The classic Mode 1 offers 9 vibrating modes to control taint vibration, and Mode 2 offers 9 vibration modes to control tail vibration; tap a pattern to start (icon flashes), tap again to stop and enter standby (icon stops flashing).

2)Draw Mode:

- a.Keep your finger on the and move it; the frequency will change according to the line you draw on the screen.
- b.Tap the , slide on the to create a pattern, then tap the again to stop; the saved mode appears under the name.


“Chat” Page Add Friends:

- 1)Click the “+” icon in the top right corner.
- 2)Select “Add Friend/Room”.
- 3)Enter your Friend ID and click “Add”.
- 4)Finally, click “Add to Contacts”.



“Chat” Page Create Room:


- 1)Click the “+” icon in the top right corner.
- 2)Select “Add Friend/Room”.
- 3)Enter a Room Name, upload an image, then click “Create”.
- 4)Click “Copy Room ID” to invite others and enable multi-user interaction in the same room.



“Chat” Page Interact with Friend:


In the chat window, tap the “+” icon at the bottom left:

- 1) Interact – request remote control of your device,
- 2) Image – send pictures,
- 3) Voice Call – make voice calls,
- 4) Video Call – make video calls; during voice or video calls, you can minimize the screen to also use the Interact and Image functions.




I can’t control the device?

When you open the app for the first time please agree and accept all the requests.



I can't install the APP?

When you download the app for the first time please agree and accept all the requests.



How to Clean & Store:

- 1.Please turn off the product before cleaning.
2. Please clean the toy with warm water and aseptic soap.
3. After washing, dry the item with a towel or paper tissue.
4. Keep the item in a cool and dry place.
5. Please avoid sun exposure, being heated, high pressure and wet environment.

How to Charge:

The indicator light flashes while charging, and is always on after fully charged.

Package List:

1 Vibrator, 1 Remote Control, 1 USB Cable, 1 User Manual

Product Details:

Product Size	9.50*3.65*2.26 Inches
Material	Silicone + ABS
Working Noise	≤50DB
Product Modes	9 Vibrating Modes
Charging Time	70 Minutes(Fully Charged)
Working Time	About 60 Minutes(Fully Charged)
Waterproof Rating	IPX7

Notes:

1. Please kindly read the manual before using this product.
2. Fully charged before first use.
3. Please charge it with a matching adapter.
4. Please use the charging cable inside this package.
5. Please don’t use the product while charging.

- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep them away from children. Please do NOT dispose of batteries in household trash or incinerate them.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) Battery type: CR2032
- e) Nominal battery voltage: 3.7V
- f) Non-rechargeable batteries are not to be recharged.
- g) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating), or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
- h) Ensure the batteries are installed correctly according to polarity (+ and-).
- i) Do not mix old and new batteries, different brands, or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- j) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period according to local regulations.
- k) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.