

user manual



Please read the instruction manual carefully before use to ensure correct installation and quick use. The product is subject to the actual item!

Watch charging

·When using for the first time, please charge the watch. The watch uses a magnetic charging port. Connect the magnetic cable, then plug it into a power source. We recommend using a charger with a specification of 5V 1A or higher to charge the watch. After charging is complete, please turn off the power or unplug the magnetic cable.

First start-up

·Press and hold the power button for 3 seconds until the watch displays the startup screen. The first time you start up a smart device, it will take some time to check all the apps, so please be patient. Once it's done, set the language (choose the one you want), go to the settings and selection screen, and keep clicking "Next" until you get to the system operation screen.

·If you need to change the language after starting up, go to Settings - System - Language
- select the first item, and add the system default language.

Key functions

power button: ·Press and hold to turn on;

·When the screen is on, press briefly to turn off the screen.

·Press and hold for two seconds while the device is turned on to enter the shutdown/restart selection interface.

·If improper operation causes the watch to freeze, press and hold the power button for 10 seconds to force a restart.

back button: ·In the clock interface, press briefly to enter the main menu; press and

hold to call up the volume adjustment shortcut key.

·In non-clock mode, press briefly to return to the main menu.

Sliding operation

- Swipe up on the clock interface to bring up recent tasks.
- Swipe down on the clock interface to bring up notifications/control center.
- Swipe left on the clock interface to enter the main menu.

Dial

1. The watch's main screen can display a variety of beautiful watch faces, and we have pre-installed several watch faces for you.
2. Users can long press the screen for 2 seconds on the watch face interface to enter the watch face selection mode, and then swipe left or right to choose from a variety of watch faces.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.