

工艺:风琴折,4C

Charging Case (charging): Red light: Charging. Blue light: Fully charged. No light: Discharging.  ● Charging ● Fully charged ● Discharging	EARBUD TOUCH OPERATIONS MUSIC CONTROL <table border="1"> <thead> <tr> <th>Action</th><th>Left Ear</th><th>Right Ear</th></tr> </thead> <tbody> <tr> <td>Double Tap</td><td>Play/Pause music</td><td>Play/pause music</td></tr> <tr> <td>Triple Tap</td><td>Decrease volume</td><td>Increase volume</td></tr> <tr> <td>Quadruple Tap</td><td>Enter low-latency/music mode</td><td>Enter low-latency/music mode</td></tr> <tr> <td>Long Press 3s</td><td>—</td><td>Next track</td></tr> </tbody> </table>	Action	Left Ear	Right Ear	Double Tap	Play/Pause music	Play/pause music	Triple Tap	Decrease volume	Increase volume	Quadruple Tap	Enter low-latency/music mode	Enter low-latency/music mode	Long Press 3s	—	Next track	CALL CONTROL <table border="1"> <thead> <tr> <th>Action</th><th>Left Ear</th><th>Right Ear</th></tr> </thead> <tbody> <tr> <td>Double Tap</td><td>Answer/End call, Cancel outgoing call</td><td>Answer/End call, Cancel outgoing call</td></tr> <tr> <td>Long Press 2s</td><td>Reject call</td><td>Reject call</td></tr> </tbody> </table> VOICE ASSISTANT CONTROL <table border="1"> <thead> <tr> <th>Action</th><th>Left Ear</th><th>Right Ear</th></tr> </thead> <tbody> <tr> <td>Single Tap</td><td>Exit voice assistant</td><td>Exit voice assistant</td></tr> <tr> <td>Long Press 3s</td><td>Open voice assistant</td><td>—</td></tr> </tbody> </table>	Action	Left Ear	Right Ear	Double Tap	Answer/End call, Cancel outgoing call	Answer/End call, Cancel outgoing call	Long Press 2s	Reject call	Reject call	Action	Left Ear	Right Ear	Single Tap	Exit voice assistant	Exit voice assistant	Long Press 3s	Open voice assistant	—	SPECS <table border="1"> <tbody> <tr> <td>Brand</td><td>Lytmi</td></tr> <tr> <td>Model</td><td>Lytmi CozyClip B1</td></tr> <tr> <td>BT Version</td><td>BT5.3</td></tr> <tr> <td>Charging Input</td><td>5V=0.6A</td></tr> <tr> <td>Battery Capacity</td><td>40mAh(Earbuds) 350mAh(Charging Case)</td></tr> <tr> <td>Charging Time</td><td>1.8 Hours (Earbuds) 2 Hours (Charging Case)</td></tr> <tr> <td>Waterproof Rating</td><td>IPX4(earbuds)</td></tr> <tr> <td>Bluetooth Range</td><td>10 m / 33 ft</td></tr> <tr> <td>Hall Switch</td><td>Yes</td></tr> </tbody> </table>	Brand	Lytmi	Model	Lytmi CozyClip B1	BT Version	BT5.3	Charging Input	5V=0.6A	Battery Capacity	40mAh(Earbuds) 350mAh(Charging Case)	Charging Time	1.8 Hours (Earbuds) 2 Hours (Charging Case)	Waterproof Rating	IPX4(earbuds)	Bluetooth Range	10 m / 33 ft	Hall Switch	Yes	NOTICE - Do not charge the charging case continuously for more than 12 hours. - Do not disassemble the headset or put the device into the fire to avoid explosion. - Do not place the magnetic charging cable or the magnetic charging port or the headset near metal objects. - Use of charging cables not approved by the manufacturer may cause fire, explosion or other hazards. - Use the product within the temperature range of 32°~95°F and store the product within the temperature range of 14°F~113°F. Excessively high or low temperatures may cause equipment malfunction. - Do not expose the headset to the sun for a long period of time, otherwise it will be easily deformed, aging and breakage. - This product has a built-in non-removable lithium battery, the battery is prohibited from disassembly, impact, extrusion or put into the fire, if there is a serious expansion, please do not continue to use. Warranty: 12-Month Limited Warranty Support: Lifetime Technical Support Email: support@lytmi.co Official Website: www.lytmi.co Support Phone: (+1) 2108588666 youtube@lytmi Instagram@lytmiofficial Facebook@Lytmi Tiktok@lytmi
Action	Left Ear	Right Ear																																																					
Double Tap	Play/Pause music	Play/pause music																																																					
Triple Tap	Decrease volume	Increase volume																																																					
Quadruple Tap	Enter low-latency/music mode	Enter low-latency/music mode																																																					
Long Press 3s	—	Next track																																																					
Action	Left Ear	Right Ear																																																					
Double Tap	Answer/End call, Cancel outgoing call	Answer/End call, Cancel outgoing call																																																					
Long Press 2s	Reject call	Reject call																																																					
Action	Left Ear	Right Ear																																																					
Single Tap	Exit voice assistant	Exit voice assistant																																																					
Long Press 3s	Open voice assistant	—																																																					
Brand	Lytmi																																																						
Model	Lytmi CozyClip B1																																																						
BT Version	BT5.3																																																						
Charging Input	5V=0.6A																																																						
Battery Capacity	40mAh(Earbuds) 350mAh(Charging Case)																																																						
Charging Time	1.8 Hours (Earbuds) 2 Hours (Charging Case)																																																						
Waterproof Rating	IPX4(earbuds)																																																						
Bluetooth Range	10 m / 33 ft																																																						
Hall Switch	Yes																																																						

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.