


## Invisible Wireless Charger User Manual

Model: E30SZ



### EN

Thank you for selecting our product. Before utilizing it, please take the time to thoroughly review and strictly adhere to the included instructions and safety precautions.

#### Package Contents

1. Alignment assistant × 1
2. Black power sticker × 1
3. Transparent sticker × 1
4. Adhesive metal ring × 1
5. Wireless Charger × 1
6. Charging Cable × 1
7. QC 3.0 Adapter × 1
8. User Manual × 1

#### Specification

Input: 12V=1.5A  
Output: 10W (Max)  
Charging distance: 0-30mm(0"-118")  
Size: 104\*104\*10.5mm

#### Note:


1. When charging distance is between 0-18mm(0"-0.7"), you can use the charger with or without any sticker.
2. When charging distance is between 18-30mm(0.7"-1.18"), please use the black power sticker.

#### Instruction for the indicator light:

1. Red light turns on briefly and then goes off - power on, ready for charging.
2. Red light always on - charging.
3. Red light flashing - Metal object detected while charging, over-voltage or under-voltage protection activated.

### Installation Steps

Please installed on non-metallic materials such as marble, wood, glass, etc., and the thickness is within 0-30mm.



#### 1. Mount the adhesive metal ring

Rip off the protective layer of 3M tape, and mount the adhesive metal ring in your favorite position under the table.

#### 2. Attach the charger


Attach the charger to the adhesive metal ring, plug in and check if the wireless charger is power on.

#### 3. Fold the alignment assistant

Fold the "Alignment assistant" up along the indentation line, and tear off the double-sided tape (notice: do not stick this part to the table at this time yet).

#### 4. Locate the charging position

Place the "Alignment assistant" on the table, and move towards to the top of the charger, and continuously adjust the position until the light board is fully lit, then paste "Adhesive tape at back" area on the table to fix the card.



#### 5. Stick the power sticker

Tear off the circular installation prompt area in the center of the cardboard along the dotted line, and stick the power sticker on the blank area. (If the thickness of the desktop is within 18mm, please use the transparent table sticker.)

#### 6. Easy charging begins

Remove the "Alignment assistant" keep only the power sticker, place your phone in the center of the power sticker, easy charging begins!

### Important Safety Instructions

1. Do not squeeze or collide.
2. Do not disassemble or put it into fire or water to avoid short circuit and leakage.
3. Do not use the wireless charger in high temperature, high humidity or corrosive environments to avoid circuit damage and current leakage.
4. Do not place the wireless charger too close to magnetic cards with magnetic stripes or chips (ID cards, bank cards, etc.) to avoid the magnetic cards becoming invalid.
5. Children should be supervised to ensure that they do not use the wireless charger as a toy to avoid unnecessary accidents.
6. Please use it at an ambient temperature of 0-45°C.

### Attention

1. Please use PD20W or QC3.0 compatible power adapter for fast charging.
2. The back of the phone must not be adorned with ring buckles, items that augment its thickness, or metallic objects, as these will hinder the effectiveness of the phone's wireless charging capabilities.
3. It is normal to get hot while charging, if your phone gets hot seriously and stops charging for a long time, please adjust the position of the charger. Please make sure the center of the charger is aligned with the center of the wireless charger charging zone before charging.

### Warranty scope

When the listed conditions are fulfilled, we provide free exchange service and refund service with no additional cost.

1. Product malfunction during normal use.
2. The product is still under the 1 year warranty.

The following conditions aren't covered by the 1 year warranty:

1. Use third party adapter that isn't QC 3.0 certified.
2. The product is damaged intentionally, such as disassembling the product without professional guidance.
3. Product damage that are caused by man-made accident.

### Extended Service

If the product exceeds the warranty period, the customer still enjoys maintenance service, but the maintenance cost is required.

### DE

Vielen Dank, dass Sie sich für unser Produkt entschieden haben. Bevor Sie es verwenden, nehmen Sie sich bitte die Zeit, die beiliegenden Anweisungen und Sicherheitsvorkehrungen gründlich zu lesen und strikt zu befolgen.

#### Paket Inhalt

1. Ausrichtungsassistent × 1
2. Schwarzer Power Aufkleber × 1
3. Transparenter Aufkleber × 1
4. Klebender Metallring × 1
5. Kabelloses Ladegerät × 1
6. Ladekabel × 1
7. QC 3.0-Adapter × 1
8. Benutzerhandbuch × 1

#### Spezifikation

Eingang: 12V=1.5A  
Ausgang: 10W (Max)  
Ladeabstand: 0-30mm(0"-118")  
Größe: 104\*104\*10,5mm

#### Lösung:

1. Wenn der Ladeabstand zwischen 0 und 18 mm liegt, können Sie das Ladegerät mit oder ohne Aufkleber verwenden.
2. Wenn der Ladeabstand zwischen 18 und 30 mm (0,7 bis 1,18) liegt verwenden Sie bitte den schwarzen Power-Aufkleber.

#### Anleitung für die Kontrolleuchte:

1. Rotes Licht geht kurz an und erlischt dann - eingeschaltet, bereit zum Laden.
2. Rotes Licht leuchtet immer beim Laden.
3. Rotes Licht blinkt - Beim Laden wurde ein Metallobjekt erkannt, Überspannungs- oder Unterspannungsschutz aktiviert.

### Instalationsschritte

Bitte auf nichtmetallischen Materialien wie Marmor, Holz, Glas usw. installieren, und die Dicke liegt innerhalb von 0-30 mm.



#### 1. Montieren Sie den selbstklebenden Metallring

Ziehen Sie die Schutzschicht des 3M-Klebebands ab und bringen Sie den Kleber an Metallring an Ihrer Lieblingsposition unter dem Tisch.

#### 2. Schließen Sie das Ladegerät an

Befestigen Sie das Ladegerät am selbstklebenden Metallring und prüfen Sie, ob das kabellose Ladegerät eingeschaltet ist.

#### 3. Klappen Sie den Ausrichtungsassistenten zusammen

Falten Sie den "Ausrichtungsassistenten" entlang der Einkerbungsline nach oben und reißen Sie das doppelseitige Klebeband ab (Hinweis: Kleben Sie diesen Teil zu diesem Zeitpunkt noch nicht auf den Tisch).


#### 4. Suchen Sie die Ladeposition

Legen Sie den "Alignment Assistant" auf den Tisch, bewegen Sie ihn zur Oberseite des Ladegeräts und passen Sie die Position kontinuierlich an, bis die Lichtplatte vollständig beleuchtet ist. Kleben Sie dann den Bereich "Adhensivetape" auf die Rückseite des Tisches, um die Karte zu fixieren.

**eazpower**  
Easy Power, Easy Go



support@eazpowertech.com  
https://www.eazpowertech.com



## 6. Der einfache Ladevorgang beginnt

## Wichtige Sicherheitshinweise

- ## Hinweis

- ## Garantieumfang

Die folgenden Bedingungen fallen nicht unter die 1-Jahres-Garantie:

- ## erweiterter Service

FR

## Contenu de l'emballage

- 

## Spécifications

### Remarque

- ## Instruction pour le voyant lumineux

- ## Etapes d'installation

The diagram illustrates the process of a plate being placed on a table. It consists of two parts: (1) A plate is held above a table. (2) The plate is lowered and makes contact with the table surface, causing both the plate and the table to deform slightly, as shown by the dashed lines.

1. Montez la bague métallique adhésive

## 2. Fixez le chargeur

- 

- ### 3. Plier assistant d'alignement

#### 4. Localisez la position de charge

Collez l'autocollant d'alimentation

### La charge facile commence

## Consignes de sécurité importantes

- # Avis

- ### Portée de la garantie

Les conditions suivantes ne sont pas couvertes par la garantie d'un an :

- ## Service étendu

## FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

FCC RF exposure statement:

CE

Dieses Produkt erfüllt die Anforderungen der Europäischen Gemeinschaft an Funkstörungen

|                                                                                     |                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Verwendung nur in Innenbereichen                                                                                                                                                                    |
|  | Dieses Symbol bedeutet, dass das Produkt nicht als Hausmüll entsorgt werden darf. Stattdessen ist es an der jeweiligen Sammelstelle für das Recycling von Elektro- und Elektronikgeräten abzugeben. |