

四合一CD播放器

CD

小夜灯

蓝牙音箱

收音机

产品使用说明

外观按键

灯罩

喇叭口

功能按键

CD 盘放置区域

拨动开关

显示屏

Type-c充电电口

TF接口

音频输出口

硅胶防滑脚钉

功能按键

循环播放

CD/蓝牙/FM/TF

上一曲/减音量

灯光/蓝牙发射

拨动开关

加音量/下一曲

暂停/播放

开机

向上拨动[拨动开关]----开机。 向下拨动[拨动开关]----关机。 设备开启后无任何操作屏幕1分钟后息屏（进入低功耗模式）。

CD 模式使用说明

1.在CD 盘放置区域放上CD盘。
2.向上拨动[拨动开关]---开机。
3.设备开机后，自动读碟播放。
CD 播放状态时：
•短按[⏮]暂停/播放，长按[⏮]CD停止播放。
•长按[⏮]减少音量;长按[⏭]增加音量;
•短按[⏮]切换上一曲,短按[⏭]切换下一曲;
•循环功能:短按[⏮]四档模式依次循环切换，一档 (ONE) 单曲循环,二档(ALL)整体循环，三档(SFL)随机播放，四档(OFF)顺序播放。显示屏上会显示对应的模式状态，停留5秒后消失。

蓝牙模式使用说明

短按[📶]按键，打开蓝牙，显示屏bL闪烁，蓝牙处于搜索配对状态,此时打开您手机的蓝牙功能,在蓝牙搜索设备中,出现:“K8”字样,点击选中“K_8”设备名称。自动进入配对，配对连接成功后,会有提示音，显示屏bL常亮。

蓝牙音箱播放状态时：
•短按[⏮]暂停/播放。
•长按[⏮]减少音量;
•长按[⏭]增加音量;
•短按[⏮]切换上一曲。
•短按[⏭]切换下一曲;
•长按[⏮]断开蓝牙连接，蓝牙处于被搜索状态。

FM 模式使用说明

•短按 [📻] 切换至FM模式,显示屏出现FM ▶ 小字符样。
•长按 [📻] 自动搜台，搜索中，短按 [📻] 可停止搜台；搜台结束后短按 [📻] 切换频道；
•短按 [🔇] 闭音/播放；
•长按 [⏮] 减少音量,长按 [⏭] 增加音量；
•短按 [⏮] 向上手动搜台,短按 [⏭] 向下手动搜台；
•短按 [📶] 退出FM模式,切换其它模式。

TF 模式使用说明

插入TF卡，短按[📶]切换至TF模式，显示屏出现TF大字字符样。设备自动识别TF卡的内容并自动播放音乐.备注：显示屏出现NO 大字字符样,代表未识别到TF卡或TF卡异常。

小夜灯使用说明

短按[💡]开启灯光，第一档为暖光灯，第二档为呼吸灯。第三档关闭灯光，依次循环开启灯光。
长按[💡]开启设备的蓝牙发射模式，此时设备可连接无线耳机或其他无线设备。

产品充电使用说明

给产品充电时将USB数据线的USB端口接入电源适配器，Type-C端口接入产品充电电口，指示灯常亮，充满后熄灭。

规格参数

电源输入：DC5V/2A
LED功率：0.2W
扬声器功率：4Q5Wx2
电池容量：4000mAh
产品重量：616G
产品尺寸：194x137x71mm
电源充电电口为国际通用Type-C端口

FCC Waming Statement

Changes or modifications not expressly approved by the party res possible for compliance could void the user's authority to operate the equipment This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and canradiate radio frequency energyaand, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorent or relocate the receving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radioTV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement Thedevice can be usedin portable exposure condition without restriction.

非常感谢您选择我司产品
在使用产品前请认真阅读好产品说明

4-IN-1 CD PLAYER

CD

NIGHT LIGHT

BLUETOOTH SPEAKER

RADIO

PRODUCT INSTRUCTION

APPEARANCE BUTTON

Lampshade

Speaker

Function Button

CD disk storage area

Switch Toggle Lever

Display Screen

Type-c Charging Port

TF card interface

Audio Output Port

Silicone Non-slip Mat

FUNCTION BUTTON

Loop Playback

CD/Bluetooth/FM/TF

Previous Song/ Decrease Volume

Light/ Bluetooth transmitter

Toggle Switches

Increase Volume/ Next Song

Pause/play

ON/ OFF

Push [Toggle Switches] up ---- to power on. Turn [Toggle Switches] down ---- to power off. After the device is turned on, there is no operation screen. After 1 minute, the screen will break (enter low power mode).

CD MODE INSTRUCTIONS

1. Place the CD in the CD placement area.
2. Push the [Toggle Switches] upwards to turn on the device.
3. After the device is turned on, it will automatically read and play the disc.
When the CD is playing:
• Short press [⏮] to pause/play, long press [⏮] to stop CD playback.
• Long press [⏮] to reduce volume; long press [⏭] to increase volume.
• Short press [⏮] to switch to the previous song. Short press [⏭] to switch to the next song.
• Loop function: Short press [🔁] to cycle through the four modes in sequence, the first mode (ONE) for single loop, the second mode (ALL) for overall loop, the third mode (SFL) for random playback, and the fourth mode (OFF) for sequential playback. The corresponding mode status will be displayed on the display screen and will disappear after 5 seconds.

BLUETOOTH MODE INSTRUCTIONS

Short press the [📶] button to switch to Bluetooth mode. The display bL flashes and Bluetooth is in the searchpairing state. Now turn on the Bluetooth function of your phone. In the Bluetooth search device, the word "K_8" appears. Click to select the "K_8" device name. Automatically enter pairing. After the pairingconnection is successful, there will be a prompt tone and the display bL will be always on.
When the Bluetooth speaker is playing:
• Short press [⏮] to pause/play.
• Long press [⏮] to reduce the volume;
• Long press [⏭] to increase the volume;
• Short press [⏮] to switch to the previous song.Short press [⏭] to switch to the next song;
• Long press [🔇] to disconnect the Bluetooth connection. The Bluetooth is in the search state.

FM MODE INSTRUCTIONS

• Short press [📻] to switch to FM mode, and the screen will show FM▶ in small characters.
• Long press [📻] to automatically search for channels. During the search, short press [📻] to stop searching for channels;
• Short press [📻] to switch channels after searching for channels;
• Short press [🔇] to mute/play;
• Long press [⏮] to reduce the volume, long press [⏭]to increase the volume;
• Short press [⏮] to search channels manually upwards, short press [⏭] to search channels manually downwards,
• Short press [📶] to exit FM mode and switch to other modes.

TF MODE INSTRUCTIONS

Insert the TF card, short press [📶] to switch to TF mode, and the screen will display TF in large characters.The device automatically recognizes the content of the TF card and automatically plays music. Note: The screen displays NO in large characters, which means that the TF card is not recognized or the TF card is abnormal.

NIGHT LIGHT INSTRUCTIONS

Short press [💡] to turn on the light. The first level is warm light and the second level is breathing light.The third level turns off the light, and the lights are turned on in sequence.Long press [💡] to turn on the device's Bluetooth transmission mode. The device can now connect to wireless headphonesor other wireless devices.

PRODUCT CHARGING INSTRUCTIONS

When charging the product, connect the USB port of the USB data cable to the power adapter, and the Type-C port to the product charging port. The indicator light is always on and goes out when fully charged.

AUDIO INTERFACE USER MANUAL

The audio port can be connected to a three- or four-section wired headset.

NOTES

• Do not use or store the product in direct sunlight or high temperature for a long time.
• Do not charge too close to magnetic cards, touch recording media and sophisticated instruments
• Do not disassemble or modify the product.
• Do not touch the AC adapter with wet hands
• Keep this product away from water or other liquids.
• If you want to clean this product, disconnect the power supply
• Product working environment temperature magic range : -20-45°

SPECIFICATION PARAMETER

Power input : DC5V/2A
LED power: 0.2W
speaker power: 4Q5Wx2
Battery capacity: 4000mAh
Product weight: 616G
Product size: 194x137x71mm
The power charging port is an international Type-C port

FCC Waming Statement

Changes or modifications not expressly approved by the party res possible for compliance could void the user's authority to operate the equipment This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and canradiate radio frequency energyaand, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorent or relocate the receving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radioTV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement Thedevice can be usedin portable exposure condition without restriction.

RoHS

MADE IN CHINA