

Smart Sport Glasses

User Manual
Model No:RGS1

1 Packing List

- * Smart Sports Glasses


*1
- * Magnetic Charging Cable

*1
- * Prescription lens nose clip frame

*1
- * User Manual

*1

2 Product Diagram



3 Product specifications

Model: RSG1
Lens: TAC
Bluetooth version: 5.3
Chipset: JL7006F8
Playing time: Up to 6 hours
Connection distance: ≤ 10 m
Battery capacity: 130mAh
Splash resistant: IPX5
Charging time: Up to 2 hours
Product weight: ±43g
Product size: 17 x 16 x 5.5cm

4 Pairing

Touch and hold the raised touch button for 3 seconds to automatically enter pairing mode.

Ensure connecting mobile / device has Bluetooth turned on. Go to connections on device and search for 'ROKITSSG' and select to pair.

5 Multi-Function Button Guide

Turn on	Touch and hold the raised touch button for 3 secs.
Turn off	Touch and hold the raised touch button for 5 secs.
Answer the call	Double touch / click raised touch button.
Reject the call	Touch and hold raised touch button for 1.5 secs.
Hang up	Double touch / click raised touch button.
Play/Pause	Double touch / click raised touch button.
Next song	3 touches / clicks raised touch button.

6 Indicator Light Guide

Turn on	Blue light for 1s
Turn off	Blue light for 1s
Charging	Slow flashing blue light
Charge complete	Blue light stays off

7 Safety Rules

- Do not disassemble or modify the glasses for any reason, otherwise it may cause the glasses to malfunction or burn out. This is not covered by the warranty.
- Loud volume can cause hearing damage, please adjust to the appropriate volume when using the device.
- Do not use the device during thunderstorms, as thunderstorms may cause the equipment to malfunction and increase the risk of electric shock.

8 Note

- Please put the glasses in the correct position when charging.
- If the battery is not properly replaced, there is a danger of explosion and it can only be replaced with a battery of the same type. In the case where you need to replace the battery, it is recommended you return the product to the supplier for battery replacement.
- The battery (battery pack or combination battery) must not be exposed to excessive heat such as sunlight or fire.

9 FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

* RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.