Yi Smart

4G LTE Security Camera

1. What's in the box



2. Get to know your camera





3. Getting started

1. Pairing your camera

Step 1
Connect the power adapter to an outlet and turn the switch on to activate the camera. The camera indicator will flash blue and you will hear "Beep–Beep".

Yi Smart APP Code

Step 2
Log into the Yi Smart App or Yi IoT App, you can tap the "+" sign to add your device. Then you can scan the camera's QR code with your phone or select the 4G connection.

Step 3
If you scan the camera's QR code with your phone, wait for the pairing.
If you select the 4G connection, then use the camera to scan the QR code that will be generated. , tap "Next Step", wait for the pairing.

Step 4
You will hear "Pairing is successful" and then the Yi Camera is ready to use.

Note: You must move your 4G device to a place with a better signal and connect.

2. Connect the camera to power

Option 1:

- Use the household electrical power to power the camera. As shown in Figure ①, plug the power cord into the camera's USB-C charging port, and then connect the other end to a household electrical outlet.

Note:

- The output specifications of the power converter must be 5V, 1A. If you need to use the camera, as shown in Figure ②, turn the camera switch to ON to start the camera.
- When using the camera for the first time, it is recommended to fully charge the battery before use. While charging, please ensure that the camera switch is turned OFF . It is recommended to charge the battery for more than 5 hours. (Normal charging time is about 5 ~ 8 hours)



- Option 2:
Use the solar panel to power the camera. As shown in Figure ③, insert the USB-C port of the solar panel power output cable into the camera's charging port to connect the camera to power.

Note: Please ensure that the solar panel is installed in a location where it can receive ample sunlight for a long period and is in normal working condition. If you need to use the camera,as shown in Figure ④, turn the camera switch to ON to start the camera.



3. Install the solar panel



Step 1:
Install the solar panel bracket base in the appropriate position as shown in the picture.

Step 2:
Install the solar panel bracket on the bracket base in the order shown in the picture, and tighten it.

Step 3:
Fix the solar panel on the bracket and adjust the angle of the solar panel.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

–Reorient or relocate the receiving antenna.
–Increase the separation between the equipment and receiver.
–Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
–Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20cm

ADVERTENCIA IC

Cet appareil contient des émetteurs / récepteurs exempt és de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :
(1) Cet appareil ne doit pas causer d'interférences.
(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm

V1.1

小蚁 xiaoyi.com

2025-04-02

2025-04-02
新建

印刷公差≤0.5mm
SCALE 1:1

切刀
压线
齿刀
开槽
半穿
粘合

审核人员
设计主管 ▶
产品经理 ▶
质量工程 ▶
认证工程 ▶
软件测试 ▶
部门总监 ▶

项目号 ▶ W022JP	项目名称 ▶ 小蚁2K低功耗太阳能球机	印刷颜色 ▶ K100	物料材质 ▶ 80g书写纸	图号 ▶
设计于 ▶ 庄红娜	物料名称 ▶ 说明书（国内版）	成品尺寸 ▶ 600×100mm（平面展开）	特种工艺 ▶ 风琴折	料号 ▶

通知人员
项目经理 ▶
采购经理 ▶