





2K Wireless Battery Camera


1. What's in the box



1x 2K Wireless Battery Camera




2x Solar Panel Camera Screw Kit




2x Solar Panel Bracket

2. Get to know your camera



Spot Light
IR LED
Lens
Motion Sensor (PIR)
Microphone




Reset Button
Support Mount Slot
TF Card Slot
USB-C Charging Port
Power Switch

3. Getting started

1. Pairing your camera

Step 1
Connect the power adapter to an outlet and turn the switch on to activate the camera. The camera indicator will flash blue and you will hear "Bleep-Bleep".

Note: To install a camera that was previously installed on a different network or if you change your password, you must reset your camera.



Yi Smart APP Code

Step 2
Log into the Yi Smart App, you can tap the "+" sign to select your device or scan the camera's QR code with your phone.

Step 3
Enter the password of the same Wi-Fi network that is connected to your phone, then use the 2K 9pin-Ti8 Outdoor Solar Camera to scan the QR code that will be generated.

Step 4
Tap "Next Step". You will hear "Pairing is successful" and then the 2K Pair-Ti8 Outdoor Solar Camera is ready to use.

Quick camera pairing
Note: Turn on the Bluetooth function of your mobile phone. After resetting the camera, it will scan for Bluetooth devices and pair them.



Note: The camera and mobile phone should be as close as possible within the coverage of the Wi-Fi signal during the pairing process.


2. Connect the camera to power

Option 1:

- Use the household electrical power to power the camera. As shown in Figure (1), plug the power cord into the camera's USB-C charging port, and then connect the other end to a household electrical outlet.

Note:

- The output specifications of the power converter must be 5V, 1A. If you need to use the camera, as shown in Figure (2), turn the camera switch to ON to start the camera.
- When using the camera for the first time, it is recommended to fully charge the battery before use. While charging, please ensure that the camera is turned OFF. It is recommended to charge the battery for 6 hours. (Normal use about 5 ~ 8 hours.)




Flip the switch Left


Option 2:

Use the solar panel to power the camera. As shown in Figure (3), insert the USB-C port of the solar panel power output cable into the camera's charging port to connect the camera to power.

Note: Please ensure that the solar panel is installed in a location where it can receive ample sunlight for a long period and is in normal working condition. If you need to use the camera as shown in Figure (4), turn the camera switch to ON to start the camera.



3. Install the solar panel



Step 1: Install the solar panel bracket base in the appropriate position as shown in the picture.

Step 2: Install the solar panel bracket on the bracket base in the order shown in the picture, and tighten it.

Step 3: Fix the solar panel on the bracket and adjust the angle of the solar panel.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The distance between user and products should be no less than 20cm

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2BQ-DP-WY211

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's a licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The distance between user and products should be no less than 20cm

ADVERTENCIA IC

Cet appareil contient des émetteurs / récepteurs exemptés de la licence conformes aux RSS / RSSI d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

La distance entre l'utilisateur et de produits ne devrait pas être inférieure à 20cm

V1.1

印刷公差≤0.5mm
SCALE 1:1

- 切刀

压线

齿刀

开槽

半穿

粘合
-

审核人员

- 设计主管 ▶
- 产品经理 ▶
- 质量工程 ▶
- 认证工程 ▶
- 软件测试 ▶
- 部门总监 ▶

通知人员

- 项目经理 ▶
- 采购经理 ▶

项目号 ▶ W107BP	项目名称 ▶ 2K Wireless Battery Camera	印刷颜色 ▶ K100	物料材质 ▶ 80g书写纸	图号 ▶	通知人员
设计于 ▶ 庄红娜	物料名称 ▶ 说明书（国内版）	成品尺寸 ▶ 600×100mm（平面展开）	特种工艺 ▶ 风琴折	料号 ▶	