




VCOROS VR2
INSTRUCTION MANUAL



1. On/Off button/Multi-function button/
Wireless status indicator (blue)

2. Volume up/Next song

3. Volume down/
Previous song

4. Speakerphone /
Charging port

5. Light button /
Light indicator (blue) /
Charging indicator (red)

6. RGB ambient light

7. Voice assistant button/
Voice assistant indicator (blue)

Important Notice:


Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Power on/off

Power on: Long press **【On/Off button】** for 3 seconds, hear the power on tone, LED light flash.

Power off: Long press **【On/Off button】** for 3 seconds, hear the shutdown tone, LED light off.


Switching voice broadcasting: power on without connecting wireless state, double-click **【On/Off button】**, switch to voice announcement.



Wireless connection

Wireless connection: long press **【On/Off button】** 3 seconds to turn on the phone, the phone opens the wireless, search and connect the blue tooth name "VR2".

Wireless indicator status: Before wireless is not connected, the blue indicator light is flashing fast; after wireless is connected, the wireless indicator light is flashing slowly; when the music is paused, the blue light is flashing slowly; when the music is playing, the blue light is on for a long time.



Telephone function

Switching automatic/manual answer: when not connected to wireless, double-click **【volume + button】** to switch manual answer/automatic answer.

Auto answer: wait 15 seconds for an incoming call and then answer it automatically.


Manual answer: Short press **【Multi-function button】** to answer the call.

Refuse to answer: Long press **【Multi-function button】** for 2 seconds to refuse to answer during an incoming call.

End call: short press **【Multi-function button】** to end the call.

End code replay: double press **【Multi-function button】** to replay the end code.


Cancel call: short press **【Multi-function button】** to cancel call when calling.



RGB light on/off/switching

Turn on/off the light: long press **【Lighting button】** to turn on/off the ambient light effect; default colorful light effect on the power-on, the blue LED light of the lighting key is on for a long time

Switching Lights: Short press **【Lighting button】** to cycle through the seven-color ambient lighting colors




Music function

Music play and pause: When the music is paused, short press **【Multi-function button】** to play the music; Short press **【Multi-function button】** to pause the music while it is playing.

Previous song/volume down: short press **【Volume-button】** while music is playing Switch to the previous song, long press **【Volume-button】** volume down.


Next song/volume up: short press **【Volume + button】** while music is playing Switch to the next song, long press **【Volume + button】** volume increase.



Charging function/voice assistant

Charging indicator status: red light long light when charging, full off (power on state, plug in the charger, the machine will automatically shut down)

AI voice assistant: under wireless connection, short press **【voice assistant button】** to wake up the voice assistant, the blue LED light will be on for a long time; short press again to exit the voice assistant, the blue LED light will be off.



Product List




VR2 Device*1



Speaker Microphone*1



Velcro Package*1



Type-C Charging Cable*1



Clip-on Base*1



Instruction manual*1

Caveat

1. Do not put the product into open flame to avoid explosion;
2. Do not disassemble the product to avoid damage to the product's electronic components;
3. Please do not close to sharp objects to cause damage to the product;
4. Please place it in a dry place if it is not used for a long time;
5. Before using the wireless device, please fully charge it first;
6. If the red light does not come on when charging, the voltage may be too low;
7. In order to extend the life of the built-in polymer battery, please charge the device at least once a month.

Instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.
- (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.