

Quick Start Guide

Smart Camera



Before using the product, please read this guide carefully and keep it properly.

Specification

Name	Smart Camera		
Model	LC2518		
Power	DC 5V=1A		
Working Environment	Working Temp	-5℃~45℃	Humidity: < 90%
	Storage Temp	-20℃~60℃	Humidity: < 95%

Packing List

* A partial list is for reference only, please refer to the actual packing list.



Camera



Magnetic iron piece



USB Cable



Bracket



Mounting tape



Screws Set




Positioning Sticker



Quick Start Guide

Appearance

- * Virtual graph. The cable interface of different devices may be different, and the appearance of the product is subject to the physical object.



- * Please remove the protective film before use to ensure optimal performance.

Power On and Start Up

Indicator status


Red light keeps on: the camera starts.

Green light slow flashing: waiting for network distribution, net disconnection.

Alternating red and green: connecting to net.


Red light slow flashing: the device is offline.

Green light keeps on: the camera is online.



Charging Instructions

- The device is partially charged upon delivery. Before first use, please open the silicone plug and use the power cable and adapter to fully charge the device. The battery is built-in; do not attempt to remove it.
- After charging, please firmly reseal the silicone plug into the power port to prevent moisture or water from entering.



- * To ensure safety, do not charge the device in environments with extreme high or low temperatures, or high humidity.



Download and install the APP

Open the mobile app store to search for "xpai", or scan the QR code below, download the app and complete the installation.



Add camera

1. Insert a SIM card into the device to enable functionality.
2. Turn on the power switch. Wait for the device to boot up and connect to the network. The indicator light will turn solid green once connected.
3. Launch the APP -> Register new account->Follow the instruction and finish the registration
4. Log in the APP -> Click "Add a device " -> Follow the voice prompt to add the camera




* The illustration is for reference only, please refer to the actual APP interface.

Install the camera

Insert MicroSD Card

Please make sure to power off the camera first, then find the MicroSD card slot on the side of the camera and insert the contact side of the MicroSD card into the card slot.

Note: You must cut off the power of the camera before installing or removing the MicroSD memory card.




Three installation methods of the camera

- Desktop
- Ceiling(via mounting sticker)
- Wall(via mounting sticker)

Install the camera

Wall/Ceiling Mounting Steps

1. Take out the camera bracket. Check the orientation of the bracket thread, then tighten the central knob.
2. Adhere the positioning sticker to the desired installation location. Drill holes at the marked positions on the sticker.
3. Insert the plastic wall anchors into the drilled holes. Pass the screws through the bracket's mounting holes and tighten them into the anchors.
4. Screw the camera onto the bracket thread to secure it.



Precautions for Installation

- * Ensure the installation wall can bear 3 times the total weight of the camera

Warning

- Please use this product under the premise of complying with the electrical safety regulations of the country and applicable regions.
- Please make sure the product is firmly installed on the wall or ceiling

Notes

- If the product does not work properly, please contact the service center. Do not disassemble or modify the product yourself.
- Keep the product away from electromagnetic interference sites to avoid damage
- Do not touch the heat dissipation parts of the product with your hands to avoid burns.
- Please keep the product away from liquid environment.
- The product needs to be stored in a dry and non-corrosive gas environment.
- Please use this product in the specified temperature and humid environment.
- Do not point the lens directly at strong light, otherwise it will damage the image sensor.
- Please ventilate around the product to avoid heat buildup.
- Do not touch the image sensor directly. If you need to clean it, please slightly dampen a soft clean cloth with alcohol and gently wipe off the dust.
- Products connected to the Internet may face network security issues, please strengthen the protection of personal information, When you find that there are network security risks in the product, please contact us in time.
- Please keep your username and password safe
- Please keep all the original packaging materials of the product, and you need to return it to the manufacturer for processing when there is a problem.

Warranty

(Reserved by the user, and not reissued if lost)

Name		Tel	
Address			
Postal Code			
Model		SN	
Production Date		Purchase Date	
Purchase Price		Invoice No.	
Shop Name			

The host is guaranteed within 1 year from the purchase date:

1. In case of any failure caused by the product itself during the warranty period, please contact our after-sales service;
2. Please send back or fax the completed warranty card in time after purchase, so that you can enjoy the repair and replacement for free, otherwise it will not be accepted;
3. The information on your warranty card will be used for repair, please fill it in carefully;
4. The following cases are covered by paid warranty:
 - Failure caused by man-made reasons;
 - Failure caused by improper use environment not meeting the requirements of the product;
 - Product damage caused by force majeure;
 - There is no product serial number or warranty card, or the product serial number and label is indistinguishable or damaged;
 - The warranty period has expired.

* Within the scope permitted by law, the interpretation right of the above terms belongs to Shenzhen Xiaopai Technology Co.,Ltd.

WEEE Directive



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 7.9 inches between the radiator & your body. This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.



Manufacturer

Shenzhen Xiaopai Technology Co.,Ltd.

Address: Unit A 8F 806, Skyworth bldg, Gaoxin Ave. 1.S.,
Nanshan District, Shenzhen, China

Email: service@xpaihome.com

Website: <https://xpaihome.com/pages/smart-help-center>

SKYWORTH 创维

- 料号(Part No.): 料号待申请
 成品尺寸(Folded Size): 78*78 mm
 封面封底(Cover&Back): 无矿物油(Mineral Oil Free)
 印刷颜色(Print Color): 黑色(Black)
 材质(Material): 80g书底(80g Writing Paper)
 内页(Inside Page):
 印刷颜色(Print Color): 黑色(Black)
 材质(Material): 80g书底(80g Writing Paper)
 装订方式(Binding Style): 骑马钉(Saddle stitch)



中国强制性认证产品认证标志
RoHS directive requirements



欧盟化学品注册、评估、限制及禁止法规
REACH directive requirements

技术要求(NOTES):

1. 印刷材料处理工艺均应符合REACH法规及最新RoHS指令要求。
(Please materials and the corresponding post processing must be accord with REACH regulations and RoHS directive requirements.)

■ 厂家/Manufacturer: VolonFawenziJiahu

■ 设计/Designer: Xiang

■ 日期/Date: 2025/1/28

■ 认证签字/Certification Audit:

■ 审核/Audit: