


1 0 5 G 双 铜 单 色 双面印 , 对折
80x110mm

Installation Instruction

Connect the USB interface of the speaker to any available USB port on your computer,laptop or TV.

Note: The audio source of the connected device is the main volume control. It is recommended to set the device's volume to 70% and adjust the speaker's volume using the knob on the speaker.

Volume Control Knob



The Volume control knob is used to turn the speaker on/off and up/down the volume as needed.

Power Off: Rotate the knob counterclockwise until you hear a "click" sound.

Power On: Rotate the knob clockwise, and you will hear a "click" sound and see the RGB lights illuminate.

Volume Control: Rotate the knob clockwise to increase the volume; rotate the knob counterclockwise to decrease the volume.

Zero-volume zone: the zero-volume zone is implemented so that you can quickly mute the speaker without having to turn it off. Simply move the volume knob into the


KASOHQEE

USER MANUAL
For Computer Speaker
MODEL:BT805

Package Contents

- . BT805 Speaker 1PC
- . User's Guide 1PC

Hardware Review



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC 's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

American agent information :
Company Name: GLOCERTS TECHNOLOGY INC
FRN: 0036339737
Contact Name: Huiying Fan
Address: 19784 SUNKISSED RIDGE DR, RIVERSIDE, CA 92507
Telephone No: (626) 588-8039
Email: huiying.fan@glocerts.com

zero-volume zone at any time to mute the speaker and keep the RGB going.

RGB Touch-sensitive Buttons

This speaker features 12 different RGB lighting effects, including static, dynamic. Simply tap the RGB touch-sensitive button to select your preferred lighting effect, including turning off the RGB lighting.

Switch between USB mode and Bluetooth mode

Tap the touch button to switch freely between USB and Bluetooth modes. You will hear the corresponding voice prompt.

USB mode: The audio source comes from the connected USB device.

Bluetooth mode: The audio source comes from any connected Bluetooth device.

Default mode: USB mode.

BASS Adjustment

There are 4 different BASS levels available. Adjust it according to your favourite for different use, gaming, movies or music as below:

RGB Touch Button: Press and hold for 2 seconds to increase the bass level, and you will hear the corresponding voice prompt.

Mode Touch Button: Press and hold for 2 seconds to decrease the bass level, and you will hear the corresponding voice prompt.

Default bass: Bass Level 2.

Connecting to A Bluetooth Enabled Device

To connect to a Bluetooth device, simply select "Bluetooth Mode" and search for the device name " BT805 " to pair and connect. You will hear a corresponding voice prompt whether the connection is successful or not. If it fails, please try pairing and connecting again.

Connection System Requirements

- . The device has an available USB port
- . Windows 7 or above
- . Mac OS or above

Specifications

Speaker Size	ø52"×2
Output Power	5W×2
Frequency Response	100Hz-20kHz
Sensitivity	85dB
SNR	≥ 75dB
Wireless Version	5.4
Input Interface	USB
Power Input (USBA)	5V
Unit Size	400x73x75mm
Weight	770g