


说明书尺寸: 70*90MM

PANTONE 2297C PANTONE Black 3C

OMNIBAR



5000mAh

15W MAGNETIC WIRELESS POWER BANK USER GUIDE

GUÍA DEL USUARIO DEL BANCO DE ENERGÍA INALÁMBRICO

MAGNÉTICO DE 15 W

PBK5KA

IMPORTANT SAFETY INSTRUCTIONS

Before using this power bank, please read all warnings and instructions carefully. To avoid risks such as explosions, fires, electric shock, or personal injury, strictly adhere to these guidelines and those from the manufacturers of any equipment you use with the power bank. For more information, please visit www.omnibar.com.

WARNINGS

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR PERSONAL INJURY.

When using this power bank, basic safety precautions should always be followed. Please read all the instructions before using the product.

- KEEP AWAY FROM CHILDREN: Don't allow children to operate or play with the power bank.
- ALWAYS KEEP DRY: Protect the power bank from rain, snow, and any form of liquid. Do not charge or use the power bank if it's exposed to liquid. If internal components get wet, your power bank MUST be disposed of. Isolate it in a fire-safe location before disposal. Failure to comply with these guidelines could cause serious damage, injury, or worse. Contact your local fire department if you see any sparks or smell burning.
- FLAME-FREE ZONE: Keep smoking, sparks, and flames away from the power bank.
- AVOID STATIC: Do not expose the device to strong electrostatic or electromagnetic interference.
- HANDLE GENTLY: Avoid dropping or severe impacts to ensure the power bank works properly.
- NO TAMPERING: Do not attempt to open the power bank casing. Never allow foreign objects to enter into inputs, outputs or ventilation holes.
- NO BATTERY REPLACEMENT: Do not try to replace or alter the power bank battery. It is rechargeable but not replaceable.
- PROFESSIONAL SERVICING ONLY: Only a qualified repair person should service the device using the correct parts to ensure continued safety.

TECHNICAL SPECIFICATIONS

MODEL: PBK5KA

CAPACITY: 5000mAh

LITHIUM BATTERY ENERGY: 5,000mAh 3.7Vdc/18.5Wh

RATED CAPACITY: 2,700mAh (5V=3A)

USB-C INPUT: 5V=3A 9V=2A (18W Max)

USB-C OUTPUT: 5V=3A 9V=2.22A 12V=1.67A (20W Max)


WIRELESS OUTPUT: 5W / 7.5W / 10W / 15W

MATERIALS: Fireproof PC+ABS Plastic


SIZE: 4.09x2.71x0.52in(104*68.9*13.3mm)

WEIGHT: 4.62oz(131g)


PRODUCT OVERVIEW




Recharging Power Bank



Charging Your Device Wirelessly



Charging Your Device via USB-C Cable



*Remove the case for wireless charging if you have.

OPERATING GUIDELINES

- AVOID WATER: When traveling, take care to keep it dry; avoid rain, snow and any water. It's also best to keep it cool and shaded from direct sunlight.
- KEEP IT COOL: Give your power bank some breathing room. Don't stack things on it or block its ventilation while in use or in storage.
- COOL DOWN BEFORE CHARGING: After a full discharge, let your power bank chill for 1-2 hours before recharging. It's like letting it take a nap and prolongs the life of your battery!
- RECHARGE REGULARLY: To preserve the battery, use and recharge the power bank at least once every 3 months.
- ONE PORT, ONE DEVICE: Don't overload it! Only power one device per port or socket on the power bank. Never connect a multi-outlet power strip, surge protector or extension cord.
- USE CERTIFIED ACCESSORIES ONLY: Ensure all accessories, attachments and appliances used with the power bank are safety certified to avoid potential hazards.
- PULL THE PLUG: When disconnecting, pull the plug-not the cord. It's less likely to break into an accidental tug-of-war, damaging your cables or power bank.
- INSPECT CORDS: Ensure that cords, plugs, and cables are not damaged before using with the power bank.
- CHECK FOR DAMAGE: If you spot any cracks or damage, stop using the power bank immediately. Avoid contact with any leaked liquid. The battery acid can be irritating or worse. If it touches skin or eyes, flush with water and seek medical attention.
- AVOID USING DAMAGED UNITS: Do not operate the power bank or any connected devices if they are damaged or altered.

OPERATION INSTRUCTIONS

Checking Battery Status:

Press the button once to check remaining battery power. The indicator light stays on for about 30 seconds, then turns off automatically.

Charging via Cable:

When connecting the power bank's charging port to your device, it usually starts outputting power automatically. If your phone isn't compatible with this auto-charging, press the power button once to start charging. After pressing, the output mode remains active for 30 seconds. If no device is connected during this period, the mode shuts down automatically.

When Charging Wirelessly:

This product features an auto-wake function for wireless charging. Simply place your phone on the charger and it will start charging automatically. However, due to compatibility issues, some phones require you to press the button to activate the wireless charging function. Press the button once and the battery indicator will light up to show that wireless charging is turned on. Then you can place your device on it. If no device is placed on the charger within 30 seconds, the wireless charging function will automatically turn off.

WIRELESS CHARGING TIPS

To charge your phone wirelessly, place it on the charging area as shown in the picture. For optimal performance, keep the distance between your phone and the power bank within 0.16in. If exceeded, charging stops, and you'll need to reposition your phone.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and radiates radio frequency energy and, if it's not installed or used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by switching the equipment off and on again, the user is encouraged to try correcting the interference using one or more of the following methods: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and the receiver. (3) Connect the equipment to an outlet on a different circuit from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for assistance.

Omnibar is a registered trademark of Omnibar LLC. All the images and text in this user guide are the copyright of Omnibar. The photos and illustrations in this guide may differ from the actual product.

WEEE INFORMATION

 Disposal and recycling information: This product and battery should not be disposed of as household waste or be thrown into the fire. When disposing of the product and battery, please handle the battery according to the local environmental laws to avoid explosion.

Only suitable for safe use in non-tropical climates.

Made in China



FCC radiation exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 0 cm surrounding the device and 0cm above the top surface of the device must be respected.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Antes de usar este banco de energía, lea detenidamente todas las advertencias e instrucciones. Para evitar riesgos como explosiones, incendios, descargas eléctricas o lesiones personales, siga estrictamente estas pautas y las de los fabricantes de cualquier equipo que utilice con el banco de energía. Para obtener más información, visite www.omnibar.com.

ADVERTENCIAS

INSTRUCCIONES RELATIVAS AL RIESGO DE INCENDIO, DESCARGA ELÉCTRICA O LESIONES PERSONALES.

Al utilizar esta batería externa, siga siempre las precauciones básicas de seguridad. Lea todas las instrucciones antes de usar el producto:

- MANTENER FUERA DEL ALCANCE DE LOS NIÑOS: No permita que los niños operen ni jueguen con la batería externa.
- MANTENER SIEMPRE SECO: Proteja el banco de energía del agua lluvia, nieve y cualquier tipo de líquido. No cargues ni uses el banco de energía si está expuesto a líquido. Si los componentes internos se mojan, DEBES desechar el banco de energía. Aísla el dispositivo en un lugar a salvo del fuego antes de desecharlo. No cumplir con estas pautas podría causar daños graves, lesiones o consecuencias peores. Contacta con el cuerpo de bomberos local si ves chispas o hueles a humo de quemado.
- ZONA LIBRE DE LLAMAS: Mantenga el humo, las chispas y las llamas lejos de la batería externa.
- EVITE LA ESTÁTICA: No exponga el dispositivo a interferencias electrostáticas o electromagnéticas fuertes.
- MANIPULAR CON CUIDADO: Evite caídas o impactos fuertes para garantizar el correcto funcionamiento de la batería externa.
- NO MANIPULAR: No intente abrir la carcasa de la batería externa. Nunca permita que objetos extraños entren en las entradas, salidas o orificios de ventilación. NO DE.
- REEMPLAZAN LAS BATERÍAS: No intente reemplazar ni alterar la batería del banco de energía. Es recargable, pero no reemplazable.
- SERVICIO PROFESIONAL SOLAMENTE: Solo un técnico cualificado debe realizar el mantenimiento del dispositivo utilizando las piezas correctas para garantizar su seguridad.

ESPECIFICACIONES TÉCNICAS

MODELO: PBK5KA

CAPACIDAD: 5,000mAh

ENERGÍA DE BATERÍA DE LITIO: 5,000mAh 3.7Vdc/18.5Wh

CAPACIDAD NOMINAL: 2,700mAh (5V=3A)

ENTRADA USB-C: 5V=3A 9V=2A (18W Max)

SALIDA USB-C: 5V=3A 9V=2.22A 12V=1.67A (20W Max)

SALIDA INALÁMBRICA: 5W / 7.5W / 10W / 15W

MATERIALES: Plástico PC + ABS ignífugo


TAMAÑO: 4.09x2.71x0.52in(104*68.9*13.3mm)

PESO: 4.62oz(131g)


DESCRIPCIÓN GENERAL DEL PRODUCTO



Recarga Del Banco De Energía



Cargando Tu Dispositivo Inalámbtricamente



Cargando Tu Dispositivo A Través De Un Cable USB-C



*Retira la carcasa para la carga inalámbrica si la tienes.

DIRECTRICES DE FUNCIONAMIENTO

- EVITA EL AGUA: Cuando viajes, manténlo seco; evita la lluvia, la nieve y el agua. También es recomendable mantenerlo fresco y protegido de la luz solar directa.
- MANTÉNLO FRESCO: Dale espacio a tu batería externa. No apiles objetos encima ni bloques su ventilación mientras la uses o la guardes.
- ENFRIÉBELLO ANTES DE CARGARLO: Después de una descarga completa, deja que tu batería externa se enfríe durante 1 o 2 horas antes de recargarla. ¡Ea como dejarla descansar y prolonga la vida útil de la batería!
- RECARGA REGULARMENTE: Para conservar la batería, usa y recarga la batería externa al menos una vez cada 3 meses.
- UN PUERTO, UN DISPOSITIVO: ¡No la sobrecargues! Alimenta solo un dispositivo por puerto o toma de la batería externa. Nunca conectes una regleta multimedio, un protector de sobretensión ni un alargador.
- UTILICE SOLO ACCESORIOS CERTIFICADOS: Asegúrese de que todos los accesorios, complementos y aparatos utilizados con la batería externa cuenten con certificación de seguridad para evitar posibles riesgos.
- DESCONECTE EL ENCHUFE: Al desconectarlo, tire del enchufe, no del cable. Es menos probable que se rompa accidentalmente y dañe los cables o la batería externa.
- INSPECCIONE LOS CABLES: Antes de usar con el banco de energía, asegúrese de que los cables, enchufes y cordones no estén dañados.
- CONFIRME SI HAY DAÑOS: Si detecta grietas o daños, deje de usar la batería externa inmediatamente. Evite el contacto con cualquier líquido derramado. El ácido de la batería puede ser irritante o incluso peor. Si entra en contacto con la piel o los ojos, enjuague con agua y busque atención médica.
- EVITE EL USO DE UNIDADES DAÑADAS: No utilice la batería externa ni ningún dispositivo conectado si están dañados o alterados.

INSTRUCCIONES DE FUNCIONAMIENTO

Verificación del Estado de la Batería: Presiona el botón una vez para comprobar la energía restante de la batería. La luz indicadora se mantiene encendida durante unos 30 segundos y luego se apaga automáticamente.

Carga a Través de Cable: Al conectar el puerto de carga del banco de energía a tu dispositivo, generalmente comenzará a suministrar energía automáticamente. Si tu teléfono no es compatible con esta carga automática, presiona el botón de encendido una vez para iniciar la carga. Después de presionar, el modo de salida permanece activo durante 30 segundos. Si no hay ningún dispositivo conectado durante este período, el modo se apaga automáticamente.

Carga inalámbrica: Al cargar de forma inalámbrica: Este producto tiene una función de activación automática para la carga inalámbrica. Simplemente coloca tu teléfono en el cargador y comenzará a cargar automáticamente. Sin embargo, debido a problemas de compatibilidad, algunos teléfonos requieren que pulses el botón para activar la función de carga inalámbrica. Presiona el botón una vez y el indicador de batería se iluminará para mostrar que la carga inalámbrica está activada. Luego puedes colocar tu dispositivo en el cargador. Si no se coloca ningún dispositivo en el cargador dentro de 30 segundos, la función de carga inalámbrica se apagará automáticamente.

CONSEJOS DE CARGA INALÁMBRICA

Para cargar tu teléfono de forma inalámbrica, colócalo en el área de carga tal como se muestra en la imagen. Para un rendimiento óptimo, mantén la distancia entre tu teléfono y el banco de energía dentro de los 0.16in. Si se excede esta distancia, la carga se detendrá y deberás reposicionar tu teléfono.

DECLARACIÓN DE CUMPLIMIENTO DE LA FCC

Este dispositivo cumple con la Parte 15 de las Reglas de la FCC. El funcionamiento está sujeto a las siguientes dos condiciones: (1) Este dispositivo no debe causar interferencia dañina. (2) Este dispositivo debe aceptar cualquier interferencia recibida, incluyendo la interferencia que pueda causar un funcionamiento no deseado.

ADVERTENCIA: Los cambios o modificaciones no expresamente aprobados por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.

NOTA: Este equipo ha sido probado y se ha verificado que cumple con los límites para un dispositivo digital de Clase B, de conformidad con la Parte 15 de las Reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra la interferencia dañina en una instalación residencial. Este equipo genera, utiliza y irradia energía de radiofrecuencia y, si no se instala o utiliza de acuerdo con las instrucciones, puede causar interferencia dañina en las comunicaciones por radio. Sin embargo, no hay garantía de que no ocurra interferencia en una instalación particular. Si este equipo causa interferencia dañina en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo de nuevo el equipo, se anima al usuario a intentar corregir la interferencia utilizando uno o más de los siguientes métodos: (1) Reorientar o reubicar la antena receptora. (2) Aumentar la separación entre el equipo y el receptor. (3) Conectar el equipo a una toma de corriente en un circuito diferente al del receptor. (4) Consultar con el distribuidor o un técnico experimentado en radio / TV para obtener asistencia.

Omnibar es una marca registrada de Omnibar LLC. Todas las imágenes y el texto de esta guía del usuario son propiedad intelectual de Omnibar. Las fotos e ilustraciones de esta guía pueden diferir del producto real.

INFORMACIÓN SOBRE RAEE

 Información sobre eliminación y reciclaje: Este producto y su batería no deben desecharse como residuos domésticos ni arrojarse al fuego. Al desechar el producto y la batería, manipule la batería de acuerdo con las leyes ambientales locales para evitar explosiones.

Advertencia: No lo desarme, aplástelo ni lo exponga al fuego ni a altas temperaturas. Si se hincha considerablemente, suspnda su uso inmediatamente. Nunca lo use después de sumergirlo en agua.

Solo apto para uso seguro en climas no tropicales.

Fabricado en China



WARRANTY

This device has a **3-year warranty**, covering 36 months from the date of purchase (the "warranty period"). During the warranty period, if a device failure occurs under normal use due to manufacturing defect, Omnibar will repair or replace the device. The company reserves the right to verify that proper use and maintenance guidelines were followed.

CONDITIONS THAT VOID THIS WARRANTY:

- Unauthorized repair, disassembly, or alteration of any kind.
- Evidence of abnormal usage or misuse.
- Damage from dropping, abuse, or negligence.
- Damages caused by failure to follow the operating instructions.
- Tampering with the product's original serial number label and other similar markings.
- Fake products, including those indicated by a missing product serial number or nonconformity between the product model and serial number.
- Improper storage, such as long-term exposure to humidity or temperatures outside the parameters specified in the technical specifications of this user's guide.
- Expiration of the product warranty.

FORCE MAJEURE: Omnibar shall not be liable for any failure or delay in performing any of its obligations under this warranty if such failure or delay is caused by or results from events beyond its reasonable control, including, but not limited to:

- Natural disasters (e.g., earthquakes, floods, hurricanes, wildfires)
- Acts of God
- War, invasion, or acts of terrorism
- Civil unrest, riots, or strikes
- Government actions, regulations, or restrictions
- Epidemics, pandemics, or quarantines
- Power outages or electrical failures
- Supply chain disruptions

The above information shall be filled in by the buyer

 support@omnibar.com

 www.omnibar.com

QC PASS 08