


尺寸：70mm×100mm






wg-3b wireless charger



User Manual

English




To Remove:
1. Press and hold the button on the left side of the plug.
2. While holding the button, turn the plug to the right and pull it out.

Product specification


Supported Devices:

Up to 3 devices simultaneously (phones or earphones with wireless charging support)
INPUT:DC12V $\equiv$ 3A OUTPUT:15W*1,10W*2

Usage Method



Note: Please use a standard AC to DC power adapter with an output of 12V/3A (36W).
Using a charger with incorrect specifications may cause charging instability or damage.



Please position your phone or headphones precisely at the correct position of the charging coil to guarantee normal charging.

Tip:

The optimal charging position is when the rear camera of your phone is aligned with the top edge of the wireless charger.

Troubleshooting

If the troubleshooting steps mentioned below haven't solved your issue, please email us at info@zealsound.com for further assistance.

1. Wireless Charger Fails to Charge Phone / Charging Is Unstable / Charging Is Slow

① Check Compatibility

Make sure your phone model supports wireless charging. Wireless chargers only work with phones that have wireless charging capability. If your phone does not support wireless charging, it will not charge using this wireless charger. Please try testing with another phone that supports wireless charging.

② Align Phone Properly

Place your phone correctly in the center of the charging coil. Misalignment may prevent the phone from charging or cause unstable charging.

③ Remove Phone Case if Needed

If your phone case does not support MagSafe functionality, please remove it, as it may interfere with wireless charging.

2. Wireless Charger Fails to Charge AirPods

① Check Compatibility

This wireless charger only supports AirPods models with a wireless charging case.

AirPods 1 and AirPods 2 with the standard (non-wireless) charging case are not compatible.

② Ensure Proper Alignment

Make sure the AirPods charging case is correctly positioned on the charging coil to ensure proper charging.

3. Why does the charging indicator light turn off a few seconds after placing the earphones (with wireless charging support) on the wireless charger?

This is normal behavior.

When the charging case is properly placed on a wireless charger, the indicator light will turn on for 2—5 seconds to confirm that charging has started, and then automatically turn off.

This is a power-saving feature designed to reduce energy consumption and avoid unnecessary light disturbance. Charging will continue even after the light turns off, as long as the case is correctly aligned on the charging pad.

4. Why doesn't the wireless charger work with my smartwatch?

This wireless charger is not compatible with smartwatches.

Warranty

This product comes with a 12-month warranty. However, the warranty will be void if the equipment is tampered with, misused, mishandled, improperly adjusted, or subjected to excessive wear and tear. If you require further assistance or have any questions, please feel free to contact our dedicated after-sales service team at info@zealsound.com. We are committed to actively working with you to find a suitable solution for any issues you may encounter.

⚠ This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device meets the FCC requirements for RF exposure. The device is designed for normal indoor use and complies with applicable FCC exposure limits.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body



MADE IN CHINA

