Security Camera

Quick Operation Manual

01.....Interface
02.....Interface/Download App
03.....APP Account Registration
04-06.....Add Camera
07.....More Connection Methods
08.....App Function Introduction
09.....System Setting /PC Software
10.....Night Vision Setting
11.....How to Monitoring Function
12.....How To Share The Device
13.....How To Setup Image Flipping Light Anti-Interference
14.....FCC Warning Statement
15.....Warranty Card

Interface

01

Download The APP

Scan the QR code download the APP

Or Search(O-KAM Pro) In App Store or Google Play

O-KAM Pro

02

APP Account Registration

1.Click "register now" on the login interface-select the address area-enter your email-get the verification code.

2.After entering the verification code, it will automatically enter the password setting interface,set the password, and click Finish;



03

Add Camera

1:

Click "+ Add" or

Click "⊕" in the upper right corner



2:

On the QR code scanning interface ,Click Wifi/4G camera

04

3:

Confirm that the blue light

and enters the state of waiting for network configuration



4:

Select your router and enter your password "Next"

05



5:

Point the phone screen directly in front of the camera lens.The distance between the two is 10-20CM.Try not to shake the phone druing the process.

Then you will hear a "Beep " and the connection is successful.

6:

And click " Bind Now "

IF prompted connection failed:

1:Is the wireless password correct?

2:Is the camera connected to the

3:Reset Setting and connect again

4:Long press for 2 seconds to restore settings

06

More Connection Methods

Hotspot configuration 1:

Select the hotspot mode, Click to Connect, Select the WiFi product with @ (as shown in the figure), Click Connect, and after successful connection, Return to the O-KAM interface.

2:

Open the video, click on "Connect the device to the internet now", select WiFi signal (only supports 2.4G), and enter the password. Alternatively, click on Settings select 'Device Settings', select' WI-FI Netwrok ', connect the nearest router network signal (only supports 2.4G), enter a password, and a prompt will appear' Wireless connection in progress, please wait, wireless connection succeeded 'Confirm



07

App Function Introduction



1:Switch the size of the screen

2: Add Device

3: Do not Disturb Mode

4: Share

5: PlayBack

6:System Settings

1:Cloud Storage Store

2: System Settings

3: HD/SD/Auto

4: Sound

5: Intercom

6:Full Screen

7:Night Vision Setting

8: PTZ Correction

9: Alarm

10: Screenshot

11:Record

12:Motion Detection

08

System Settiings

1:Cloud Storage Store

2: Notification Settins

3: Device Settings

Device name/Delete Device

4: Device Health

5: Monitoring Function

Humanoid Zoom Tracking

Human Frame

Person Tracking

6:AI Smart Service

7:TF Card Settings

Up to 256G

8: Share

9: Help

Computer Software

File Name: SuperIPCam-OKAM

Download Link:

https://video3.3388903.com/download/O-KAM.zip

09

Night Vision Setting

- Black and white night Vision
- Full color night vision:Color video at any time
- Smart Night vision:Default



10

How to Monitoring Function

Enter the system settings" ⊕ "-Monitoring Function

- Motion Detection:Human Detection
- Huma Frame:ON/OFF
- Person Tracking:ON/OFF
- Activity Zone:Custom area
- Detection Schedule:Setting Detection Schedule





11

How to Share The Device

Enter the system settings" ⊕ "-Share;

Sharing Methodd:Use another accout to scan and share the QR code to add a camera;

Open permission of Device sharing, the person being shared can set the function of the device

If the permission is turned off, you can only watch the video, and cannot set the function.

12

How To Setup Image Flipping And Light Anti-Interference

Enter the system settings" ⊕ "-Device Settings-Video Management



13

How to Delete Device

Enter the system settings" ⊕ "-Device Settings;

Note:If you change the mobile phone connection or move the device to a new environment, please delete the old mobile device, press and hold the device for 5-10 seconds to restore the factory settings.

14

How to Setting ONVIF/Rtsp

Rtsp:

Main code stream

Rtsp://192.168.xx.xx:10555/tcp/av0_0

Subcode stream

Rtsp://192.168.xx.xx:10555/tcp/av0_1

Onvif Port:10080

Open ONVIF method: Settings - ⊕ Device Settings

Plaintext Password settings -Enable clear text password

Setting password (Must)



15

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

..Reorient or relocate the receiving antenna.

.. Increase the separation between the equipment and receiver.

.. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

..Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.RF Exposure Statement To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

16

Warranty Card

User name: _____

Address: _____

Telephone: _____

Fax: _____

Post code: _____

E-mail: _____

Product model (Model): _____

Product Number (S/N): _____

Production Date: _____

Purchase Date: _____

If you have other requirements, please fill in below:

_____

_____

Dealer: _____ Telephone: _____

Distribution unit: (seal)

QUALIFIED CERTIFICATE

QC: PASS