

Instructions for use:

1. Before use, please rinse with water into shower gel and dry immediately;
2. You can suck this product, or stimulate the chest with the product, and you can also use the product to insert the genitals and anus to get pleasure;
3. You can turn on different vibration frequencies according to your own needs;
4. After use, please rinse with water or shower gel, then dry and store in a cool place, pay attentionNeed to stay away from minors.

Remote control power supply instructions:

1. To keep the remote control running normally, you need a 27A12V battery.

If the battery fails, replace it with a new onePool, install the battery pay attention to the correct placement of the positive and negative poles, if not used for a long time, please turn off the power after the battery in time.

2. The battery used in this remote control is a non-rechargeable battery which cannot be charged, different types of batteries or new and old Do not mix batteries. The battery should not be exposed to such as sunlight fire or similar high temperatures excessive heat and moisture environment.

Product power supply instructions:

1. Link the USB cable to a USB power adapter (not included) or USB port you can use anyUSB power adapter for charging.
2. It takes about 1.5-3 hours to fully charge, and the specific charging is decided according to the remaining power inside the productTime.
3. The use time of this product after full charge is: 45-90 minutes, the specific use time depends on the choice of choice Frequency mode, the greater the vibration frequency, the faster the power consumption.
4. Before disposal, the battery must be removed from the product, and the product must not disconnect the power before removing the battery Source, batteries need to be disposed of safely and properly and environmentally friendly.

Care and Maintenance:

1. Wash and dry with neutral soap or water before and after each use of the product away from extreme high or low temperatures Environment.
2. Please store this product in a cool, ventilated and dry place to ensure that the product is protected from direct sunlight, high temperature and heavy pressure Humid environment.

Note the instructions:

1. This product is only suitable for adults, non-contraceptives, please keep away from minors.
2. During use, do not exert excessive force and pay attention to avoid injury.
3. Do not mix this product with others, if you feel uncomfortable during use, please stop using this product immediately.
4. It is necessary to check the product regularly for damage, if it is found that it is damaged, please stop using it immediately.
5. The device has a heating surface, which must be paid attention to when using it by people who are not sensitive to heat.



Product Description



Key operation: Short press to turn on/change frequency, long press to turn off


- 1 Vibration frequency modulation key
- 2 Turn on/retract frequency modulation key
- 3 Warm button

(Note: The three buttons on the remote control are independently controlled. Short press to turn it on, FM, and long press to turn it off for 3 seconds)

Operation steps:



- 1、receiving the product Fully charge the product first.



- 2、When the product is fully charged Long press the penis to turn on the key 3 seconds on/off.

1. Vibration key: Short press to activate the vibration frequency modulation function, long press for 3 seconds to deactivate the function.

2. Key on: Short press to turn on the telescopic/frequency modulation function, long press for 3 seconds to turn off the function.

3. Heating button: Short press to turn on heating/long press for 3 seconds to turn off heating function

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction