



EN

Programmable tire pressure sensor

TPMS TS7000

Quick Start Guide

iCarzone Inc.
All Rights Reserved
www.icarzone.com

1. Safety Instructions

Please read this manual carefully before using the product, be familiar with the structure of the product and master the installation method of the product. Before installation, please confirm that the product accessories are complete, the product can work normally, and there is no abnormal appearance and structure. During the installation process, the company shall strictly abide by the maintenance operation specifications and use professional maintenance tools. Otherwise, the company will not be responsible for any problems caused by the customer's illegal operation. If there is any problem in the process of using the product, it must be replaced or stopped immediately and tested by professional maintenance personnel or after-sales service. After installing the product, be sure to re-measure the dynamic balance of the tire to eliminate safety risks.

2. Parameters:



Product Model: TPMS TS7000
Storage temperature: $-10^{\circ}\text{C}\sim 50^{\circ}\text{C}$
Operating temperature: $-40^{\circ}\text{C}\sim 125^{\circ}\text{C}$
Pressure monitoring range: 0-900Kpa
Maximum transmit power: $\leq -10.3\text{dBm}$
Battery life: 3-5years
Frequency: 433.92MHz & 315MHz(For United States)
Pressure accuracy: $\pm 5\text{Kpa}$
Temperature accuracy: $\pm 3^{\circ}\text{C}$
Weight: 30.9g (With valve)
Dimensions: approx.73mm*48mm*20mm

3.Sensor Component diagram :





4. Installation Operation Steps :

Step 1:
Please remove the tire cap.



Step 2:
Then install the tire sensor.

Step 3:
Inflate the tires.



Step 4:
Please put on the
valve cover.

Step 5:
Test balance.



Step 6:
Adjust balance.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.