

QUICK START GUIDE


Wireless IP Camera



1 APP Installation

1. Download the APP

- Download the app from the App Store(IOS devices) or Google Play (Android devices).



- Scan the QR code below to download the APP



For IOS



For Android

2 Register an account

Run the APP, input user name and password, Choose Region, then tap <Login>.

After tap <Login> will reach the Home menu.

Registration screen showing fields for Email, Password, and Choose Region. A Login button is at the bottom.

Home screen showing 'My Home' and 'Device' options. A bottom navigation bar includes Home, AI, Message, and Me icons.

3 Adding Device

Connect power adapter to the camera. Plug the adapter into an outlet. Wait until the camera indicator light on. Tap button <Add Device> in the right corner of the main menu. Aim the scanning window at the QR code on the camera.

QR scanning screen with a 'Scan QR Code' header and a 'Manual Add' button at the bottom.

Tap button <Red slow flashing> when the camera LED is blinking in red.

'Indicator Light' screen with options: Red slow flashing, Blue steady or blue slow flashing, Red and blue alternating flashing, and Other indicator light statuses.

Tap button <Next> to connect camera hotspot.

'Wi-Fi Configuration' screen showing a diagram of a router, camera, and phone. It includes instructions and a 'Next' button.


Select a 2.4GHz/ 5GHz WIFI network for the camera to connect and input the WIFI password, tap button <Next>.

'Wi-Fi Configuration' screen with input fields for WiFi name and password, and a 'Next' button.


Input the password, Tap button <Next> to connect WIFI.

Login screen with fields for User name and New password, and a 'Next' button.


Waiting for the WIFI connecting.




Device was added successfully and tap <Next>.



Set a device name.




Choose the accurate region in where you want to setup your devices.




4 Mounting the Camera


Place cube camera on a table




Keep a gap of more than 10 inches (25cm) between objects to the side of the camera lens to avoid overexposure caused by infrared light reflection.



2 Drill and install anchors
Anchors are not required if the wall is made of wood




3 Screw the mounting bracket into position




4 Press the camera to the mounting bracket until click into place

Keep a gap of more than 10 inches (25cm) between objects to the side of the camera lens to avoid overexposure caused by infrared light reflection.



1 Screw hole positioning card



2 Drill and install anchors
Anchors are not required if the wall is made of wood




3 Screw the mounting bracket into position



4 Press the camera to the mounting bracket until click into place



Rotate the camera to adjust the view angle and check it by using the live stream which you can access in the app.



5 Notification of Compliance

FCC Compliance Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.