

Use Instruction

Thank you for choosing our toy R/C car. To ensure correct and pleasing operations, please read through the following use instruction and have enough understanding of the product before using.

⚠ CAUTION:

■ BATTERY OPERATED PRODUCT

Not recommended for children under 6 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

■ EQUIPPED WITH A SMALL SCREWDRIVER THAT MAY BE NEEDED




Please notice that the small screwdriver is not a toy, must store it where the children cannot access it. Retain it for future use for adults.

How to Insert the Battery



1. Turn the two switches located on both the car and the controller to the "OFF" position.
2. According to the arrowhead that shows, open the battery cover.
3. Insert the batteries following the picture.
4. Close the battery compartment.





How to Play with the Rc car

1. Turn the two switches located on both the car and the controller to the "ON" position.
2. Then operate the car.
3. When the remote control car is turned on and the remote controller is paired, the red light flashes and stops, indicating that the pairing has been successful. Do not turn the steering wheel on the remote controller when pairing. If the red light keeps flashing, please approach the remote control car and wait patiently.
4. When the remote control car is turning left or right, please turn the steering wheel on the controller first, and then press the forward or backward functions on the remote controller.
5. If the car does not run in a straight line adjust the steering alignment lever located beneath the chassis.
6. When your R/C model car begins to lose performance, power, or function, it may be time to recharge the rechargeable battery or change the new battery!



Operating Guide





Battery Safety Information

1. Don't short-circuit terminals.
2. Don't recharge non-rechargeable batteries.
3. Rechargeable batteries may only be charged under the supervision of an adult.
4. Remove all batteries if vehicle will not be used for a long period of time.
5. Dispose of batteries safely. Don't dispose of batteries in fire as they may explode.
6. The battery charger used should be regularly examined for damage to the cord, plug, enclosure and other parts. In the event of damage do not use it until it has been repaired.
7. Exhausted batteries are to be removed from the toy.
8. Keep these instructions for future reference: they contain important information.
9. Packaging has to be kept since it contains important information.
10. Rechargeable batteries are to be removed from the toy before being charged.

Care and Maintenance

1. Always remove batteries from the toy when it is not being used for a long period of time.
2. Wipe the toy gently with a clean damp cloth.
3. Keep the toy away from direct sunlight or direct heat.
4. Do not submerge the toy into water that can damage the electronic assemblies.



MADE IN CHINA

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.