


User Manual



CiNMOORE

CATALOG

[ENGLISH]

1.What's in the box?	P.01
2.What's in the box?	P.02
3.Installation	P.03
4.Installation	P.04
5.Installation	P.05
6.Adding Camera	P.06
7.Adding Camera	P.07

[ESPAÑOL]

1.¿Qué hay en la caja?	P.11
2.¿Qué hay en la caja?	P.12
3.Instalación	P.13
4.Instalación	P.14
5.Instalación	P.15
6.Añadir Cámara	P.16
7.Añadir Cámara	P.17

1 . What's in the box?




Camera x1



Mounting
Base x1




Mounting
Screws x1



Adapter x1



Power
cord x1




User
Manual x1

Turned Up




Reset
Button

Micro SD
card slot



Speaker



Type-C
power
connector



2 . Installation

It can be placed on the writing desk, dining table, coffee table and other flat surfaces, and can also be fixed on the wall.

1Wall Installation


Step 1

First , use a pencil to mark the distance between the holes on the wall and then use a drilling tool to drill two holes at the mark. The diameter of the holes is about 6mm and the depth of the holes is about 30mm.




Step 2

Nail the two Long Valley expansion nuts into the holes.




Step 3

Place the quick release plate with the arrow side up, align the holes of the plate with the holes of the wall, put the screws through the holes of the base, and screw into the expansion nuts on the wall with a Phillips screwdriver.



Step 4

Align the notch on the bottom of the camera with the raised part of the base and then turn it clockwise until it locks into place.



⚠ Note for wall installation


The mounting wall should be able to support at least 3 times the total weight of the camera.

⚠ Warning

To prevent injury, the unit must be securely fastened to a ceiling or wall according to the installation instructions.

3 . Adding Camera

Plug the power cable into the Type-C power connector on the back of the camera and the camera will turn on automatically with the blue light blinking.



Tips: After power on, please do not turn the camera head with your hand. If the lens positioning is not accurate, you can calibrate it through the CiNMOORE APP.

Indicator light

Camera Status	Indicator Color
Matching network	• Blue light flashing
Equipment is working normally	• Blue light
Upgrading	• Blue light and low flash

Connect to CiNMOORE APP



Download and install the CiNMOORE APP by searching "CiNMOORE" in the APP Store® or Google Play®.

Google Play and the Google Play logo are trademarks of Google LLC.

App Store and Apple logo are trademarks of Apple Inc.

Company Statement

(1) We have tried our best to ensure the completeness and accuracy of the materials. If you have any questions or disputes, we reserve the rights to provide clarification or interpretation.

(2) We will update the content promptly based on product functionality and regularly modify the products or programs described in this information. Updates will be included in the new version without prior notification.

(3) The content of this material is for customer reference only. There is no guarantee that it is exactly the same as the product. Please refer to the actual product for accurate information.

(4) The camera parts shown in this information are for illustration purposes only and do not represent the purchased configuration.

Operating conditions:

Temperature: -10° to 45°C (14° to 113°F)

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Information

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: this equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician to help.

To maintain compliance with the FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Use only the supplied antenna.

FCC Conditions

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

1 . ¿Qué hay en la caja?




Cámara x1




Base de
Montaje x1



Tornillos de
Montaje x1



Adaptador x1



Cable de
alimentación x1




Manual de
Usuario x1

Subido




Botón de
Reinicio

Ranura
para
tarjeta
Micro SD



Altavoz



Conector de
alimentación
Type-C



2 . Instalación

Se puede colocar en el escritorio, la mesa del comedor, la mesa de café y otras superficies planas, y también se puede fijar en la pared.

Instalación en la Pared


Paso 1

Primero, utiliza un lápiz para marcar la distancia entre los agujeros en la pared y luego utiliza una herramienta de perforación para hacer dos agujeros en la marca. El diámetro de los agujeros es de aproximadamente 6 mm y la profundidad de los agujeros es de aproximadamente 30 mm.




Paso 2

Clave las dos tuercas de expansión Long Valley en los agujeros.




Paso 3

Coloque la placa de liberación rápida con el lado de la flecha hacia arriba, alinee los agujeros de la placa con los agujeros de la pared, inserte los tornillos a través de los agujeros de la base y atornille en las tuercas de expansión en la pared con un destornillador Phillips.



Paso 4

Alinea la muesca en la parte inferior de la cámara con la parte elevada de la base y luego gírala en sentido horario hasta que se encierre en su lugar.




⚠ Nota para la instalación en la pared

La pared de montaje debe ser capaz de soportar al menos 3 veces el peso total de la cámara.

3 . Añadir Cámara

Conecte el cable de alimentación a la alimentación tipo C conector en la parte posterior de la cámara y

La cámara se encenderá automáticamente con la luz azul parpadeando.



Consejos: Después de encender, no encienda el cabeza de la cámara con la mano. If la lente po-El sitio no es preciso, se puede calibrar a través de la APP CiNMOORE.

Luz indicadora

Estado de la Cámara	Color del Indicador
Red de emparejamiento	• Luz azul parpadeante
El equipo está funcionando normalmente	• Luz azul
Actualización	• Luz azul y parpadeo lento

Conéctate a la aplicación CiNMOORE



Descarga e instala la aplicación CiNMOORE buscando 'CiNMOORE' en la App Store ® o Google Play ®.

Google Play y el logotipo de Google Play son marcas comerciales de Google LLC.

App Store y el logotipo de Apple son marcas comerciales de Apple Inc.

Declaración de la Empresa

(1) Hemos hecho todo lo posible para garantizar la integridad y precisión de los materiales. Si tiene alguna pregunta o disputa, nos reservamos el derecho a brindar aclaraciones o interpretaciones.

(2) Actualizaremos el contenido oportunamente en función de la funcionalidad del producto y modificaremos regularmente los productos o programas descritos en esta información. Las actualizaciones se incluirán en la nueva versión sin previo aviso.

(3) El contenido de este material es solo para referencia del cliente. No se garantiza que sea exactamente igual al producto. Consulte el producto real para obtener información precisa.

(4) Las piezas de la cámara mostradas en esta información son solo a título ilustrativo y no representan la configuración del producto comprado.

Condiciones de funcionamiento:

Temperatura: de -10°C a 45°C (de 14°F a 113°F)

Declaraciones de la FCC

Este dispositivo cumple con la parte 15 de las normas de la FCC. El funcionamiento está sujeto a las siguientes dos condiciones: (1) este dispositivo no debe causar interferencias perjudiciales y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo la interferencia que pueda causar un funcionamiento no deseado.

Información de la FCC

Tenga en cuenta que los cambios o modificaciones no expresamente aprobados por la parte responsable del cumplimiento podrían invalidar la autoridad del usuario para operar el equipo.

Cumplimiento de la FCC: Este equipo ha sido probado y se ha comprobado que cumple con los límites para un dispositivo digital de clase B, de conformidad con la parte 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial.

Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales a las comunicaciones de radio. Sin embargo, no se garantiza que no se produzcan interferencias en una instalación particular. Si este equipo causa interferencias perjudiciales a la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se recomienda al usuario intentar corregir la interferencia mediante una o más de las siguientes medidas:

- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo a una toma de corriente en un circuito diferente al al que está conectado el receptor.
- Consultar con el distribuidor o un técnico de radio/televisión experimentado para obtener ayuda.

Para mantener el cumplimiento de las directrices de exposición a RF de la FCC, este equipo debe instalarse y operarse con una distancia mínima de 20 cm entre el radiador y su cuerpo. Utilice solo la antena suministrada.

Condiciones de la FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CiNMOORE

support@cinmoore.com

***Our company reserves the right to finalize product failure.**



FCCID: 2BMXI-CMC2U

CiNMOORE

