


TALOSBO

Enjoy Leisure Time

ROBOTIC POOL CLEANER User Manual

Talosbo Pleco Pro



FCC Statement

Note: This equipment has been tested and found to comply with the limits according to Part 15 of the FCC Rules of a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications or persons. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorientate or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the manufacturer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This compliance to FCC radiation exposure limits for an uncontrolled environment, and minimum of 20 cm separation between antenna and body.

Warning

Changes or modifications of this product are not expressly approved by the party responsible for compliance (Talosbo), and unauthorized modifications could void the user's authority to operate the equipment.

Compliance Declaration

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Importer: Talosbo Inc.

Website: www.talosbo.com

Thank you for choosing Talosbo.

You've now joined a family of millions who have already put their trust in Talosbo to take care of their pools and are enjoying the convenience of a pristinely clean pool.

This user manual will help you maintain your device and ensure it performs at its maximum efficiency for years to come. Please take a few moments to read through.

If you have any questions, please visit our website at www.talosbo.com and contact our customer service team for assistance or more information.

Packing List

NO.	Name	Model	QTY(pc)
1	Device	Talosbo Pleco Pro	1
2	Charger	/	1
3	User Manual	/	1
4	Quick Guide	/	1
5	Hook	/	1

CONTENTS

Packing List	02
Important Safety Precautions	04
1. Specifications	05
2. Structure	07
2.1 Product External Overview	07
2.2 Product Internal Overview	07
3. Compatible Pool Types	08
4. Get Started	08
4.1 Charge Your New Pleco Pro	08
4.2 Set Up Your New Pleco Pro	09
4.3 Connect to the App	10
4.4 Choose Your Cleaning Mode	11
4.5 Run Your New Pleco Pro	13
5. Do A Filter Cleaning	15
6. Maintenance and Storage	16
6.1 Replace the Tracks	16
6.2 How to Store	17
7. Troubleshooting Solutions	18
8. Talosbo Customer Care	19
9. FAQ and Troubleshooting	19
10. Conventional Warranty	20

Important Safety Precautions

Read this manual carefully and use your device in accordance with the instructions. Talosbo is not liable for any damages or injuries caused by improper use.

Instructions:

1. Do not operate your Talosbo pool cleaner while people or animals are in the pool.
2. Turn the cleaner off while not in use or while performing maintenance.
3. Do not allow children to ride the Talosbo pool cleaner under any circumstances. Please supervise children when they are around an operational Talosbo pool cleaner.
4. Use only authorized Talosbo power adapters.
5. The adapter cord should only be replaced by a qualified electrician or Talosbo Customer Care.
6. It's suggested to plug the power adapter into a power strip or surge protector rather than directly into an electrical outlet.
7. Ensure your device is powered off and the charging port is dry before charging. While charging, your Talosbo pool cleaner should be kept in a cool place. Do not cover your Talosbo pool cleaner while charging as this may cause components to overheat.
8. Do not run your Talosbo pool cleaner out of the water as it may lead to overheating.
9. Only certified professionals should disassemble the sealed drive kit of your Talosbo pool cleaner.
10. The oil seal around the motor contains grease, which may cause a small amount of water pollution if the motor is damaged. If you suspect there is a leak, stop using the unit immediately.
11. Do not pierce the shell of your Talosbo pool cleaner, throw, or damage the cleaner intentionally.
12. When placing your device into the water, do not drop or throw it. For best results, gently lower it into the pool.

Attention

Failure to operate the device as per the cautions can cause a damage to the device or personal injury.

1. Charge the unit before first use.
2. Do not over charge the cleaner, which will reduce the battery life.
3. Charge the cleaner prior to being stored for a long time (over 6 months) to maintain an optimal battery life.
4. Do not operate the cleaner while pool filter is running.
5. Remember to wash and clean the filter basket and cotton foam after each use.
6. Store the cleaner in a cool and ventilated place, away from direct sunlight or any heat source.
7. Use only the pool cleaner in the following water conditions:


Temperature	41-95°F (5-35°C)
pH Value	7.0-7.4
Chlorine	Maximum 4 ppm
NaCl	Maximum 5000 ppm

1. Specifications

Model	Pleco Pro
Pool size	2150Sq.ft / 200m ²
Depth	1.6-9.8ft (0.5-3m)
Device dimension	485(L)*360(W)*240(H)mm
Weight	9.65kg
Charging time	3.5h
Runtime	up to 210mins
Battery capacity	7800mAh
Battery voltage	21.9V
Motor power	95W
Charger Input	100 - 240V~,50/60Hz
Charger output	25.2V === 2.5A
Filtration	Double-level
IP grade	IPX8 Waterproof
OTA upgrading	Available
APP connection	Available

2. Structure

2.1 Product External Overview



a.Handle

Use the handle to remove and transport the device.

b.Cleaning Mode

Customize cleaning modes on the cleaner.

c.On/Off Button

Turn on/ turn off the device.

d.Pump

Pump water out through the outlet.

e.Lid Open Button

Open the cover to take out the filter basket.

f. LED Indicator

Different light colors indicate device status.

g. Charging Port

Connect the charger to charge the device.

h. Track

Enhances ability to climb walls and overcome obstacles.

i. Roller Brush

Loosens dirt and collects it into the device.


2.2 Product Internal Overview

j.Filter Basket(180µm)

Collects dirt and debris, install before use and clean after each use.

k.Filter Foam

An auxiliary filter designed to trap fine dirt particles. Recommended for floor cleaning. Avoid installing it in pool water with heavy dust, as it may affect the cleaner's performance.





Note:

Do not operate the device if the top cover or roller brush is damaged. If any liquid leaks from the sealed parts, stop charging or using the device immediately.

3. Compatible Pool Types

This device is suitable for cleaning floors, walls, and waterlines in in-ground pools up to 2150 sq. ft. (200 m²), including rectangular, oval, and irregular shapes. It is compatible with pools made of PVC, gunite, tile, and other materials.




4. Get Started

4.1 Charge Your New Talosbo Pleco Pro

The device is equipped with a lithium-ion rechargeable battery. Charge the battery before first use and when it is low.

Connect your device to a power outlet using the included cable and adapter.



Note:

1. When charging, ensure your device is at least 3m (approx. 10ft) away from the edge of the pool.
2. To reduce the risk of fire, keep your device and adapter away from direct sunshine or water when charging.

- 3. For safety, always double-check that the device is powered off and the charging port is dry before charging.
- 4. When yellow LED is flashing, you should charge the device immediately.
- 5. The optimal charging environment is a temperature of 41°F -95°F (5°C -35°C), RH of 5%-95%.

The U-shaped LED indicator on the top of the cleaner changes color to Indicate the battery status. It flashes yellow when the battery is low during operation and turns solid blue when fully charged.


Refer to the guide below for detailed information on the LED indicator and the corresponding device statuses.

LED Color	LED Status	Description
Yellow	Pulsing	Charging, Battery < 30%
	Flashing	Under Working, Battery< 15%
	Solid	Under Working, Battery 15%-30%
Blue	Pulsing	Charging, Battery 30%-99%
	Solid	Charging, Battery 100%
		Under Working, Battery >30%
Red	Flashing	Check the error code in the app and refer to the troubleshooting section in the user manual for details

4.2 Set Up Your New Talosbo Pleco Pro

Press the on/off button  to turn on the device, the power button will light up white, and The LED indicator will display the battery status. Once WiFi is connected, a beep will sound. You can then check the battery level and set the cleaning mode via the app.

Press and hold the on/off button for 3 seconds until a beep sounds to turn off the device.




Note:

If the red LED is flashing, refer to the troubleshooting section in this manual or call for service.


4.3 Connect to the App

You can download the Talosbo App to your smart mobile device by scanning the QR code below, or by searching for "Talosbo" in Google Play or App Store.

	iOS	Android
	iOS 12 and up	Android 10.0 and up

Open the app, create an account or log in, and follow the instructions to pair your Talosbo Pleco Pro.

Enable Bluetooth on your phone, select your Pleco Pro in the app, and connect. Once connected, a beep will sound, confirming the connection.



Note:

1. App operations must be done before the device enters the water, as the Wi-Fi connection may be lost once submerged.
2. You can update the device via the app using OTA technology.