

882x170mm 双面印刷

126 mm

170 mm

T711TV

Skyaudio

Wireless TV Headphone



Hunan Tianyu Huayun Intelligent Technology Co., Ltd.

Any problem, please contact us:
skyaudio2025@163.com

Table of Contents

1. Table of Contents..... 01

2. Product Parameters 02

3. Description of Product Buttons 04

4. Headphone Charging 05


5. Diagram of TV Sound Settings 06-09

6. FCC Statement 10

Product Parameters

EN	
Driver Unit	40mm
Impedance	32Ω
Headphone Power	20mW
Sensitivity	105dB +/-3dB
Frequency Range	20Hz-20KHz
Transmission Connection	30m
Battery Capacity	500mAh
Charging Time	2-3h
Working Time	≤20h

Description of Product Buttons



Headphone

1 On/Off (Power Button)

2 Volume "-"


3 Volume "+"

4 "M" to switch movie / TV sound mode

5 Type-C Charging Port

Headphone Charging

2 Ways To Charge



Charging 1

Adapter Charging

Charging 2

Computer Charging

Red, Charging Status

Blue, Full Charged Status

Normal Charging 2-3 Hours

Note:

(1) Headphone low battery: 'Battery low' voice prompts, alarms every 3 minutes, and the red light flashes twice.

(2) For the first charge, it is recommended to charge for more than 4 hours.

Diagram of TV Sound Settings

Note: The following lists the common sound output methods of some TVs. If your TV brand is not included here, please refer to your TV's user manual for detailed instructions.

Figure1:

SONY TV

```
graph TD
    A[Headphones or speaker] --> B[Options]
    A --> C[Press TV or remote control]
    B --> D[Setting]
    C --> D
    D --> E[Sound setting]
    E --> F[Headphone/Audio Out]
    E --> G[Speaker]
    F --> H["Headphone (3.5mm,RCA, Optical)"]
    F --> I[Audio Out]
    I --> J[Sound or amplifier, etc.]
    G --> K[TV Speaker]
    G --> L[Audio System]
    K --> M["(TV and headphones have sound at the same time)"]
    L --> N[Headphones have sound]
```

06

Figure2:

SAMSUNG TV

```
graph TD
    A[Connecting optical method] --> B[MENU/press TV or remote control]
    A --> C[Settings]
    C --> D[Sound]
    D --> E[Other setting]
    E --> F[SPDIF Output]
    F --> G[Dolby Digital]
    F --> H[PCM]
    G --> I["Optical Output (marked with X)"]
    H --> J["TV Speaker (3.5mm,RCA)"]
    H --> K[External Speaker/Audio Output]
    K --> L[Sound or amplifier, etc.]
    B --> M[MENU/press TV or remote control]
    M --> N[Settings]
    N --> O[Sound]
    O --> P[Sound Output]
    P --> Q[Receiver]
    Q --> R[Headphone has sound]
    P --> S[Optical]
    S --> T[Optical Output]
    B --> U[MENU/press TV or remote control]
    U --> V[Settings]
    V --> W[Sound]
    W --> X[Speaker Settings]
    X --> Y[Speaker Select]
    Y --> Z[PCM; External Speaker]
    Z --> AA[TV Speaker]
    AA --> AB["TV Speaker (3.5mm,RCA, Optical)"]
    AB --> AC["TV and headphones have sound at the same time"]
```

07

Figure3:

LG TV

```
graph TD
    A[Output setting1] --> B[MENU]
    A --> C[Press Smart by remote control or setting]
    B --> D[Sound]
    C --> D
    D --> E[Sound Out]
    E --> F[TV Speaker]
    F --> G["3.5mm,RCA,Optical (TV and headphones have sound at the same time)"]
    E --> H[LG Sound Sync Optical]
    E --> I[LG Sound Sync wireless]
    E --> J[External Speaker Optical/HDMI ARC]
    J --> K[Digital Sound Output PCM]
    K --> L["(Optical, output)"]
    E --> M[Headphones]
    M --> N["(3.5,RCA, Optical)"]
```

08

Figure4:

LG TV

```
graph TD
    A[Output setting2] --> B[Home Page]
    B --> C[Settings]
    C --> D[Sound]
    D --> E[Sound setting]
    E --> F[ARC Mode]
    F --> G[Off]
    G --> H[TV has no sound]
    E --> I[TV Speaker]
    I --> J[On]
    J --> K[TV has sound]
    E --> L[Digital Sound Output(PCM)]
    L --> M["(Optical)"]
    A --> N[Sound]
    N --> O[Sound Out]
    O --> P[TV has sound 3.5mm, RCA]
    O --> Q[Audio Out Optical/HDMI,ARC]
    O --> R[LG Sound Sync Fiber Optic]
    O --> S[LG Sound Sync wireless]
    O --> T[Audio Out Wired]
```

09

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

10