

51.2mm

Spider Find My Tracker  Works with Apple Find My Works with Android Find Hub INSTRUCTION MANUAL PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE	Getting Started - Remove the product from the packaging. - Please retain all packaging after you have checked and counted all the parts and the contents against the parts list. Package Contents - Spider Find My Tracker *3 - Key Chain *2 - Luggage Tag *1 - Manual - Redeemable Information Card*3 Key Features - Smart Finder - Uses Apple Find My app & Google Find Hub app to find your device - Find from Apple & Google device - Sim compatible Safety Instructions - Keep the unit away from heat sources, direct sunlight, water and any other fluids. - Do not operate the unit if it has been exposed to water, moisture or any other fluids to prevent damage to the unit. - Do not use the unit if it has been dropped or damaged in any way. - Repairs to electrical equipment should only be performed by a qualified technician. Improper repairs may place the user at serious risk. - Do not use the unit for anything other than its intended use. - Keep the unit out of reach of children. - This appliance is not a toy. - Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.	Specifications - Size: 2031 (ø) x 7mm - Battery: Replaceable CR2032 battery - Working Time: 10 months - Volume: 80.0dB - Net weight: 5.0g - App Name: Apple Find My & Google Find Hub Description of Parts  Battery Replacement The product includes one pre-installed CR2032 button cell battery, when battery is drained, replace battery as below: - Rotate the back cover counterclockwise to remove. - Replace only with a 3V CR2032 Lithium coin battery as per the indicated polarity. - Put back the cover and secure it tightly.	WARNING • INGESTION HAZARD: This product contains a button cell or coin battery. • DEATH or serious injury can occur if ingested. • A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. • KEEP new and used batteries OUT OF REACH of CHILDREN • Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body. 	 This symbol marked on the product indicates "Warning: contains coin battery" - Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate. - Even used batteries may cause severe injury or death. - Call a local poison control center for treatment information. 1x3V CR2032 battery. - Non-rechargeable batteries are not to be recharged. - Do not force discharge, recharge,	disassemble, heat above 45 degree C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns. - Ensure the batteries are installed correctly according to polarity (+ and -). - Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. - Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations. - Always completely secure the battery compartment. If the battery compartment	does not close securely, stop using the product, remove the batteries, and keep them away from children. Instructions for Use Power on/off the unit Power on: Short press the Power button once and you'll hear a ring tone, indicating it is powered on and will be in pairing status. Power off: Long press the Power button for three seconds, it should beep twice, indicating it is powered off. Factory Reset - Press the button four times rapidly and then hold it a fifth time until you hear a ringing chime. - A reset operation is required to enable the device to enter the pairing state again. (synchronization of Find My also require simultaneous unbinding) and rebind the new Apple ID account. Add to the Find My App - Open "Find My" app on your supported iPhone, iPad, iPod Touch or Mac computer. - Allow notifications from the app. - Select "Items" at the bottom, then tap "Add Other Item" or tap on "+" icon directly. - Select "Other Supported Items" - Make sure your Spider Find My Tracker is close to your phone. It will pop-up "Searching Items" - You will see pop-up "Spider Find My", then tap "Connect". - Follow the pop-up to fill items, and select on entry, then tap "Continue". - When "This Item Is Linked to Your Apple ID" pop-up, tap "Agree" - Tap "Finish" to complete the setup.
Function Introduction Find Items - tap "Play Sound" to make your Spider Find My Tracker beep when it is nearby. Find your Item's location - Your Spider Find My Tracker's last known location will appear on the map as the emoji icon you choose during setup. Tap "Directions" to navigate to the last known location of your item. Notifications - Enable the "Notify When Found" toggle, when your Spider Find My Tracker location is seen by another Find My "enabled" device, you will receive a notification of its updated location. - Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your Smart tracker behind and it is no longer in range of your device. Note: "Notify When Found" can only be activated when your Spider Find My Trackers out of range. Lost Mode - When your Spider Find My Tracker is lost under "Lost Mode", tap the "Enable" tab, a screen calling Lost Mode will pop up, tap "Continue". You can enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your Spider Find My Tracker. - Tap "Activate" to enable "Lost Mode". Note: - When "Lost Mode" is enabled, "Notification When Found" is automatically disabled. - When "Lost Mode" is enabled, your Spider Find My Tracker is locked and cannot be paired to a new device.	Rename Item - You can rename your Spider Find My Tracker. Remove Item - Make sure "Lost Mode" is disabled and tap "Remove Item". After selecting the option, the system will pop up "Remove Item?" and tap "Remove" to remove the device. - The Spider Find My Tracker is now reset and ready to pair to a new device. Share This Item - Tap "Add Person" to share this Item - Tap "Continue" and select trusted people to share. - Tap "Share" and wait for the recipient to accept the invitation Others also can located this item. And tracking notification will be muted. *Available for iOS 17 above version. System Requirements and Compatibility - Apple ID - iPhone models with iOS 14.5 or later. - iPad models with iPadOS 14.5 or later. About the Find My App The Apple Find My network provides an easy, secure way to locate your personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch. - For full tracking functionality, update your device to the latest OS version	If Your Item Is Lost: How Others Can Contact You This tracker features an NFC sensor. If you lose your item, a finder can easily view the contact details to help return it to you. - Step 1: You must enable "Lost Mode" in the Apple Find My app under your phone number and email beforehand. - Step 2: The finder simply needs to hold the top of their iPhone, with NFC function, close to the tracker's NFC sensor. - Step 3: A contact page will automatically pop up on their screen, showing the details you provided. Anti-Stealing & Safety To prevent unwanted tracking, this device complies with Apple Find My security guidelines. - Unwanted Tracking Alerts: If someone else's tracker is traveling with you over time, your Apple device will notify you. After a while, if you still haven't found it, the tracker will play a sound to let you know where it is. - How to Disable: To stop sharing the location, press and hold the function button for 3 seconds until you hear two beeps. This will disable the tracker's location-sharing. Apple servers When pairing a device with Find My app, the phone will link to the Apple's servers. Pairing may fail because of network problems. The following action is recommended.	a. Change the phone's network, such as switching between Wi-Fi and mobile. The first pairing may take a long time. Please wait patiently. b. Reset your Spider Find My Tracker. c. When "Lost Mode" is enabled, DO NOT REMOVE ITEM in the APP. Your this item will be locked and cannot be paired to a new device. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark, or registered trademark of Cisco in the U.S. and other countries and is used under license. Set up using the Google Find Hub App - Go to Google Play and search for "Find Hub" - Install the app or tap to "Update" - Hit "Open" or tap on the Find Hub app icon on your phone home page - Sign in to your Google Account. You might want to select the checkbox that says "Don't ask again" if you have more than one account, your item will link to the primary account setup on your phone. - You might be asked to allow some permissions. Review the terms and confirm.	Connect to the Find Hub App - Make sure your phone's Bluetooth is ON and you are connected to the Internet. - Bring your tap close to your phone and wait for the pop-up "Wireless Tap" to Wireless locate, on the pop up bottom sheet, hit "Connect" - Read and accept the prompts to complete the pairing Enable Lost Mode If your item goes missing, select the device in the "Find Hub" app and tap "Mark as lost" You will receive a notification once its location is detected. You can also leave your contact details so anyone who finds the item can get in touch with you. Location Sharing Select the device in the "Find Hub" app and tap "Share Device". Once the invitation is accepted, the shared tracker will appear in both users' "Find Hub" apps. Both users can track the location and ring the device locally. Unknown tracker alerts Your safety comes first. "Find Hub" is designed to prevent unwanted tracking. If your phone detects an unfamiliar tracker traveling with you, you will receive an alert. You can view its location on a map, ring it to find it or get further safety guidance. Privacy Your location data is end-to-end encrypted, meaning that Google can never view or access it. Only you can see where your items have been and currently are. With the Find Hub app, Google does not use nor share your data. The information you share about yourself and your devices remains confidential.	Find Hub helps you find and connect to what matters in a single, secure place. Find your belongings quickly and safely – even if your devices are offline. Plus, seamlessly and securely share your location with friends & family for peace of mind. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android TV (in select devices (devices or phones) and in certain countries for age-eligible users. Find Hub and Android are trademarks of Google LLC. Care and maintenance Read the following recommendations before using the unit. Following these you will be able to enjoy the product for many years. - Don't expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected. - Don't use abrasive cleaning solvents to clean the unit. - Don't expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort or certain plastic parts. - Don't dispose of the unit in the fire as it will result in an explosion. - Don't expose the unit to contact with sharp objects as this will cause scratches and damage. - Don't let the unit fall down onto the floor. The internal circuit might get damaged. - Don't attempt to disassemble the unit as it may get damaged if you are not professional.	FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.