



LED PROJECTOR

User Guide



Due to continuous improvement, actual product may differ from the manual, manual is for reference only.


PACKING LIST




1 Projector




2 Remote
(Batteries Not Included)



3 User Manual



4 HDMI Cable



5 Power Cable

01/Remote control introduction

**Power button:**

Turn on/off

**Mute button:**

Mute

**Focus button:**

Adjust focal distance

**Input button:**

Choose to enter the Application Center, HDMI

**Back button:**

return to last step

**Quick Menu Key:**

Enter the setting pop-up window interface

**Home button:**

short press and return to the homepage

**Direction Buttons:**

- Up
- Down
- Left
- Right
- OK

**Volume button:**

Volume-, Volume+

**NETFLIX:**

Direct enter NETFLIX

**YouTube:**


Direct enter YouTube

**Prime video:**



Direct enter PrimeVideo

● To avoid power shortage, please do not mix up the old and new batteries. To avoid battery leakage and corrosion, please take the battery out if do not use remote control for a long time.




02/Host Appearance and Function Description



03/Interface connect



Display the USB connection is successful



04/Setting


- On the homepage, select Settings




- Network & Internet Setting



- Signal source Setting



- Bluetooth & Accessories Setting



05 /APP


First step

On the homepage, select
All Apps




Second step

Select App store




Third step

You can search for what you need




06/Miracast and DLNA/MagicCast


• On the homepage, ScreenCast Assistant




• Miracast



• DLNA




• MagicCast



07/Speaker mode setting


First step

On the homepage, select
My APPS--Bluetooth Speaker




Second step

Connect to the Bluetooth for
playing music



Third step



playing music




08/Electronic focusing

Electronic focusing

Press the "☺" and "☹" buttons on remote control to adjust the clarity



09/Projection distance & size




10/Technology Features

Imaging technology	TFT LCD
Native resolution	1280*720
Light source	LED
Focus mode	Auto focus
Projection distance	0.91-6.43 M
Screen size	28.5-200 inches
Aspect ratio	16: 9 and 4: 3 and Auto-fit


Power Input	100V-240V-50/60HZ
Input	USB*1/HDMI*1/I/R*2
Output	Earphone
Speaker	4Ω5W
Unit size	207*155*180mm
Net Weight	1.46KG
Throw Ratio	1.37:1

11 / Projector Installation


- ① Loosen the bottom screw hole counterclockwise,
Take off the machine.



- ② Rotate the machine to a fixed position.



- ③ Installation completed.




● Fixed Hanger Screw Hole Type: 1/4 inch threaded hole

Note: The above brackets are not included with the machine, and are for illustration only.

12/Unload the dust net and clear

First step

Take out dust filter from the projector bottom



Second step


Clean the dust net

- ❶ For your safety, please cut off the power before cleaning



Third step

Align the bottom bayonet and
Install the dust filter



FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Please read the notes carefully:

- To ensure stable power supply, please use national standard power cable and power cord with grounding;
- Please use the type of power supply indicated on the projector and the supplied power supply for power supply;
- Please do not disassemble the machine yourself, otherwise the company will not undertake warranty service;
- Do not look directly at the projector lens while the machine is working, it might cause damage to your eyes;
- To prevent clogging the projector vents, do not cover them with cloth, carpet or other materials;
- This projector does not have waterproof function, please keep it away from rain, moisture and other items containing liquid such as vase, cup, etc;
- To prevent electric shock, please keep the projector away from rain, water or moisture;
- Cut off the power supply if do not use this projector for a long time;
- Use the original foam or other anti-shock material to protect projector if you need transport this projector;
- If you find the projector has problems, please contact with the supplier, do not repair by yourself;
- To extend the projector life span and protect your eyesight, we suggest you may have a break after 3-4 hours using.

Maintain Indication:

1-year warranty from factory, for more warranty information, please contact with supplier. (Warranty service does not include housing, instruction manual, packaging and user's personal subjective objections to image, sound quality, timbre, etc.)