

Instruction Manual

K09 Helmet headphones

Installation tutorial


Fixed installation by clamps

Step 1




Secure the product to the back clip, back clip, and helmet
Attach Velcro separately to fix it, and pull the steel clip
Simply fix it to the left edge of the helmet

Step 2




Stick the headphone Velcro separately into the
Bluetooth headphone groove on the inside of the helmet

Step 3



Attach the speakers to the Velcro positions
on both sides of the helmet
(Short line horn on the left, long line horn on the right)

Step 4



Attach the microphone Velcro to the inside of the helmet
near the mouth .Paste the microphone
(organize the label and lining)

Step 5



Insert the plug into the headphone jack

Step 6



installation is complete

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Installation function description



- ① Turn on and off/answer, hang up, refuse to answer/pause/play
flashlight on and off/Ambient lights on and off
- ② Volume+ /Next song
- ③ Volume- /Previous song
- ④ Headphone jack
- ⑤ Charging socket
- ⑥ Voice assistant
- ⑦ Ambient light
- ⑧ Charging display/Bluetooth connection indicator
- ⑨ flashlight
- ⑩ Screen

Key operation instructions

Power on button

Power on (in press and hold for 3 seconds in the shutdown state, hear "power on";
Flashing red, blue, green and orange lights, The ambient light is on)

Boost

Power off (press and hold for 5 seconds in the power on state, "hear Power off", Ambient light for 1 second)

Pairing mode

Pairing mode (When the device is powered on the red blue green and orange light blinks, and
the phone Bluetooth is turned on to search for K09, After connecting the mobile phone, the red,
blue, green and orange lights are bright)

Answer

Answer the phone (power down in the connection state, short press to answer the phone)

Terminate a call

Terminate a call(short press to end a call)

Reject call

Terminate a call(Long press for 2 seconds)

Music play/pase tap on music

Terminate a call(short press to end a call)

Volume+keys

Volume Plus(when playing music,shortpress);Next song(when music state, press and hold for 2 seconds)

Volume - keys

Volume Plus(when playing music,shortpress);Next song(when music state, press and hold for 2 seconds)

Voice assistant

Single player voice assistant key, summon voice assistant

Atmosphere lights

After successfully pairing the ambient light, it will remain on for a long time; Click the power button to play/pause music;
Double click the power button to turn on/off the flashlight; Press the power button three times to turn on/off the ambient light.

Bluetooth indications and prompts

Power on status (when Bluetooth connection is successful, the ambient light stays on)

When Bluetooth is disconnected, the blue light flashes

Low battery alarm (prompts "low battery" every 60 seconds when turned on)

Charging status (red light on continuously during charging, fully charged light off)

FMPattern

Mode switch

Press and hold the mode button for 2 seconds to switch between Bluetooth mode and FM mode.

Auto-scan

Press and hold 2S V+ to search forward, press and hold 2S V- to search backward.

Station switching

Click the power button to switch stations in sequence.

Volume+

Volume+

Volume-

Volume-

Music Sharing Mode

Mode Activation

Long press the mode button for 2 seconds
(cycles through Bluetooth/FM, Music Sharing, Intercom)

Transmit/Receive Switch

Double click the call button

Share pairing receiver

Default receiver after mode switching

Intercom Mode

Mode Activation

Long press the mode button for 2 seconds
(cycles through Bluetooth/FM, Music Sharing, Intercom)



Intercom Operation

Long press the call button to intercom

Clear Intercom Pairing Mode

Press V+/V- simultaneously for 5 seconds

Notes



the power delivered by the charger must be between min [0.3]Watts required by the radio equipment, and max [3]Watts in order to achieve the maximum charging speed.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.